Revision A contains system configuration instruction for MX2's shipped with an abbreviated version of ROM-DOS. System configuration instructions for the expanded version of ROM-DOS begin with Revision B. Please contact your LXE customer support representative for assistance.

MX2 Reference Guide

MX2A137REFGD
October 2000
E-EQ-MX2RG-A-ARC

LXE®

Copyright © 2000 by LXE Inc.
An EMS Technologies Company
All Rights Reserved

MX2A137REFGD

REVISION A

REGULATORY NOTICES

Notice:
LXE Inc. reserves the right to make improvements or changes in the products described in this manual at any time without notice. While reasonable efforts have been made in the preparation of this document to assure its accuracy, LXE assumes no liability resulting from any errors or omissions in this document, or from the use of the information contained herein.

Copyright Notice:
This manual is copyrighted. All rights are reserved. This document may not, in whole or in part, be copied, photocopied, reproduced, translated or reduced to any electronic medium or machine-readable form without prior consent, in writing, from LXE Inc.
Copyright © 2000 by LXE Inc., An EMS Technologies Company
125 Technology Parkway, Norcross, GA 30092, U.S.A. (770) 447-4224
LXE is a registered trademark of LXE Inc. All other brand or product names are trademarks or registered trademarks of their respective companies or organizations.
Note: The original equipment's Reference Manual is copyrighted by PSC® Inc. *This* manual has been amended by LXE® Inc., for the MX2 and Docking Stations with PSC's express permission.

Notice:
The long term characteristics or the possible physiological effects of radio frequency electromagnetic fields have not been investigated by UL.

FCC Information:

This device complies with FCC Rules, part 15. Operation is subject to the following conditions:

1. This device may not cause harmful interference
   and
2. This device must accept any interference that may be received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

Warning: Changes or modifications to this device not expressly approved by LXE, Inc., could void the user's authority to operate this equipment.

Shielded cables must be used with this unit to ensure compliance with the FCC Class A limits.

Docking Cradles Product Label Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

EMC Directive Requirements:
This is a Class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.

Industry Canada:

This Class A digital apparatus meets all requirements of the Canadian Interference Causing Equipment Regulations. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Approvals:

EMI / EMC Standards:	**Transceiver:**	**Safety Standards:**
FCC Part 15 Subpart B	FCC Part 15, Subpart C	EN 60825-1
EN 50022 Class A	ETSI 300 328	CDRH Class 2
EN50082-1	IC-RSS 210	

Table of Contents

CHAPTER 1 INTRODUCTION AND SPECIFICATIONS 1-1

Introduction 1-1
Document Conventions 1-2
Technical Specifications 1-3
General 1-3
Physical 1-3
Keypad 1-4
Display 1-5
Battery 1-6
Power Management 1-7
Memory 1-7
Standard Range Laser Scanner 1-8
PC Card 1-8
IR Communications Port 1-9
Docking Pads 1-9
Radio PC Card 1-10
Contacting LXE 1-12
Manuals and Accessories 1-14
Manuals 1-14
Accessories 1-14

CHAPTER 2 USING ADVANCED FEATURES 2-1

Introduction 2-1
Programming the Enter Keys 2-1
Key Combinations for International Characters 2-2
International Characters and LXE Terminal Emulations 2-3
Resetting the MX2 2-4
Warm Boot 2-4
Cold Boot 2-4
Safe Boot 2-5
Hardware Reset 2-6
Using PC Cards 2-7
The IR Serial Port 2-7
Laser Scanner 2-9

The Disk Drives 2-10
Additional Drives 2-10
Configuring the MX2 2-11
Troubleshooting - Enable I 2 of 5 2-11
Transferring Files 2-12
Advanced Power Management 2-15
Batteries 2-15
Doze Mode 2-15
Auto-Off Timer 2-15
Backlight 2-15
Power Management at the Radio Card 2-16
Radio PC Card Configuration 2-17
Getting Started 2-17
Installing ODI Drivers 2-17
Installing NDIS Drivers 2-27
Proxim Configuration Settings 2-30
Lucent Configuration Settings 2-34
RF Throughput, Performance and Troubleshooting 2-38
Power Management at the Proxim RangeLAN2 Access Point 2-38
Site Survey 2-39
Throughput and Performance 2-40
Operational Problems 2-40
Problems with DOS Drivers 2-42

CHAPTER 3 SOFTWARE CONFIGURATION 3-1

Introduction 3-1
BIOS and DOS 3-1
PC Card and RF Networking Software 3-1
Disk Drives and Files 3-2
Drive A 3-3
Drive B 3-5
Drive C 3-8
Drive D 3-10
Drive E 3-10
System Configurations 3-11
Default Configuration 3-11
I/O PC Card Support Configuration 3-13
Data Entry 3-14
Keyboard Data Entry 3-14

Barcode Data Entry 3-14
Infrared Port Data Entry 3-14
Terminal Emulation 3-15

CHAPTER 4 THE CONFIGURATION UTILITY 4-1

Introduction 4-1
Installing and Starting the Utility on a PC 4-1
BIOS Upgrade File Location 4-2
RF Files Location 4-2
Quick Start 4-5
The Main Menu 4-7
Default 4-9
The Custom Configuration Menu 4-10
The File Configuration Windows 4-15
The Program Settings Windows 4-25
The Comm Settings Dialog Box 4-33
Comm Port 4-33
Baud Rate 4-33
The File Transfer Window 4-34
List File 4-34
Save 4-35
Browse 4-35
Files to Transfer 4-36
Add 4-36
Browse 4-37
Edit 4-37
Delete 4-37
Receive 4-38
Send 4-39
Done 4-39

CHAPTER 5 USING XFER 5-1

Introduction 5-1
About XFER 5-1
Syntax and Parameters 5-2
XFER Parameters 5-2
The XFER_ARGS Environment Variable 5-21
Multiple-Option Blocks 5-23

The Modem-Initialization File 5-25
Keywords 5-25
Sample Modem- Initialization File 5-29
Performance 5-30
Error Codes 5-31

CHAPTER 6 COMMANDS 6-1
Introduction 6-1
System Utilities 6-1
ROM-DOS Commands 6-9
ROM-DOS vs MS-DOS 6-9

CHAPTER 7 THE DOCKING STATION 7-1
Introduction 7-1
The Single Dock 7-2
Attaching the Single Dock to a Computer 7-3
The Power Adapter 7-4
Using a Single Dock 7-5
Technical Specifications 7-7

APPENDIX A CONNECTOR CONFIGURATIONS A-1
Introduction A-1
The MX2 Computer A-1
Serial IR Port A-1
Single Dock A-2
25-Pin Connector A-2

APPENDIX B PROGRAMMING PARAMETERS B-1
Introduction B-1
Parameters, Settings, and Defaults B-2
Code 39 ..... B-2
Interleaved 2 of 5 ..... B-3
Matrix 2 of 5 ..... B-3
Standard 2 of 5 ..... B-4
Code 11 ..... B-4
Codabar/Ames B-5

MSI B-5
Code 93 ..... B-6
Universal Product Code-A (UPC-A) B-6
Universal Product Code-E (UPC-E) B-7
European Article Numbering (EAN) Japan Article Numbering (JAN) B-7
UPC, EAN, JAN Extensions B-8
Code 128 ..... B-8
Labelcode 4/5 ..... B-8
Other Controls B-9

APPENDIX C BARCODES FOR CONFIGURING MX2 C-1

Introduction C-1
Default Settings C-2
Barcodes C-5
Predefined Defaults C-5
Code 39 ..... C-5
Interleaved 2 of 5 ..... C-8
Matrix 2 of 5 ..... C-11
Standard 2 of 5 ..... C-14
Code 11 ..... C-17
Codabar/Ames C-20
MSI C-24
Code 93 ..... C-27
Code 128 ..... C-29
Labelcode 4/5 ..... C-32
UPC-A C-33
UPC-E C-35
EAN/JAN C-37
UPC/EAN/JAN Extensions C-39
Other Controls C-40

APPENDIX D KEY MAPS D-1

Keypad D-1
Key Map 101-Key Equivalencies for Batch Units D-2

INDEX

Illustrations

Figure 1-1 The MX2 Hand Held Computer 1-3
Figure 1-2 MX2 Keypad 1-4
Figure 1-3 MX2 Display 1-5
Figure 1-4 Battery Pack 1-6
Figure 1-5 Laser Scanner Location at Top of Unit 1-8
Figure 1-6 PCMCIA Card 1-8
Figure 1-7 IR Port Location on Bottom of Unit 1-9
Figure 1-8 Docking Pad Location on Bottom of Unit 1-9
Figure 2-1 Location of the Enter Keys 2-1
Figure 2-2 Program Trigger Icons 2-1
Figure 2-3 Location of the Hardware Reset Mechanism 2-6
Figure 2-4 The IR Port on Bottom of Unit 2-7
Figure 2-5 Scanner Aperture Location 2-9
Figure 2-6 Scan Button Location 2-9
Figure 2-7 XFER Options (Xmodem Protocol) 2-13
Figure 3-1 CONFIG.SYS File on Drive A 3-3
Figure 3-2 AUTOEXEC.BAT File on Drive A 3-4
Figure 3-3 CONFIG.SAF File on Drive A 3-4
Figure 3-4 CONFIG.SYS File on Drive B 3-6
Figure 3-5 AUTOEXEC.BAT File on Drive B 3-7
Figure 3-6 CONFIG.SAF File on Drive B 3-7
Figure 3-7 CONFIG.SYS File on Drive C for Default Configuration 3-11
Figure 3-8 AUTOEXEC.BAT File on Drive C for Default Configuration 3-12
Figure 3-9 CONFIG.SYS File on Drive C for I/O PC Card Support 3-13
Figure 3-10 AUTOEXEC.BAT File on Drive C for I/O Card Support 3-13
Figure 4-1 Configuration Utility Main Menu 4-7
Figure 4-2 Example - The Important Dialog Box 4-9
Figure 4-3 Example - The Open Dialog Box for Selecting a Configuration File 4-10
Figure 4-4 Example - The Open Dialog Box for Selecting a Program Settings File 4-11
Figure 4-5 Example - The Custom Configuration Menu 4-12
Figure 4-6 The Prompt for Saving Changes to the Current File Configuration 4-13
Figure 4-7 The Prompt for Saving Changes to the Current Program Settings 4-14
Figure 4-8 Example - The First File Configuration Window 4-15
Figure 4-9 The File Selection Dialog Box for Adding an Application File 4-16
Figure 4-10 The Edit File Properties Dialog Box for an Application File 4-18
Figure 4-11 Example - The Second File Configuration Window 4-19
Figure 4-12 Example - The Select DOS Files Dialog Box 4-21
Figure 4-13 Example - The Third File Configuration Window 4-23
Figure 4-14 Example - The First Program Settings Window 4-27

Figure 4-15 Example - The Second Program Settings Window 4-28
Figure 4-16 Example - The Third Program Settings Window 4-29
Figure 4-17 Example - The Fourth Program Settings Window 4-30
Figure 4-18 Example - The Fifth Program Settings Window 4-31
Figure 4-19 Example - The Last Program Settings Window 4-32
Figure 4-20 The Comm Settings Dialog Box 4-33
Figure 4-21 The File Transfer Window 4-34
Figure 4-22 The Prompt for Saving Changes to the Current File List 4-35
Figure 4-23 The File Selection Dialog Box for Adding a Data File 4-36
Figure 4-24 The Edit File Properties Dialog Box for Editing a Data File 4-37
Figure 4-25 Example - PC Receiving Files from MX2 4-38
Figure 4-26 Example - PC Sending Files to MX2 4-39
Figure 7-1 Charging/Communication Dock for One MX2 7-2
Figure 7-2 Back Panel of the Single Dock 7-3
Figure 7-3 US Dock Power Adapter 7-4
Figure A -1 Serial IR Port A-1
Figure A -2 Docking Pads – Right, Center, Left A-1
Figure A -3 The Cable Connector for the Single Dock A-2
Figure D-1 MX2 Keypad D-1

Table of Contents

CHAPTER 1 INTRODUCTION AND SPECIFICATIONS 1-1

Introduction 1-1
- Document Conventions 1-2

Technical Specifications 1-3
- General 1-3
- Physical 1-3
- Keypad 1-4
- Display 1-5
- Battery 1-6
- Power Management 1-7
- Memory 1-7
- Standard Range Laser Scanner 1-8
- PC Card 1-8
- IR Communications Port 1-9
- Docking Pads 1-9
- Radio PC Card 1-10

Contacting LXE 1-12

Manuals and Accessories 1-14
- Manuals 1-14
- Accessories 1-14

Illustrations

Figure 1-1 The MX2 Hand Held Computer 1-3
Figure 1-2 MX2 Keypad 1-4
Figure 1-3 MX2 Display 1-5
Figure 1-4 Battery Pack 1-6
Figure 1-5 Laser Scanner Location at Top of Unit 1-8
Figure 1-6 PCMCIA Card 1-8
Figure 1-7 IR Port Location on Bottom of Unit 1-9
Figure 1-8 Docking Pad Location on Bottom of Unit 1-9

Chapter 1
Introduction and Specifications

Introduction

This reference guide is a technical supplement to the "MX2 Installation and Operator's Guide." It contains technical information about the MX2's system configuration, disk drives, utilities, and DOS commands. Included in the appendices are a table of configuration parameters, barcodes for setting those parameters, and connector configurations for the MX2 and the Single Dock.

This manual is provided as a reference guide for system administrators, developers, and programmers who want to create end-user solutions for MX2 DOS portable computers. It is not intended for use by first-time MX2 users.

LXE offers two basic configurations:

- RF Configuration – a MX2 *with* a PCMCIA radio and antenna. The unit may be configured with or without an integrated laser scanner.
- Batch Configuration – a MX2 *without* a PCMCIA radio and antenna. The unit may be configured with or without an integrated laser scanner.

Both configurations can use the Single Dock without requiring adjustment.

MX2's running LXE's Terminal Emulation programs require a PCMCIA radio, antenna and RF configuration files.

	The "MX2 Installation and Operator's Guide (LXE DocID MX2A136OPGDWW)" is directed toward the MX2 operator. It is delivered with each MX2. It contains safety warnings, descriptions of the controls and connectors, and instructions for day to day operation.

Document Conventions

This reference guide uses the following document conventions:

Convention	Meaning
ALL CAPS	All caps are used to represent disk directories, file names, and application names.
Menu|Choice	Rather than use the phrase "choose the Save command from the File menu", this manual uses the convention "choose File|Save".
"Quotes"	Indicates the title of a book, chapter or a section within a chapter (for example, "Document Conventions").
[ ]	Indicates a key on the keyboard (for example, [Enter]).
	Indicates a reference to other documentation.
	Differences in operation or commands due to radio type.
ATTENTION	Keyword that indicates vital or pivotal information to follow.
	Attention symbol that indicates vital or pivotal information to follow. Also, when marked on product, means to refer to the manual or operator's guide.
	International fuse replacement symbol. When marked on the product, the label includes fuse ratings in volts (v) and amperes (a) for the product.
Note:	Keyword that indicates immediately relevant information.
CAUTION	Keyword that indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury.
WARNING	Keyword that indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.
DANGER	Keyword that indicates a imminent hazardous situation which, if not avoided, will result in death or serious injury.

Technical Specifications

General

CPU	AMD Am486 33Mhz
Operating Temperature	-10C° to 50C° (14°F to 122°F)
Storage Temperature	-20°C to 70°C (-4°F to 158°F)
Sealing	IP54 (dust and splashing water)
Humidity	0 to 95% non-condensing
Drop	4 foot multiples
Usage	Indoors, Limited outdoors

Physical



Figure 1-1 The MX2 Hand Held Computer

Parameter	Specification
Height	7.98 in (198 mm)
Width	3.4 in (86 mm)
Depth	1.4in (36 mm)
Weight (with battery)	No radio, no laser 11.5 oz. (325 grams) No radio, with laser 11.7 oz (330 grams) Radio, no laser 12.7 oz (360 grams) Radio, laser 12.9 oz (365 grams)

Keypad



Figure 1-2 MX2 Keypad

Parameter	Specification
Type	Rubber Membrane
Keys	38-key (alphanumeric)
Function Keys	5 dedicated - FN, CTL, ALT, 2 special
Shift Keys	5 Shifted Function Keys
Shared Numeric	No
Arrow Keys	4, implemented on numeric keys
Key colors	5
Character	Western-European character support
Emulation	LXE ANSI Plus, TN3270, TN5250

Display



Figure 1-3 MX2 Display

Parameter	Specification
Type	Supertwist graphics LCD
Writable Area	Approximately 2.2” x 1.75” (5.6 cm x 4.4 cm) plus icon area
Char	16 line by 20 character 8 line by 20 character
System Status	Dedicated icons (8)
Graphics	128 x 160
Prog. Interface	BIOS/Memory Map
Lighting	Backlight with programmable timeout
Contrast Adjustment	Keyboard adjustable

Battery



Figure 1-4 Battery Pack

Main - Rechargeable

Technology	Nickel Metal Hydride (NiMH) Battery Pack
Configuration	3 x AA
Capacity	1250 mAH
Protection	Polyswitch PTC and Klixon circuit breaker
Life, Operating	> 8 hrs. batch; > 6 hrs with RF link
Life, Storage	> 14 days data retention, with fully charged pack
Charging	In 1 Slot dock: =< 3 hrs.

Backup - Rechargeable

Type	Rechargeable Lithium (Li)
Data Retention Period	> 1 hour
Recovery from Cutoff	1M min, 5M typical after 5M operation

Power Management

Parameter	Specification
Automatic Shutdown	Unit turns off when battery door is removed.
Shutdown Timer	Yes
Low Battery Indication	Yes
APM Compatible	Yes
Turn on to Previous State	Yes
Batteries required for Operation	Yes

Memory

RAM	8 Mbytes	
	Mapping	Contiguous from 0000
	Upgradability	Factory upgrade
Flash	2 Mbytes, 3.3V (default: 2M)	
	Mapping	Combined DOS and BIOS

Standard Range Laser Scanner



Figure 1-5 Laser Scanner Location at Top of Unit

Location	At top of unit, built into unit
Aperture Height	0.65" (1.65 cm)
Aperture Width	1.06" (2.69 cm)

PC Card



Figure 1-6 PCMCIA Card

Note: The PCMCIA card must be installed by authorized personnel.

Parameter	Specification
Physical	One only Type 2 with custom ejector. Sealed inside unit.
Location	Bottom of unit
Connections	Per PCMCIA specifications
RF Usage	Internally mounted antenna
Memory usage	ATA Flash
Modem usage	Not supported. (Cable exits card end)
Power Management	Not supported
Vpp	5V only

IR Communications Port



Figure 1-7 IR Port Location on Bottom of Unit

Physical	.65" wide x .25" high (1.65 cm x .63 cm)
Location	Bottom of unit
Interface	Modified RS-232
Dock Usage	Pad on bottom of unit for RS-232 input (RXD) while in dock.

Docking Pads



Left Middle Right
RXD Neg Pos
Figure 1-8 Docking Pad Location on Bottom of Unit

Physical	Total width of three pads 1" (2.54 cm) Width of individual pad .06" (.15 cm)
Location	Bottom of unit
Dock Usage	With MX2 in the dock, keypad facing front of dock: Right-most pad : positive lead used for recharging batteries. Middle pad: negative lead used for recharging batteries. Left-most pad: RS-232 input (RXD) into MX2 while in dock.

Radio PC Card

Note: Radio PCMCIA cards must be installed / removed by authorized personnel.

LXE 6400 PCMCIA 2.4GHz Type II

Parameter	Specification
Bus Interface:	PCMCIA 2.0, Type II
Radio Frequencies:	2.4 - 2.4835 GHz FH SS
RF Data Rates:	1.6 Mbps
RF Power Level:	100 mW
Channels	15
Connectivity:	Novell, TCP/IP, Ethernet, NDIS, ODI
Operating Temperature	60° C (140° F)

LXE 6500 PCMCIA 2.4GHz Type II

Parameter	Specification
Bus Interface:	PCMCIA 2.0, Type II
Radio Frequencies:	2.4 - 2.4835 GHz IEEE MAP 802.11 DS SS
Range	1400 ft dependant on speed and environment
RF Data Rates:	11 Mbps
RF Power Level:	35 mW nominal
Channels	11 US, 13 Europe, 4 France, 1 Japan
Connectivity:	Novell, TCP/IP, Ethernet, ODI
Supply Current w/o Encryption	Doze Max 9mA, Receive Max 240mA, Transmit Max 300mA (with encryption, add 10mA)
Output Power	15 dBm (nominal)
Operating Temperature	0°C to 55°C (32°F to 131°F)
Security	RC4 IEEE 802.11 compliant encryption

Contacting LXE

LXE offers a variety of services to help you with your questions. LXE has an *automated attendant phone system* to help direct your call to the proper department or individual.

Product Information

To obtain information concerning LXE products contact your Project Coordinator at **(770) 447-4224 (USA) or +31 346 217070 (Europe)** if you know their extension, otherwise contact the LXE customer support help line at **(770) 449-0154 (USA) or +31 346 217070 (Europe)**.

Additional Training

To obtain information on training, contact the Manager, Technical Services at **(770) 447-4224 extension 3412 (USA) or +31 346 217070 (Europe)**.

Sales Support

To obtain sales support contact your Project Coordinator at **(770) 447-4224 (USA) or +31 346 217070 (Europe)**, if you know their extension, otherwise:

Ordering Equipment

To place an order or get pricing information on additional LXE equipment or accessories contact LXE Sales at **(770) 447-4224 (USA) or +31 346 217070 (Europe)** and select **option 2 (USA) or +31 346 217070 (Europe).**

Spare Parts

To order spare parts or obtain information on spare parts contact the LXE customer support help line at **(770) 449-0154 (USA) or +31 346 217070 (Europe)**.

Technical Support

To obtain technical support for LXE equipment:

- Have a copy of your Field Service Installation Report or last Field Service Report on hand (if available).
- Call LXE Technical Support at **(770) 449-0154 (USA) or +31 346 217070 (Europe)**.

Repair

To return equipment for repair:

- For DOS based products, ensure that the hard disk has been properly backed-up. LXE assumes no liability for the data stored on the hard drive.
- Remove rechargeable battery from all battery-powered devices.
- Have model and serial numbers ready.
- Equipment _____
- Model Number _____
- Serial Number _____
- Be prepared to give a description of the problem.
- Contact Repair Services at **(770) 449-0154 (USA) or +31 346 217070 (Europe)**.
- Obtain a Return Authorization Number (RA Number).
- Place a copy of the equipment configuration parameters from the last Field Service Report (if available) in the package with the equipment.
- Write the RA number on the airbill in the Reference section and on the outside of the package.
- Return equipment to:

  LXE Repair Services
  125 Technology Parkway
  Norcross, GA 30092

Repair Status

To obtain the status of hardware repairs:

- Have the Return Authorization Number (RA Number) ready.
- Contact Repair Services at **(770) 449-0154 (USA) or +31 346 217070 (Europe)**.

Preventive Maintenance Inspections (PMI)

To obtain information concerning Preventive Maintenance Inspections for LXE equipment, contact the PMI Field Coordinator at **(770) 447-4224 extension 3452** or contact the LXE customer support help line at **(770) 449-0154 (USA) or +31 346 217070 (Europe)**.

Manuals and Accessories

Manuals

LXtrEme MX2 Reference Guide	MX2A137REFGD
LXtrEme MX2 Docking Station Operator's Guide	MX2A139OPGDWW
ANSI Plus Reference Guide	ANSIPA136REFGD
TN3270 Terminal Reference Guide	TN3270A136RFGD
TN5250 Terminal Reference Guide	TN5250A136RFGD
TN6600 System Administrator's Guide	TN6600ADMINGD
User's Guide : OnNet Kernel for Windows 2.0 and PC/TCP Network Software Kernel for DOS 4.0	9000A136FTPUSER

Accessories

Cables

Dock Serial Cable (9 Pin and 25 Pin) [dock to PC or dock to printer]	2325A052CBLDOCK925
Cable, Serial RJ-DB9 (terminal to PC cable)	2325A051CBLRJDB9

Batteries, Battery Chargers and Power Supplies

Battery, 1250 mAh, NiMH, MX2	2325A376BATTNMH850
Dock, Single, Power Supply, External AC, US	2325A301PSDOCK110
Dock, Single, Power Supply, External AC, Int'l	2325A302PSDOCK220
Battery Charger, 110V Single-slot	2325A377CHGR1US
Battery Charger, 220V Single w/Euro connector	2325A378CHGR1EU
Battery Charger, 220V Single w/IEC 320 connector	2325A379CHGR1IEC
Battery Charger, 110V Four-slot w/pwr supply US	2325A380CHGR4US
Battery Charger, 220V Four-slot w/pwr supply Euro	2325A381CHGR4EU

Software Configurations

MX2, Batch, No Radio, No TE	2326X00501A
MX2, Proxim 2.4GHz	2326X02301A
MX2, Proxim 2.4 with FTP	2326X02401A
MX2, Proxim 2.4 with FTP, ANSI Plus TE	2326X02201A
MX2, Proxim 2.4 with FTP, TN3270 TE	2326X3T201A
MX2, Proxim 2.4 with FTP, TN5250 TE	2326X5T201A
MX2, Lucent 2.4, 802.11	2326X00801A

MX2, Lucent 2.4, 802.11 with FTP	2326X00901A
MX2, Lucent 2.4, 802.11 with FTP, ANSI Plus TE	2326X00701A
MX2, Lucent 2.4, 802.11 with FTP, TN3270 TE	2326X3T301A
MX2, Lucent 2.4, 802.11 with FTP, TN5250 TE	2326X5T301A

Holding Accessories

Softcase	MX2A401CASE
Holster	MX2A402HOLSTER

Utilities and Kits

Configuration Utility	2325A478CONFIGUTIL
Developer's Tool Kit (for C programmers)	2325A476DEVKIT
Universal Program Generator (for batch applications)	2325A477UNIPROGEN

Table of Contents

CHAPTER 2 USING ADVANCED FEATURES 2-1

Introduction 2-1
Programming the Enter Keys 2-1
Key Combinations for International Characters 2-2
International Characters and LXE Terminal Emulations 2-3
Resetting the MX2 2-4
Warm Boot 2-4
Cold Boot 2-4
Safe Boot 2-5
Hardware Reset 2-6
Using PC Cards 2-7
The IR Serial Port 2-7
Laser Scanner 2-9
The Disk Drives 2-10
Additional Drives 2-10
Configuring the MX2 2-11
Troubleshooting - Enable I 2 of 5 2-11
Transferring Files 2-12
Advanced Power Management 2-15
Batteries 2-15
Doze Mode 2-15
Auto-Off Timer 2-15
Backlight 2-15
Power Management at the Radio Card 2-16
Radio PC Card Configuration 2-17
Getting Started 2-17
Installing ODI Drivers 2-17
ODI with TCP/IP 2-18
ODI with NetWare Client 2-20

ODI With IPX/SPX 2-22
ODI Datalight Sockets 2-24
Sample SOCKET.CFG File 2-25
Installing NDIS Drivers 2-27
NDIS for TCP/IP 2-27
Proxim Configuration Settings 2-30
Link Support Layer 2-30
TCPIP Protocol 2-30
Install Proxim RangeLAN2 Drivers 2-30
DOS Configuration Parameters 2-31
DOS Parameters 2-31
Setting the RangeLAN2 Security ID 2-33
Lucent Configuration Settings 2-34
Link Support Layer 2-34
TCPIP Protocol 2-34
Install Lucent WaveLAN II Drivers 2-34
NET.CFG File and Parameters 2-35
WaveLAN_Network_Name 2-35
Station_Name 2-35
AP_Density 2-36
Transmit_Rate 2-36
PortType 2-36
Medium_Reservation 2-36
Card_Power_Management 2-37
Maximum_Sleep_Duration 2-37
Receive_All_Multicasts 2-37
RF Throughput, Performance and Troubleshooting 2-38
Power Management at the Proxim RangeLAN2 Access Point 2-38
MU Access Control 2-38
Message Filtering 2-38
Site Survey 2-39
Throughput and Performance 2-40
Operational Problems 2-40
Problems with DOS Drivers 2-42

Illustrations

Figure 2-1 Location of the Enter Keys 2-1
Figure 2-2 Program Trigger Icons 2-1
Figure 2-3 Location of the Hardware Reset Mechanism 2-6
Figure 2-4 The IR Port on Bottom of Unit 2-7
Figure 2-5 Scanner Aperture Location 2-9
Figure 2-6 Scan Button Location 2-9
Figure 2-7 XFER Options (Xmodem Protocol) 2-13

Chapter 2
Using Advanced Features

Introduction

This chapter provides information about advanced features of the MX2 computers. It does not cover basics, such as use of the keypad and display. For basic information about the MX2, see the "MX2 Installation and Operator's Guide."

Programming the Enter Keys



Figure 2-1 Location of the Enter Keys

The MX2 allows reprogramming of one of the Enter keys. One Enter key may be reprogrammed from a list of available keys. There is no option for swapping the function of the Enter keys. However, if one key is reprogrammed, the other key automatically becomes the Enter key.

To program an Enter key

First, hold down the [ALT] key then the [FN] key and press the desired [Enter] key to reprogram. The program-trigger icon should appear on the right in the display, indicating which Enter key is to be reprogrammed.

Left Enter Key Right Enter Key

Figure 2-2 Program Trigger Icons

Select the key sequence to reprogram the Enter key. The following keys are valid selections:

- Caps
- Intl
- Backspace
- Tab
- Enter

Note: All of these functions, with the exception of the Enter key are the Fn shifted state of another key. When selecting the key, you do not need to enter Fn mode first.

For example, to assign the left Enter key to Caps, press [ALT] then [Fn], then left [Enter], then [Ctrl]. The MX2 automatically translates the Ctrl keypress into the Caps key.

Key Combinations for International Characters

International Characters	Accent or Letter	Letter
á, é, í, ó, ú, É	‘(apostrophe)	a, e, i, o, u, E
ç or Ç	‘(apostrophe)	c or C
à, è, ì, ò, ù	`	a, e, i, o, u
â, ê, î, ô, û	^	a, e, i, o, u
ä, ë, ï, ö, ü, ÿ, Ä, Ö, Ü	:	a, e, I, o, u, y, A, O, U
å, Å	@	None
ñ or Ñ	~	m, n, M, or N
ß	s	s
æ, Æ	!	e or E
¿	?	None
¡	!	!
¢, £, ¥	$	c, k, l, y

Enter international characters by using the following key sequence:

Fn-Alt accent letter

where

Fn-Alt is the key sequence to initiate the Intl key function,

accent is a character from the “Accent or Letter” column, and

letter is a character from the “Letter” column in the same row.

After the international icon appears on the screen, the next key pressed displays an international character and the keypad reverts to normal mode.

International Characters and LXE Terminal Emulations

The international characters shown above are supported in DOS mode only.

LXE's terminal emulation applications (ANSI Plus, TN3270/-E and TN5250) do not support these particular international characters. Use the terminal emulation application configuration utilities to create international characters for use when running terminal emulation applications on the MX2.

Resetting the MX2

One of the critical features of any portable data-collection device is its ability to protect against accidental data loss. In the event a MX2 becomes "locked up" or otherwise in a state in which data can no longer be processed, you can use any of four methods to reset the unit. This chapter describes these methods.

Warm Boot

The warm boot is one of two software methods for resetting a MX2. It is analogous to the **CTL-ALT-DEL** key sequence for rebooting IBM-compatible PCs, and the same key sequence is used to force a warm boot on a MX2. This method of resetting a unit should be used first to attempt to bring it back to a usable state.

*Note: You do not need to press the **FN** key to activate the **DEL** function of the **BkSp** key.*

Since a warm boot can be attempted only from a unit that has been turned on, certain assumptions are made. For example, the rigorous hardware tests that are performed as part of the cold boot sequence are not all necessary. This means the unit restarts faster with a warm boot than with a cold boot.

During a warm boot, data written to the RAM drive (D), the flash drive (C), or an ATA flash card will remain intact. However, if an application is running on a unit before a warm boot, its state cannot be restored.

*Note: If you do not want end users to be able to reset the unit, scan the "Enable CTL-ALT-DEL Reboot Off" barcode in Appendix C "Barcodes" to disable the **CTL-ALT-DEL** reboot.*

Cold Boot

The second software method for resetting a MX2 is the cold boot. A cold boot should be used only if a warm boot is unsuccessful. Performing a cold boot is analogous to pressing the reset button on a PC or to turning the PC's power off and then back on.

To perform a cold boot on a MX2, first turn it off. Then press **[ALT] + [FN] + [Power]**, holding the first two keys down while pressing the third.

Release all three keys simultaneously, and the unit will reset.

Simply removing and inserting the battery pack will not force a cold boot, because the backup battery can provide minimal power to sustain the MX2's operating state. The exception to this is when the backup battery is drained of all power, a condition that you should not let happen.

When a cold boot is performed, all transient data is lost, along with the state of any application that was running on the unit. Data written to the RAM drive (D), the flash drive (C), or an ATA flash card will remain intact. If a cold boot happens because of a dead backup battery, data written to a RAM drive may not be maintained.

A cold boot begins with a retesting of the hardware and then follows with the DOS boot sequence. The unit reboots DOS under the same conditions you would expect from a desktop PC: Device drivers included in the CONFIG.SYS file and applications included in the AUTOEXEC.BAT file are automatically loaded as part of the boot process; any other programs that were loaded before the cold boot will not be reloaded automatically.

Safe Boot

During the DOS boot sequence, control is passed sequentially to the CONFIG.SYS files on drives A, B, and C. A similar process is followed for the AUTOEXEC.BAT files on each drive.

It is possible for a driver or application loading from the CONFIG.SYS or AUTOEXEC.BAT file on drive C to hang the system. A cold or warm boot of the unit will not directly correct the problem, because the troublesome program will be started again as part of the boot sequence. What is required is a method by which the CONFIG.SYS or AUTOEXEC.BAT file on drive C and the loading of the CFGDEV.SYS and DECODE.SYS drivers can be taken out of the normal boot sequence. DOS can help some, with the **CTL-C** and the **F8** escape sequences.

The MX2 provides an alternative method that is less accessible to the end user. To bypass the CONFIG.SYS and AUTOEXEC.BAT files on drive C, reboot the unit (with either a cold or warm boot), and when the message "**`Wait…`**" appears on the display, immediately press the [**ESC**] and **[Space]** keys at the same time. This causes alternative CONFIG.SYS and AUTOEXEC.BAT processing to take place on drives A and B without chaining into the files on drive C.

The unit indicates safe-boot mode by emitting a low tone followed by a higher-pitched tone. The flash drive (C) and the RAM drive (D) will be preserved, and the boot sequence will place the unit at the **C:\>** prompt.

Note: *If you do not hear the two tones indicating the safe-boot sequence, you probably did not press the **ESC** and **Space** keys quickly enough. Reboot the MX2 and press the two keys simultaneously as soon as you see the "**Wait…**" message on the display.*

Hardware Reset

In the extremely rare situation where none of the rebooting methods is successful, you can use a reset mechanism that is located below the keypad matrix directly below the Lamp key.

By inserting a paper clip or other narrow device and pressing gently, the unit will perform a hardware activated cold boot. Only use the same amount of pressure used to press a normal key. Do not use a sharp instrument. If the keypad rubber matrix is punctured, the industrial specifications of the MX2 could be compromised.

Note: Attempt at least two cold boots before going into Hardware reset.



Figure 2-3 Location of the Hardware Reset Mechanism

Upon reset, you will need to set the date and time in the MX2. These DOS programs may run automatically after a Hardware Reset.

Using PC Cards

Note: The PC card slot of the MX2 is not user accessible, but functions in the same manner as the LXE 2325 for software installation, use and general features. Please refer to the "LXE 2325 Reference Guide" for PC card information.

The MX2 has a slot for plugging in PC cards, and each unit is factory-equipped with PhoenixCARD Manager Plus PC card drivers. PC cards provide such features as network connectivity, modem connectivity, and wireless capability. Their primary purpose in the MX2 is to provide additional memory storage by functioning as a disk drive.

The MX2 holds one PC card at a time. If the MX2 has a radio card installed, the radio card will need to be removed before a different PC card can be inserted.

The IR Serial Port



Figure 2-4 The IR Port on Bottom of Unit

The serial port is a half duplex IR (Infrared) port. Through software commands, the port may be set up for IR or a modified RS-232 serial communication.

In general, the IR mode is used when communicating to other IR devices (printers, computers, etc.) and the modified RS-232 mode is used to communicate with the dock for host communications.

In IR mode, all physical communications meet the IrDA physical layer specification. In the modified RS-232 serial mode, the IR port is used to transmit RS-232 level data out the IR port. With the MX2 in the dock, the keypad facing the front of dock, the left-most pad is the RS-232 input (RXD) into the MX2 while it is in the dock.

Note: The MX2 does not propagate the RS-232 hardware signals such as RTS, CTS, DTR, DSR, RI and DCD.

When transferring files using the IR port, flow control must be the same on both sides of the transmission (specifically, with Zmodem: both sender and receiver must use Xon/Xoff).

Laser Scanner



Figure 2-5 Scanner Aperture Location

The Standard Range Scanner aperture is located at the back at the top of the MX2. Barcode scanning is initiated when the user presses the Scan button. The MX2 has one scan button – a large key in the middle of the keyboard labeled Scan. This key cannot be reprogrammed.



Figure 2-6 Scan Button Location

The only option for scanning with the MX2 is with the internal laser. Due to sealing and environmental issues, no external port is available for external tethered scanners. When the MX2 does not have an installed scanner, although the scanner aperture is present, pressing the Scan button has no effect.

To use the laser, aim the top of the unit at a barcode and press the Scan button.

A red LED directly below the LCD display indicates when the scanner is active. The LED switches to green when a scan is successful.

The Disk Drives

The MX2 contains four logical disk drives that provide storage for system files, applications, and data.

Drive A is a read-only drive. Its contents cannot be changed.**Drive B** is a read-only drive used to store system utilities and to initialize the boot process. Its contents cannot be changed.

Drive C is a flash disk drive that allows full read and write access. This drive contains DOS command files, PC card drivers, utilities, and executable files and associated files for applications. It may also contain additional CONFIG.SYS and AUTOEXEC.BAT files to configure your MX2 to run applications.

Drive D is a RAM disk drive. The RAM disk is used primarily for data storage. Programs that need to be loaded into memory and then quickly removed from memory can also be placed here. Drive **D** can also be used for scratch disk space or temporary files.

Note: As with any RAM drive, data on drive D can be lost if the MX2 has a power failure caused by low batteries or a system reset. For truly secure data collection, store your data on drive C or on an ATA flash card.

Additional Drives

Drive **E** exists only if your unit has been configured to use PC ATA flash cards. The PC card looks like a hard disk drive to the operating system. You can use drive **E** for safe and permanent storage of data.

Alternately, drive **E** could be a peer-to-peer or client-server network drive that is accessed through a wireless access point or Ethernet network card link.

Your unit may have other additional logical drives. These might be RAM drives, ATA flash cards, or network drives accessed via wireless access points.

Configuring the MX2

If your unit is not already configured for use when you get it, you can use the Configuration Utility to install applications and set options for barcode scanning. The Configuration Utility operates under Windows 3.1, Windows 95, and Windows NT on a desktop or laptop PC. The Configuration Utility runs XFER automatically. For instructions on using the utility, see Chapter 4 “Configuration Utility.”

You can also use XFER at the DOS prompt or commercially available communications and file transfer software. See Chapter 5 “Using XFER.”

You can also scan barcodes with the MX2 to change MX2 configuration settings. Appendix C “Configuration Barcodes” has barcodes for many common settings.

Troubleshooting - Enable I 2 of 5

Problem

The MX2 configuration does not retain "Enable I 2 of 5" after power down. Note that this is an isolated incident and that the default MX2 with scanner configuration automatically enables Code 39, I 2 of 5, Codabar/Ames, Code 128, UPC-A and EAN/JAN.

Solution

Create a file containing the actual character string of the barcode used to set that particular parameter. The character strings are printed under the barcode in Appendix C – do not add the asterisks to the character string. Any number of setup strings can be used, one per line in the file used. After the file is created, copy the contents to the device PARAMS when the AUTOEXEC.BAT file is loaded.

For example, the setup string to enable I 2 of 5 is `$+$-151EE`.

1. Create an ASCII file – CUSTPARM.TXT – that contains the following line:

```
$+$-151EE
```

2. Place the following line in the AUTOEXEC.BAT file and the command will be run each time the AUTOEXEC.BAT file is run:

```
COPY CUSTPARM.TXT PARAMS
```

Transferring Files

To transfer data or program files, connect your MX2 to the host computer with any of the following accessories:

- Serial cable
- Single Dock

Your software application may have simple file-transfer options, or you can use the XFER utility.

When you use the Configuration Utility to transfer files (see chapter 4), the configuration utility runs XFER automatically for you. If you are not using the configuration utility, using XFER involves entering commands at the DOS command line on both the MX2 and the PC.

The XFER utility is loaded into the MX2 at the factory and placed on drive **B**. If the PATH statement has not been changed, you can run XFER from any drive on the MX2. However, before you can run XFER on your PC, you must install the Configuration Utility onto the PC's hard drive.

The command line syntax for XFER is as follows:

```
XFER [/option1 [/option2] . . .] filename
```

You can use a slash (/) or a hyphen (-) to denote options, and you can use uppercase or lowercase letters for them. Options can be placed before or after the filename on the command line. A sample command line appears at the end of this section.

You can transfer a single file by using XFER with the Xmodem protocol (the default protocol) or transfer multiple files with the Zmodem protocol.

Basic options for Xmodem protocol are listed and described in the following table. The “Default” column indicates whether the option is used (On) or ignored (Off) if you do not include it in the command line. For options that have two or more possible values, the default value is given.

Option	What It Does	Default
filename	Identifies the file to be transferred or received.	None
#	Specifies the communication port to use. Replace the # symbol with the desired setting: 1 = COM1 2 = COM2	1
B#	Specifies the baud rate. Replace the # symbol with the desired setting: 2400 4800 9600 19200 38400 57600 115200	19200
D#	Specifies the number of seconds for XFER to wait for activity before canceling the transfer. Replace the # symbol with the desired number of seconds for the timeout delay. Acceptable values are 0 (no timeout) through 65,535.	60
H or ?	Displays help for the XFER command.	Off
O	Overwrites an existing file with a new file having the same name.	Off
R	Receives the specified file or files.	Off
T	Transmits the specified file or files.	On

Figure 2-7 XFER Options (Xmodem Protocol)

An Example

To transfer a file named MYFILE from a PC to an MX2 using Xmodem protocol, you could use the following lines.

On the PC: `xfer myfile.` This command causes the computer to send the specified file using XFER's default settings.

On the MX2: `xfer /r myfile`. This command causes the MX2 to receive the specified file transmitted from the PC.

Note: For more information about XFER, including Zmodem options, see Chapter 5 "Using XFER."

Advanced Power Management

The MX2 uses advanced power management (APM) to provide the longest battery life. Control of the APM features is provided in the PM.COM utility on drive B of each MX2.

This section provides additional information for getting the most power life out of an MX2 RF unit using the RangeLAN2 wireless LAN PC card.

Batteries

For RF units, LXE recommends the use of fully charged batteries. In general, an MX2 with an RF card should be able to get through a normal 8-hour shift before the batteries need to be replaced or recharged.

Doze Mode

After 8 seconds without a keypress, scanner input, or other system activity, the MX2 goes into a power-saving state known as doze mode. To maximize battery life, especially in an RF environment, try to avoid accidental or unnecessary pressing of the keypad keys.

Auto-Off Timer

After a predetermined time without any system activity, the unit automatically shuts off. The default auto-off timeout is 5 minutes. To maximize battery life, you can set the timeout to a much shorter period.

Appendix C includes bar codes that provide auto-off settings as low as 20 seconds. You can also use the PM.COM utility to set the auto-off timer.

Backlight

Use of the display backlight severely affects battery life in the MX2. For RF applications, do not use the backlight unless it is absolutely necessary. If you do need to use it, you can change the display's auto-off timer to a setting lower than the default (15 seconds).

Appendix C includes bar codes that provide settings as low as 2 seconds for the backlight auto-off timer. You can also use the PM.COM utility to set the timeout.

Power Management at the Radio Card

To conserve battery life, the radio card has an inactivity sleep mode. The *sleep mode* is automatically engaged when a certain period of time has elapsed since the computer has sent or received data over the network. Once the card is asleep, it can be awoken by an access point attempting to send data to it. The time before sleeping is calculated by adding the `Inactivity_min` and `Inactivity_sec` parameter settings.

Note: Do not set an inactivity timeout on an RF MX2 being used as a master station. If the unit goes to sleep, you will lose all communication with your network.

The access point buffers packets that are to be sent to the MX2s. A dozing radio card will receive a sync message and wake-up list from the Access Point every 400 ms. The AP adds a media access control (MAC) address to the wake-up list each time a send attempt fails. (The access point buffers the packet and adds the MAC address of the MX2 to its wake-up list.)

If a MX2 detects that it is on the wake-up list, the radio card exits *doze mode* and enters *receive mode*. Once the radio card wakes up to receive the packet, it stays awake for all future sends until the inactivity timeout expires. This is why it is important to have the inactivity timeout as low as possible. The advantages of a higher timeout value is that the radio card will remain in Receive mode for longer periods of time; network throughput may be better because the unit will not have the delay of coming in and out of doze mode or of waiting for the wake-up list to see if there are any packets.

Generally, in the types of environments that the radio card will be used in, the user should strive for maximum power management. Most MX2 RF applications will not be expecting asynchronous network traffic, and it is doubtful that throughput differences due to power management will be noticeable with these types of applications. Always set the `Inactivity_min` parameter to 0, and set the `Inactivity_sec` parameter as low as possible (preferably to 1). Never set `Inactivity_sec` to 0, as that turns off the power management completely, and the card will always stay in receive mode.

Radio PC Card Configuration

Note: LXE will pre-install radio cards and drivers on MX2 RF units before delivery. These instructions are included for those users who may need to reinstall radio drivers and reconfigure radio parameters.

After installing the radio card, you must configure the MX2 to use the card. This is accomplished with the Configuration Utility. Use of the utility is covered in chapter 4 "The Configuration Utility." This section contains configuration information specific to the use of the Proxim RangeLAN2 (LXE's System 6400) wireless LAN PC card.

Getting Started

The MX2 Configuration Utility is provided with every unit, including the RF models. If you have not already installed it on your PC, install the utility now following the directions in Chapter 4 "The Configuration Utility."

The documentation set for RF includes an RF utilities disk. After installing the Configuration Utility, run the SETUP.EXE program on the utilities disk. Complete the setup procedure to install the drivers and other files required for RF operation onto your PC.

Note: See Chapter 4 "The Configuration Utility" for complete information on using the menus and dialog boxes in the Configuration Utility.

Installing ODI Drivers

The MX2 RF installation package includes *open data-link interface (ODI)* drivers for TCP/IP, IPX/SPX, NetWare Client, and custom installations.

- For TCP/IP, the package provides software from Novell. Novell's TCP/IP stack runs on top of the ODI driver.
- For NetWare Client, Novell's NETX.EXE and VLM.EXE programs use the IPX/SPX protocol stack, which runs on top of the ODI driver.

- These applications allow the user to run Novell client/server applications; to mount drives, printers, and other hardware; and to treat the MX2 RF as if it were a client on a Novell network.
- For other IPX/SPX solutions, the package provides software from Novell. Novell's IPX/SPX stack runs on top of the ODI driver.
- For other software implementations, you can customize one of the provided configurations.

ODI with TCP/IP

Complete the following steps to install the ODI drivers for TCP/IP:

1. Start the Configuration Utility by double-clicking on the icon in the Configuration Utility group on your PC.
2. From the Main Menu, select the Custom button.
3. An *Open dialog box* will appear (see screen displays in Chapter 4). Select the PX_TCPIP.CFG configuration file. In the next Open dialog box, select a program settings file. (If you do not have a specific one that you want to use, select DEFAULT.PRS.)

   The following files are included automatically as part of the NetWare Client download:

   LSL.COM - Link support layer driver

   NET.CFG - ODI configuration file

   RL2PCM.COM - Proxim RF ODI Driver

   TCPIP.EXE - TCP/IP protocol driver

   You need to select your MX2 application and related files.
4. Select the File Configuration button in the Custom Configuration menu.
5. Select the Add button, and use the *File Selection dialog box* (see screen displays in Chapter 4) to include the main application and additional files in your custom installation. Be sure to turn on the Main Application switch for the one you want the MX2 to use.
6. Select the Next button at the bottom of the File Configuration window.
7. In the second File Configuration window, make sure the Vendor Specific option is selected. This option identifies which Phoenix drivers to download.

Note: The I/O-card drivers are not compatible with Proxim's client driver. Do not select the I/O Cards options when using RF.

8. Select the More button to verify that the DOS files you need are included in the download. After viewing the file list and making any necessary changes, return to the File Configuration window.
9. Select the NEXT button to move to the third File Configuration window.
10. If you want to include commands to be executed in the AUTOEXEC.BAT file, select the AUTOEXEC.BAT button. Enter the commands, and save the revised file before exiting from the text editor.

    Note: Verify that the drive and directories of any drivers loaded in the AUTOEXEC.BAT file are correct. The default PX_TCPIP.CFG file assumes these drivers will go to a specific location on the MX2. If you change the destination directory on the MX2 for these files, be sure to change them here, too. The file that you selected as the main application will automatically be appended to the AUTOEXEC.BAT file before it is downloaded to the MX2.

11. If you want to make changes to the CONFIG.SYS file, select the CONFIG.SYS button.

    Note: Certain default configuration parameters and card and socket services drivers will automatically be included at the beginning of the CONFIG.SYS file before it is downloaded to the MX2.

12. Select the Text File button and open the NET.CFG file in the ...\RF\PROXIM directory.
13. Under the heading `Protocol TCPIP`, replace the Xs with the appropriate IP address, IP router, and IP netmask numbers.
14. Save the NET.CFG file before exiting from the text editor.
15. Select the Done button in the File Configuration window to return to the Custom Configuration menu.
16. Modify your program settings and communications settings, if necessary.
17. Select the Download button in the Custom Configuration menu to install the custom TCP/IP configuration on the MX2.
18. Reboot the MX2 when the download is completed.

ODI with NetWare Client

Complete the following steps to install the ODI drivers for NetWare Client:

1. Start the Configuration Utility by double-clicking on the icon in the Configuration Utility group on your PC.
2. From the Main Menu, select the Custom button.
3. An *Open dialog box* will appear (see screen displays in Chapter 4). Select the PX_VLM.CFG configuration file. In the next Open dialog box, select a program settings file. (If you do not have a specific one that you want to use, select DEFAULT.PRS.)

   The following files are included automatically as part of the Novell TCP/IP download:

   IPXODI.COM - IPZ/SPX driver

   LSL.COM - Link support layer driver

   NET.CFG - ODI configuration file

   RL2PCM.COM - Proxim RF ODI Driver

   VLM.EXE - Virtual loadable module manager

   *.VLM - Virtual loadable modules
4. Select the File Configuration button in the Custom Configuration menu.
5. Select the Add button, and use the *File Selection dialog box* (see screen displays in Chapter 4) to include the main application and additional files in your custom installation. Be sure to turn on the Main Application switch for the one you want the MX2 to use.
6. Select the Next button at the bottom of the File Configuration window.
7. In the second File Configuration window, make sure the Vendor Specific option is selected. This option identifies which Phoenix drivers to download.

   Note: The I/O-card drivers are not compatible with Proxim's client driver. Do not select the I/O Cards options when using RF.
8. Select the More button to verify that the DOS files you need are included in the download. After viewing the file list and making any necessary changes, return to the File Configuration window.

9. Select the NEXT button to move to the third File Configuration window.
10. If you want to include commands to be executed in the AUTOEXEC.BAT file, select the AUTOEXEC.BAT button. Enter the commands, and save the revised file before exiting from the text editor.

    Note: Verify that the drive and directories of any drivers loaded in the AUTOEXEC.BAT file are correct. The default PX_VLM.CFG file assumes these drivers will go to a specific location on the MX2. If you change the destination directory on the MX2 for these files, be sure to change them here, too. The file that you selected as the main application will automatically be appended to the AUTOEXEC.BAT file before it is downloaded to the MX2.

11. If you want to make changes to the CONFIG.SYS file, select the CONFIG.SYS button.

    Note: Certain default configuration parameters and card and socket services drivers will automatically be included at the beginning of the CONFIG.SYS file before it is downloaded to the MX2.

12. Select the Text File button and open the NET.CFG file in the ...\RF\PROXIM directory.
13. In the `NetWare DOS Requester` section, assign whatever drive letter you want to FIRST NETWORK DRIVE. Set PREFERRED SERVER to the name of the network to which you will be connecting.
14. Save the NET.CFG file before exiting from the text editor.
15. Select the Done button in the File Configuration window to return to the Custom Configuration menu.
16. Modify your program settings and communications settings, if necessary.
17. Select the Download button in the Custom Configuration menu to install the NetWare Client configuration on the MX2.
18. Reboot the MX2 when the download is completed.

ODI With IPX/SPX

The IPX/SPX configuration downloads the same adapter and protocol drivers as the NetWare Client configuration. It does not download the VLM files.

Complete the following steps to install the ODI drivers for IPX/SPX:

1. Start the Configuration Utility by double-clicking on the icon in the Configuration Utility group on your PC.
2. From the Main Menu, select the Custom button.
3. An *Open dialog box* will appear (see screen displays in Chapter 4). Select the PX_IPX.CFG configuration file. In the next Open dialog box, select a program settings file. (If you do not have a specific one that you want to use, select DEFAULT.PRS.)

   The following files are included automatically as part of the IPX/SPX download:

   IPXODI.COM - IPX/SPX driver

   LSL.COM - Link support layer driver

   NET.CFG - ODI configuration file

   RL2PCM.COM - Proxim RF ODI Driver
4. Select the File Configuration button in the Custom Configuration menu.
5. Select the Add button, and use the *File Selection dialog box* (see screen displays in Chapter 4) to include the main application and additional files in your custom installation. Be sure to turn on the Main Application switch for the one you want the MX2 to use.
6. Select the Next button at the bottom of the File Configuration window.
7. In the second File Configuration window, make sure the Vendor Specific option is selected. This option identifies which Phoenix drivers to download.

   Note: The I/O-card drivers are not compatible with Proxim's client driver. Do not select the I/O Cards options when using RF.
8. Select the More button to verify that the DOS files you need are included in the download. After viewing the file list and making any necessary changes, return to the File Configuration window.
9. Select the NEXT button to move to the third File Configuration window.

10. If you want to include commands to be executed in the AUTOEXEC.BAT file, select the AUTOEXEC.BAT button. Enter the commands, and save the revised file before exiting from the text editor.

    Note: Verify that the drive and directories of any drivers loaded in the AUTOEXEC.BAT file are correct. The default PX_IPX.CFG file assumes these drivers will go to a specific location on the MX2. If you change the destination directory on the MX2 for these files, be sure to change them here, too. The file that you selected as the main application will automatically be appended to the AUTOEXEC.BAT file before it is downloaded to the MX2.

11. If you want to make changes to the CONFIG.SYS file, select the CONFIG.SYS button.

    Note: Certain default configuration parameters and card and socket services drivers will automatically be included at the beginning of the CONFIG.SYS file before it is downloaded to the MX2.

12. Select the Done button in the File Configuration window to return to the Custom Configuration menu.
13. Modify your program settings and communications settings, if necessary.
14. Select the Download button in the Custom Configuration menu to install the IPX/SPX protocol stack on the MX2.
15. Reboot the MX2 when the download is completed.

ODI Datalight Sockets

Copy the ODI Datalight driver files from the installation disk to the pctcp subdirectory on the MX2.

Add the following line to the autoexec.bat file on the root directory:

For MX2's with Lucent (LXE's System 6500) radios:

```
REM ----------------------------------------
---------------------
REM Load the Link Support Layer and the
Lucent WaveLAN ODI driver.
REM ----------------------------------------
---------------------
c:\pctcp\lsl.com
c:\pctcp\wvlan43.com
c:\pctcp\odipkt.com 0x69
c:\pctcp\socketp.exe  c:\pctcp\socket.cfg
```

For MX2's with Proxim (LXE's System 6500) radios:

```
REM ----------------------------------------
---------------------
REM Load the Link Support Layer and the
Proxim ODI driver.
REM ----------------------------------------
---------------------
c:\pctcp\lsl.com
c:\pctcp\RL2PCM.COM
c:\pctcp\odipkt.com 0x69
c:\pctcp\socketp .exe c:\pctcp\socket.cfg
```

Note the following procedure for specifying the subnet mask in the socket.cfg file:

The net mask is specified as part of the ip address in the socket.cfg file. In the ip address command an optional */net_bits* can be used to indicate the number of bits in the network ID. The net mask is used to determine whether an incoming datagram is a broadcast and also for sending UDP broadcasts.

Net masks are more easily represented in binary or hexadecimal format. For example, the IP address 128.1.1.5/24 corresponds to a net mask of 255.255.255.0 (FFFFFF00h), 25 bits to 255.255.255.128 (FFFFFF80h) and 26 bits to 255.255.255.192 (FFF FFC0h).

The default net mask used corresponds to the class of address used if not explicitly specified.

Net Bits	Net Mask	Class	IP address range
8	255.0.0.0	A	0.x.x.x to 127.x.x.x
16	255.255.0.0	B	128.x.x.x to 191.x.x.x
24	255.255.255.0	C	192.x.x.x or higher

If you want to subdivide your network, you can divide it by two for every net bit added. The following table provides information on converting between net bits and net mask. The number of net bits to add when changing a 0 in the net mask to:

Net Bits	Net Mask	Net Bits	Net Mask
1	128	5	248
2	192	6	252
3	224	7	254
4	240	8	255

Sample SOCKET.CFG File

```
# Socket.cfg sets the options for Data Light
socketp.exe
# The section xxx.xxx.xxx.xxx is for this machines
IP
# The net mask is specified as part of the ip
address.
# In the ip address command an optional /net_bits
can be
# used to indicate the number of bits in the
network ID.

#   Net Bits Net Mask      Class IP address range
#  8        255.0.0.0     A     0.x.x.x to
127.x.x.x
#  16       255.255.0.0   B     128.x.x.x to
191.x.x.x
#  24       255.255.255.0 C     192.x.x.x or
higher

# The network can be subdivided by two for every
net bit added.
```

```
#   Net Bits  Net Mask Net Bits Net Mask
#   1         128      5        248
#   2         192      6        252
#   3         224      7        254
#   4         240      8        255

IP address XXX.XXX.XXX.XXX/16

# Interface sets the physical interfaces
# pdr=packet driver
# if0=interface_card
# dix=frame type
# 1500=MTU
# 10=Buffers
# 0x69=ioaddr

Interface pdr if0 dix 1500 10 0x69

# When using a gateway (IP router) to the rest of
the world,
# replace "XXX.XXX.XXX.XXX" with your gateway ip.

route add default if0 XXX.XXX.XXX.XXX

# When using a domain name server (DNS),
# replace XXX.XXX.XXX.XXX with the IP address of
the DNS,

domain server XXX.XXX.XXX.XXX

# Redisplay IP information

IP address

# options, refer to documentation to change

ip ttl 15
tcp mss 1460
tcp window 2920
```

Installing NDIS Drivers

The NDIS driver is the low-level protocol that runs the wireless LAN PC card.

- If you wish to use another version of TCP/IP besides Novell TCP/IP over ODI, use the information in this section to ensure that the implementation will work correctly on the MX2.
- For other software implementations, you can use various configuration files to configure a generic NDIS implementation on the MX2.

NDIS for TCP/IP

Normally, the IP stack talks to a packet driver, which accesses the physical hardware. Packet drivers have not been developed at this time for the RangeLAN2 PC card. To fool the IP stack into thinking that a packet driver is installed, a driver known as a *shim* can be used.

In this implementation, the NDIS driver talks directly to the RF hardware. An NDIS–to–packet driver shim sits above the NDIS driver and translates calls to the packet driver interface into calls that the NDIS driver can understand. The IP stack will make calls to the packet driver shim as if it were talking to the hardware directly. The IP stack has no knowledge of the NDIS driver.

Using the NDIS–to–packet driver shim allows many third-party TCP/IP implementations to work on the MX2.

Complete the following steps to install the packet driver shim:

1. Start the Configuration Utility by double-clicking on the icon in the Configuration Utility group on your PC.
2. From the Main Menu, select the Custom button.
3. An *Open dialog box* will appear (see screen displays in Chapter 4). Select the PX_PKDRV.CFG configuration file. In the next Open dialog box, select a program settings file. (If you do not have a specific one that you want to use, select DEFAULT.PRS.)

   The following files are included automatically as part of the NDIS-to-packet download:

   DIS_PKT.DOS - NDIS-to-packet driver shim driver

   PROTOCOL.2 - Sample NDIS configuration file

   RL2PCM.COM - Proxim RF ODI Driver

The PROTOCOL.2 file will be renamed PROTOCOL.INI when it is saved on the MX2 drive.

4. Select the File Configuration button in the Custom Configuration menu.

5. Select the Add button, and use the *File Selection dialog box* (see screen displays in Chapter 4) to include the main application and additional files in your custom installation. This should include the TCP/IP package you want to load, as well as a protocol manager (e.g., PROTMAN.SYS). Be sure to turn on the Main Application switch for the application you want the MX2 to use.

6. Select the Next button at the bottom of the File Configuration window.

7. In the second File Configuration window, make sure the Vendor Specific option is selected. This option identifies which Phoenix drivers to download.

   Note: The I/O-card drivers are not compatible with Proxim's client driver. Do not select the I/O Cards options when using RF.

8. Select the More button to verify that the DOS files you need are included in the download. After viewing the file list and making any necessary changes, return to the File Configuration window.

9. Select the NEXT button to move to the third File Configuration window.

10. If you want to include commands to be executed in the AUTOEXEC.BAT file, select the AUTOEXEC.BAT button. Enter the commands, and save the revised file before exiting from the text editor.

    Note: Verify that the drive and directories of any drivers loaded in the AUTOEXEC.BAT file are correct. The default PX_PKDRV.CFG file assumes these drivers will go to a specific location on the MX2. If you change the destination directory on the MX2 for these files, be sure to change them here, too. The file that you selected as the main application will automatically be appended to the AUTOEXEC.BAT file before it is downloaded to the MX2.

11. Select the CONFIG.SYS button, and verify that the drives and directories specified for any device drivers in the CONFIG.SYS file are correct. Be sure to include a line to load the protocol manager (e.g., `device=c:\net\protmen.sys /i:c:\net`). By default, NDIS TCP/IP drivers and programs are assumed to be in

the C:\NET directory on the MX2. If you want to put them somewhere else, change the directory paths here. Add any additional drivers that you need to load for your configuration at this time. Be sure to also change the directory specified by the `/I` option of the PROTMAN.SYS device driver in the CONFIG.SYS file.

12. If you need to modify the PROTOCOL.2 file (or any other text file), select the Text File button and open the desired file. (PROTOCOL.2 is located in the ...\RF\PROXIM directory.) Be sure to save the edited file before exiting from the text editor.
13. Select the Done button in the File Configuration window to return to the Custom Configuration menu.
14. Modify your program settings and communications settings, if necessary.
15. Select the Download button in the Custom Configuration menu to install the drivers and applications on the MX2.
16. Reboot the MX2 when the download is completed.

Proxim Configuration Settings

Link Support Layer

```
Link Support
   MEMPOOL 4096
   BUFFERS 8 1500
```

TCPIP Protocol

Substitute the appropriate IP addresses in order for your network to function properly.

```
Protocol TCPIP
   IP_Address XXX.XXX.XXX.XXX
   IP_Router XXX.XXX.XXX.XXX
   IP_Netmask XXX.XXX.XXX.XXX
```

Install Proxim RangeLAN2 Drivers

Socket	A : DO NOT CHANGE - A is the only socket
Initialize_365	N : DO NOT CHANGE - not an Intel chipset
Int	3 : 3, 5, 6, or 15 are available
Mem #1	C100 : Highly Recommended - C100,C200,C300,C400 only options
Port	300 : Highly Recommended - 300 is available
Inactivity_Min	0 : Highly Recommended - lengthens battery life (0-59)
Inactivity_Sec	1 : Highly Recommended - lengthens battery life (0-59)
Sniff_Time	0 : Highly Recommended - lengthens battery life
Domain	0 : 0-15
Station_Type	0 : 0,1, or 2
Peer_To_Peer	N : Y, N
Roam_Config	1 : 0,1, or 2
Mac_Optimize	1 : 0,1
Channel	1 : 1-15
SubChannel	1 : 1-15
Frame	Network dependent

```
Link Driver RL2PCM
        Socket          A
        Initialize_365  N
        Int             3
        Mem #1          C100
        Port            300
        Inactivity_Min  0
        Inactivity_Sec  1
        Sniff_Time      0
        Domain          0
        Station_Type    0
        Peer_To_Peer    N
        Roam_Config     1
        Mac_Optimize    1
        Channel         1
        SubChannel      1
        Frame           Ethernet_II
        Frame           Ethernet_802.2
        Frame           Ethernet_802.3
```


DOS Configuration Parameters

Configuration parameters for DOS can be contained in the NET.CFG or PROTOCOL.INI file. You can use an ASCII text editor to add or modify parameters in those files, or you can edit them using the Text File button in the third File Configuration window of the Configuration Utility. The modifiable parameters are described in the following table.

DOS Parameters

Note: Hex values are indicated with a leading 0x. NET.CFG values do not use the 0x; PROTOCOL.INI values require the 0x.

Keyword	Description
Int	Sets the interrupt (IRQ) line to be used. This must be set to 3, which is the only free interrupt.
Port	Sets the I/O port address. The default is 0x300.
Mem#1 (ODI) Memory_address (NDIS)	Sets the resource memory location (0xC000 to 0xE800). Upper memory blocks from 0xA000 to 0xCFFF are used by MX2 system software. Memory from 0xD000 to 0xDFFF is reserved for PC card client drivers. Since card services use 0xD000, only

Keyword	Description
	0xD400, 0xD800, and 0xDC00 are available for the RF driver. The Proxim driver requires 0x4000 bytes (16 KB) for the memory address.
Domain	Sets the network domain. It can be any number from 0 through 15 and must match the domain of the server or access point to which you want to connect.
Station_type	Sets the status of the RangeLAN2 PC card as a master (2), alternate master (1), or nonmaster (0) station.
Frame Ethernet_802.3 (ODI only)	Indicates that the RangeLAN2 PC card sends Ethernet packets that follow the 802.3 specification.
Socket	Sets the PCMCIA socket (A, B, C, or D) that has the PC card installed. The MX2 always uses socket A for PC cards.
Initialize_365	Determines whether to initialize the Intel 82365SL PCMCIA controller chip. Because the MX2 does not contain that chip, this parameter must be set to N.
Inactivity_min	Sets the number of minutes of inactivity before the PC card goes to sleep. Valid settings are 0 through 20. To maximize battery life, set this to 0.
Inactivity_sec	Sets the number of seconds of inactivity before the PC card goes to sleep. Valid settings are 0 through 55 (values above 5 are rounded to the nearest multiple of 5). To maximize battery life, set this as low as possible, preferably to 1.
Channel	Sets the channel to be used when the RangeLAN2 PC card is acting as the master. Valid settings are 1 through 15.
Subchannel	Sets the subchannel to be used when the RangeLAN2 PC card is acting as the master. Valid settings are 1 through 15.
Master_name	Sets the name of the RangeLAN2 PC card when it is acting as the master. The name may be up to 11 characters and must not contain any spaces. The

Keyword	Description
	default master name is MASTER.
Mac_optimize	Optimizes the RangeLAN2 PC card for the number of concurrent modes. Valid settings are 0 (light) or 1 (normal).
Roam_config	Sets the roaming speed. Valid settings are 0 (slow), 1 (normal) or 2 (fast).
Peer_to_peer	Sets the ability of the RangeLAN2 PC card to talk to other RangeLAN2 peers. Valid settings are 0 (off) or 1 (on).

Setting the RangeLAN2 Security ID

As an added security measure, the RangeLAN2 wireless LAN allows you to set a security ID for each RangeLAN2 card installed on a network. All cards (in access points and target MX2s) must have matching security IDs in order to communicate.

To set the security ID, choose the Configuration button from the Windows tool and the Set Security ID button from within the Test/Utilities button in the RL2SETUP.EXE program.

To change the security ID to the default settings, leave the Security ID field blank and select OK.

Lucent Configuration Settings

Link Support Layer

Mempool 4096 : required for Novell LSL and TCP/IP

Buffers 8 1500 : required to avoid "Network jammed" message

```
Link Support
   MEMPOOL 4096
   BUFFERS 8 1500
```


TCPIP Protocol

Substitute the appropriate IP addresses in order for your network to function properly.

```
Protocol TCPIP
   IP_Address XXX.XXX.XXX.XXX
   IP_Router XXX.XXX.XXX.XXX
   IP_Netmask XXX.XXX.XXX.XXX
```

Install Lucent WaveLAN II Drivers

Change the Lucent (LXE's System 6500) default radio parameters by editing the NET.CFG file in the PCTCP directory. This can be done with any ASCII text editor. The NET.CFG file is the configuration file used by the radio card's ODI driver. The NET.CFG file determines the wireless network name, the workstation name and other information regarding the wireless system.

LXE's terminal emulation (TE) programs also allow you to change System 6500 radio parameters using the TE Configuration Utility. Please refer to the specific terminal emulation reference guide for instruction.

NET.CFG File and Parameters

Note: Alphabetic parameter values must be in uppercase.

An **example** NET.CFG file:

```
Link Driver WVLAN43
    FRAME ETHERNET_II
    WaveLAN_Network_Name ANY
    Station_Name station_name
    AP_Density  3
    Transmit_Rate   3
    PortType  1
    Medium_Reservation  2347
    Card_Power_Management = N
    Maximum_Sleep_Duration = 100
    Receive_All_Multicasts = Y
```

The following is a list of parameters that can be modified in the NET.CFG file. For additional information about the parameters in this file see the WVLAN43.CFG file located in the PCTCP directory.

WaveLAN_Network_Name

Identifies the WaveLAN network the station will connect to.

Valid values: 0 to 32 string of printable uppercase characters.

Default: ANY

Note: Setting this value to ANY will enable the station to connect to any IEEE 802.11 network.

Note: The string for WaveLAN_Network_Name is case-sensitive. The Lucent DOS ODI driver requires the use of only UPPERCASE characters. If you have configured the Lucent Access Points with lower-case names you will need to change your Lucent Access Point WaveLAN_Network_Name parameter to UPPERCASE characters for proper operation.

Station_Name

Identifies the stations on the network. This parameter is used when performing diagnostic tests.

Valid values: 0 to 32 string of printable characters.

Default: station_name

AP_Density

Controls the roaming sensitivity of your computer. This parameter must be set according to the settings of the Lucent access points.

Valid values: 1=Low
2=Medium
3=High

Default: 3

Transmit_Rate

Controls the data rate the Lucent card will use. Supported rates depend on the card. If the card does not support the selected rate, the default value of 3 is selected automatically.

Valid values: 1=Fixed Low
2=Fixed Standard
3=Auto Rate Select (High)
4=Fixed Medium
5=Fixed High
6=Auto Rate Select (Standard)
7=Auto Rate Select (Medium)

Default: 3

PortType

Defines the connection control characteristics.

Valid values: 1=Infrastructure mode (ESS) 'normal' network operation in environments that include Lucent access points
3=AdHoc Demo mode

Default: 1

Medium_Reservation

Enables RTS/CTS communications. Sets the frame length threshold that determines when the station should start using RTS/CTS.

Valid values: 0-2347

Default: 2347

Note: The use of Medium Reservation is recommended in network environments where the density of the Lucent stations and Lucent access points is very low, and where there is poor network performance due to excessive frame collisions at the Lucent access points.

Card_Power_Management

Configures whether the Lucent radio card will perform power management.

Valid values: Y=Yes or N=No
Default: N

Maximum_Sleep_Duration

Configures the maximum amount of time the radio will stay in Sleep mode.

Valid values: 1-65535
Default: 100 (10 seconds)

Receive_All_Multicasts

Configures whether this station will receive Multicast packets.

Valid values: Y=Yes or N=No
Default: Y

RF Throughput, Performance and Troubleshooting

Because of the complicated nature of wireless LAN technology, problems occasionally arise. This section provides general information about performance and addresses some problems that might arise during setup or use of a wireless network with RF units. This should be your first resource in case of trouble.

Power Management at the Proxim RangeLAN2 Access Point

Proper setup of the access point (AP) is essential to RF power management. Even with the MX2 set up for maximum power savings, the batteries can become drained quickly if the AP is not configured properly.

MU Access Control

For environments in which multiple RF networks overlap, you can use an authorization table to prevent RangeLAN2 APs from accessing RF cards on other networks. This list contains media access control (MAC) addresses of mobile units that are allowed to associate with the AP.

See the AP user's guide for more information about MAC addresses and for information about the authorization table.

Message Filtering

Network packets include a protocol type (IPX, IP, ARP broadcast, NetBIOS, etc.) in the header field. By filtering out unwanted protocol messages, you can prevent the AP from sending these packets to the MX2. This will reduce the amount of times the radio cards have to wake up out of doze mode to service incoming packets.

It can be especially important to filter out broadcast messages. These types of packets, which are generically addressed to all computers on a system, may force the MX2 to operate continuously in full receive mode, even when the data is not relevant to the MX2. If the MX2 does not turn off automatically after the preset timeout, it is an indication that the radio card is receiving broadcast messages and is unable to go to sleep.

The Proxim AP user interface for filtering packets allows you to select the type of packets that will be filtered by selecting from a list of

possible types. The best method with the Proxim RangeLAN2 access point is to turn on filtering for every packet type that you know you won't use. For example, if the access point is hooked up to a TCP/IP network, you would set TCP/IP to Not Filtering and all other protocols to Filtering. In a NetBEUI environment, turn off the Filter NetBEUI option, and turn filtering on for all the rest of the protocols. ARP Broadcast packets should always be turned off, unless your application requires them, to prevent broadcast messages from waking up the MX2.

Note: For more information on packet filtering, see the RangeLAN2 access point manual or your network administrator.

Site Survey

Many companies have an existing Ethernet or wired LAN infrastructure and want to be able to extend that capability to wireless nodes. This is accomplished by attaching an access point to the wired LAN, allowing the wireless clients to access the network resources.

MX2s, like other 386-compatible DOS computers, can be connected to networks. With RF models, radio signals between the MX2s and the AP replace the wires connecting the nodes to the network.

A site survey is an important part of setting up a wireless network. Contact your LXE representative.

For most office environments, a site survey is not necessary. For large, industrial environments requiring multiple APs, however, you should perform a site survey before installing a RangeLAN2 network system. Run Proxim's RL2SETUP.EXE program on a laptop using a RangeLAN2 card.

The purpose of a site survey is to calculate the most effective number of access points at a site and the best placement and positioning of antennas for optimal reception of radio signals. This is done by identifying areas where transmission failures occur. As each site is unique, the surveyor needs to consider the exact conditions as they will appear in the final installation. In addition to such climate factors as moisture, excessive heat, and dust, a site survey can also be affected by physical obstructions and electromagnetic interference. Also important is the identification of potential cabling, connector, or power problems.

Throughput and Performance

The bandwidth on a radio network is constant for a given network. Therefore, the more active RF units using the same frequency- hopping pattern, the slower the throughput of any one unit. If this is a problem, you should install additional access points.

Radio signals may reflect off some obstacles and be absorbed by others. An RF unit with an unobstructed line of sight to the access point antenna can successfully transmit and receive signals at distances up to 1000 feet. In an environment that includes such obstructions as cubicle walls typically used in modern offices, the range is reduced significantly, with a maximum distance of 500 feet. Where signals must penetrate office walls, the maximum distance may be only 300 feet.

Many other factors also affect performance of wireless LANs, including the following:

- Transmitter power
- Receiver sensitivity
- Interference caused by noise, receiver desensitization, spurious responses, and intermodulation
- Shadowing
- Multipath fading
- Consumer products in use in the coverage area

Some of these factors can be sensed during a site survey and be avoided.

Operational Problems

This section lists solutions to problems that can occur with an RF unit.

The drivers won't load, or the unit locks up when the drivers load.

Be sure the RangeLAN2 PC card is correctly installed in the radio card slot before turning the unit on. Do not remove or insert any PC card while the MX2 is on.

The MX2 seems to lock up for four or five seconds after it is turned on.

Every time a MX2 is turned on, it must initialize the PC card. Wireless LAN PC cards commonly take four or five seconds to initialize. After the card is initialized, the unit should function normally.

The MX2 cannot communicate with a NetWare server.

The MX2 and the server may be using different frame types. Make sure that the frame type in your NET.CFG file matches the server's frame type.

The MX2 cannot communicate with another machine on the network.

The MX2 may not have the same domain and security ID as the other machine.

The MX2 does not shut down properly when I remove the PC card or take out the batteries.

Do not remove a PC card or the batteries while the MX2 is on or immediately after turning it off. When you turn the unit off, it suspends the RF driver, a process that can take one or two seconds. If you remove the PC card or the batteries before the driver is suspended, the unit may be left in an unstable state and may need to be reset.

The MX2 never turns itself off automatically, even when the time-out value is correctly set.

The radio may be receiving broadcast messages from the access point. See "Power Management at the RangeLAN2 Access Point," for information on filtering messages.

Problems with DOS Drivers

Some problems may occur in the DOS environment. Many problems can be caused by inappropriate memory, I/O, or IRQ settings for the MX2. If changing those settings in the NET.CFG or PROTOCOL.INI file doesn't solve the problem, consult the following list of symptoms to identify other possible causes. Contact your systems administrator if you need additional help.

NDIS driver does not install or does not work

- Domain, memory address, I/O address hex values in PROTOCOL.INI file not specified with leading 0x.
- Memory range not reserved
- Incompatible protocol manager and stack
- Improper linking in PROTOCOL.INI file
- Memory, I/O, or IRQ setup conflicts with other installed software or hardware

ODI driver does not install or does not work

- Memory range not reserved
- Incompatible protocol manager and stack
- Improper linking in NET.CFG file
- Memory, I/O, or IRQ setup conflicts with other installed software and hardware

TCP/IP fails

- Incorrect IP/subnet address
- Incorrect domain; check for MU association

Nothing happens after installation of the network software (no login, cannot find server, no TCP connection)

- Incompatible firmware and driver versions
- Memory, I/O, or IRQ setup conflicts with other installed software or hardware
- MU is out of range
- All cards must have matching security IDs to communicate

Slow or erratic performance

- Out of communication range
- Faulty antenna, antenna connector, or cable

Driver does not install, or driver hangs during installation

- Incompatible firmware and driver versions
- Memory range not reserved
- Memory range does not match setting in NET.CFG or PROTOCOL.INI file
- Memory range is too small (use I/O mode if memory is restricted)
- Memory, I/O, or IRQ setup conflicts with other installed software or hardware

Table of Contents

CHAPTER 3 SOFTWARE CONFIGURATION 3-1

Introduction 3-1

BIOS and DOS 3-1

PC Card and RF Networking Software 3-1

Disk Drives and Files 3-2

Drive A 3-3

Drive B 3-5

Drive C 3-8

Root Directory Files 3-8

DOS Directory Files 3-8

PCM Directory Files 3-9

Drive D 3-10

Drive E 3-10

System Configurations 3-11

Default Configuration 3-11

I/O PC Card Support Configuration 3-13

Data Entry 3-14

Keyboard Data Entry 3-14

Barcode Data Entry 3-14

Infrared Port Data Entry 3-14

Terminal Emulation 3-15

DOS TE User Defined Stored Forms 3-16

DOS TE Font Sizes 3-16

Illustrations

Figure 3-1 CONFIG.SYS File on Drive A 3-3
Figure 3-2 AUTOEXEC.BAT File on Drive A 3-4
Figure 3-3 CONFIG.SAF File on Drive A 3-4
Figure 3-4 CONFIG.SYS File on Drive B 3-6
Figure 3-5 AUTOEXEC.BAT File on Drive B 3-7
Figure 3-6 CONFIG.SAF File on Drive B 3-7
Figure 3-7 CONFIG.SYS File on Drive C for Default Configuration 3-11
Figure 3-8 AUTOEXEC.BAT File on Drive C for Default Configuration 3-12
Figure 3-9 CONFIG.SYS File on Drive C for I/O PC Card Support 3-13
Figure 3-10 AUTOEXEC.BAT File on Drive C for I/O Card Support 3-13

Chapter 3
Software Configuration

Introduction

This chapter details the default contents of the disk drives and the organization of system software on the MX2. It also includes descriptions of two standard software configurations.

BIOS and DOS

The MX2 uses a modified version of General Software's BIOS with Datalight's ROM-DOS. Both products are burned into system flash in a single 256K image. The A drive is included in the image, physically addressed just below the BIOS image.

ROM-DOS uses the Datalight command.com processor. This processor is fully Microsoft 6.2 compatible, except that it occupies about half the space in memory. In addition, drive C contains Datalight DOS files in a DOS subdirectory.

PC Card and RF Networking Software

PC card device drivers and utilities as well as RF networking solutions can be installed to drive C (the flash drive) or drive D (the RAM drive). You can use the Configuration Utility to download the necessary files to the MX2.

- Default IRQ for PC card is 7.
- Default PC card COM port is COM 2.

Disk Drives and Files

The MX2 has the following drive structure:

Drive A is a read-only flash drive. The contents of this drive cannot be changed.

Drive B is a read-only flash drive that you can update by using the core-update program, COREXFER.EXE, (loaded on the PC by the Configuration Utility) from a host machine. (Normal operation will not require updating of this drive.)

Drive C is a resident flash disk drive that is accessed with the FLASHDSK.SYS device driver. You can use this drive to store applications and data.

Drive D is a RAM disk accessed with the VDISK.SYS device driver. This drive can be used to store applications as well as data. However, you should take great care in selecting files for this drive. As with any RAM drive, its contents will be lost if power is removed.

Additional drives are mapped to ATA flash PC cards or to network drives via radio frequency (RF).

This organization provides an easy-to-use, extensible system that allows a high degree of performance, usability, and customization. The following sections more fully describe the contents and intended uses of each of the MX2's drives.

Drive A

Drive A is a disk image that is located in flash along with the BIOS and ROM-DOS. A read-only drive, it is intended to remain secure throughout the life of the unit. Drive A contains the following files:

AUTOEXEC.BAT	the first file in the startup sequence
CONFIG.SAF	the first file in the safe-boot sequence
CONFIG.SYS	the first file in the boot sequence
REV.COM	the utility that reports the firmware revision

The CONFIG.SYS and AUTOEXEC.BAT files contain only basic commands that the unit needs to run correctly. Both files chain to their respective counterparts on the B drive, as described in the next section.

The CONFIG.SAF file is used in the safe-boot sequence.

```
REM ************************************
REM Initial CONFIG.SYS file for
REM starting the system.
REM ************************************

NEWFILE = B:\CONFIG.SYS
```

Figure 3-1 CONFIG.SYS File on Drive A

```
@echo off
REM ***************************************
REM Initial AUTOEXEC.BAT file for
REM starting the system.
REM ***************************************
VER
PATH=A:\
B:\AUTOEXEC.BAT
```

Figure 3-2 AUTOEXEC.BAT File on Drive A

```
REM ********************************
REM Initial CONFIG.SYS for safe boot.
REM ********************************
NEWFILE = B:\CONFIG.SAF
```

Figure 3-3 CONFIG.SAF File on Drive A

Drive B

Drive B is a disk image that is located in flash. A read-only drive, it is intended to be used to store mandatory utilities and initialize the boot process. During normal use this drive will not be updated. Drive B has no subdirectories.

See Chapter 6 “Commands” for DOS and ROM-DOS command syntax.

AUTOEXEC.BAT	the second file in the startup sequence.
CFGDEV.SYS	the system-parameter-configuration device driver.
CFGIO.EXE	the utility for loading fonts and keypad layouts.
COMIO.COM	the utility for redirecting input and output to the serial port.
COMMAND.COM	the DOS shell.
CONFIG.SAF	the second file in the safe-boot sequence.
CONFIG.SYS	the second file in the boot sequence.
COREUPD.COM	the utility that updates the firmware image.
DECODE.SYS	the bar-code-decoding device driver.
FLASHDSK.SYS	the resident flash disk device driver.
FORMAT.COM	the disk-reformatting utility.
FUNCTEST.COM	the functional test for system components.
HIMEM.SYS	the device driver for accessing extended memory.
LD.BAT	the batch file for RESPONSE.BAT processing.
LOCK.COM	the utility for locking or unlocking the resident flash disk and RAM disk.

ORGANIZE.COM	the utility for reorganizing flash disk data.
PM.COM	the power-management utility.
REV.COM	the utility that reports the firmware version.
UMBLINK.EXE	the device driver for accessing upper memory blocks.
VDISK.SYS	the RAM-disk device driver.
XFER.EXE	the serial-transfer utility.

The CONFIG.SYS file will load the FLASHDSK.SYS driver to create the C drive and the VDISK.SYS driver to create the D drive. It will then load DECODE.SYS and CFGDEV.SYS before chaining to its counterpart on drive C. The AUTOEXEC.BAT file will chain to its counterpart on drive C, except during a safe boot.

The purpose of the CONFIG.SAF file is to provide a minimal boot configuration that preserves the flash and RAM drives. When the safe-boot sequence is initiated, the CONFIG.SYS file is processed instead of the CONFIG.SYS file. This prevents chaining into the drive-C initialization files by omitting the `NEWFILE = C:\CONFIG.SYS` command. It also eliminates the loading of the DECODE.SYS and CFGDEV.SYS drivers.

```
REM ****************************************
REM Standard CONFIG.SYS for building system.
REM ****************************************

REM ***************************
REM Create flash and RAM drives
REM ***************************
DEVICE = B:\FLASHDSK.SYS 4096
DEVICE = B:=VDISK.SYS 4096 /e

REM ********************************
REM Load decode/configuration drivers
REM ********************************
DEVICE = B:\DECODE.SYS
DEVICE = B:\CFGDEV.SYS
NEWFILE = C:\CONFIG.SYS
```

Figure 3-4 CONFIG.SYS File on Drive B

```
@echo off
REM **********************************
REM Standard AUTOEXEC.BAT for
REM starting system.
REM **********************************
PATH=%PATH%;B:\
C:
IF EXIST A:\CONFIG.SAF
IF EXIST C:\AUTOEXEC.BAT C:\AUTOEXEC.BAT
```

Figure 3-5 AUTOEXEC.BAT File on Drive B

```
REM ********************************
REM Standard CONFIG.SYS for safe boot.
REM ********************************

REM ***************************
REM Recover flash and RAM drives
REM ***************************
DEVICE = B:\FLASHDSK.SYS 4096
DEVICE = B:\VDISK.SYS 4096 /e
```

Figure 3-6 CONFIG.SAF File on Drive B

Drive C

Drive C is a resident flash disk drive that is accessed via the FLASHDSK.SYS device driver. By default, this drive is configured to have full read and write access. The default CONFIG.SYS and AUTOEXEC.BAT files reside here. You can modify these files to customize the system for an application. They will be called after the CONFIG.SYS and AUTOEXEC.BAT files on drives A and B are processed.

The Configuration Utility gives you the ability to customize what software tools and utilities are placed on the unit. By default, the utility installs this software to the C drive. If the unit is intended to be used with PC cards, then the Phoenix PC card drivers are installed in the PCM subdirectory on the C drive, and the proper entries will be transferred into the CONFIG.SYS and AUTOEXEC.BAT files. The exact configuration of files and the contents of the CONFIG.SYS and AUTOEXEC.BAT files will change according to the configuration of the unit.

For RF capability, additional files for network connectivity would be required. These might include a TELNET program or peer-to-peer networking tools, depending on what you choose to install.

If something happens to a unit and data integrity becomes questionable, use the CHKDSK utility to detect and correct errors on drive C. You can also use ORGANIZE.COM (on Drive C in the MX2) to recover unused sectors.

See Chapter 6 “Commands” for DOS and ROM-DOS command syntax.

Root Directory Files

AUTOEXEC.BAT	Called after the AUTOEXEC.BAT files on drives A and B are processed.
CONFIG.SYS	Called after the CONFIG.SYS files on drives A and B are processed.

DOS Directory Files

ATTRIB.COM	Displays or modifies file attributes.
CHKDSK.COM	Examines a disk and determines if the disk has any errors in the File Allocation Table

	(FAT) and will optionally fix errors.
DELTREE.EXE	Deletes a directory and all it's subdirectories.
MORE.COM	Displays 25 lines of output at a time.
XCOPY.COM	Send or receive data using a COM port.

PCM Directory Files

CNFIGNAM.EXE	Specifies which PCM Plus configuration parameters are to be used, based on the selected boot configuration.
PCM.INI	Defines system resource requirements for all boot configurations which contain PCM Plus. When a boot configuration is specified, CNFIGNAM identifies the selection as CONFIG.SYS is loaded and requests the relevant configuration information from the PCM.INI file.
PCMATA.SYS	Device driver enables the system to access ATA-configured PC cards as IDE hard drive devices using an IDE partition table.
PCMCS.EXE	Must be loaded directly after Socket Services. Coordinates access to the PC cards and allocates PC system resources among client drivers.
PCMSS400.EXE	PCM socket services are located in this driver. The purpose of socket services is to provide a layer of software support to the actual PC hardware that controls PC-compatible sockets for PC cards.

Drive D

Drive D is a RAM disk drive. By default, this drive resides in extended memory and is sized 1MB less than the total RAM in the unit.

Drive D can be used for short-term data storage. Programs that need to be loaded into memory and then removed from memory quickly can also be located there. The drive can also be used for scratch disk space or temporary files.

The MX2 preserves the data on drive D between warm or cold boots by checking for an existing RAM disk. However, only minimal checking is performed on any disk that is found. If something happens to a unit and data integrity becomes questionable, you should use the CHKDSK utility to detect and correct errors on drive D.

Drive E

Drive E is the ATA flash card. The PC card looks like a hard disk drive to the operating system and the user. More flexible than flash disk drive C, it can be used for safer and more permanent bulk storage of batch data than the RAM disk (drive D). This drive exists only on systems configured to use ATA flash cards.

Drive E could also be a peer-to-peer or client-server network drive that is accessed through an RF or Ethernet network card link. This option allows the developer to make many network drives (drives E, F, etc.) available to applications.

System Configurations

Several configurations are possible for the system software on the unit, depending upon the type of hardware that is to be supported. Two standard configurations are described below, along with directory structures and default CONFIG.SYS and AUTOEXEC.BAT file descriptions.

Default Configuration

The configuration is created by DEFAULT.CFG in the Configuration Utility. The data files will be stored on drive D. PC card drivers able to support ATA cards will be loaded.

```
FILES = 30

REM --------------------------------
REM  Phoenix Card and Socket
REM  services for accessing PC Cards
REM --------------------------------
device = c:\pcm\cnfignam.exe /NORMAL
device = c:\pcm\pcmssit.exe
device = c:\pcm\pcmcs.exe
device = c:\pcm\pcmata.sys
```

Figure 3-7 CONFIG.SYS File on Drive C for Default Configuration

```
REM ------------------------------------
REM  The following lines set up
REM  default parameters for some
REM  environment variables. These lines
REM  may be modified or overridden in
REM  the USER section below.
REM ------------------------------------
set prompt=$p$g
set dircmd=/ogn /p

REM ------------------------------------
REM  The following section is for
REM  customized user entries.
REM  Insert user-specific options and
REM  commands here.
REM ------------------------------------

REM ------------------------------------
REM  The following lines add system
REM  components to the PATH
REM  and run the main application
REM  executable, if one was specified.
REM ------------------------------------
IF EXIST c:\bparams.ini copy c:\bparams.ini PARAMS
set path=c:\;c:\dos;%path%
```

Figure 3-8 AUTOEXEC.BAT File on Drive C for Default Configuration

I/O PC Card Support Configuration

The Configuration Utility has an option for support of I/O cards. This option will download the Phoenix Super Client Driver (PCMSCD.EXE) to the C:\PCM subdirectory on the MX2. It will also add the command for loading of this driver to the CONFIG.SYS file. The CONFIG.SYS and AUTOEXEC.BAT files below were created by eliminating ATA card support and adding I/O card support to DEFAULT.CFG.

```
FILES = 30
REM ------------------------------------
REM  Phoenix Card and Socket services
REM  for accessing PC Cards
REM ------------------------------------
device = c:\pcm\cnfignam.exe /NORMAL
device = c:\pcm\pcmssit.exe
device = c:\pcm\pcmcs.exe
device = c:\pcm\pcmscd.exe
```

Figure 3-9 CONFIG.SYS File on Drive C for I/O PC Card Support

```
REM ------------------------------------
REM  The following lines set up default
REM  parameters for some environment
REM  variables. These lines may be
REM  modified or overridden in the USER
REM  section below.
REM ------------------------------------
set prompt=$p$g
set dircmd=/ogn /p
REM ------------------------------------
REM  The following section is for
REM  customized user entries.
REM  Insert user-specific options and
REM  commands here.
REM ------------------------------------
REM  The following lines add system
REM  components to the PATH and runs the
REM  main application executable, if one
REM  was specified.
REM ------------------------------------
IF EXIST c:\bparams.ini copy c:\bparams.ini PARAMS
set path=c:\;c:\dos;%path%
```

Figure 3-10 AUTOEXEC.BAT File on Drive C for I/O Card Support

Data Entry

Note: The MX2 will not run Microsoft Windows products i.e. Windows 3.1, Windows For Workgroups, Windows 95, Windows NT, etcetera.

The LXE MX2 computer accepts data entry from the keyboard, barcode scanner and the Infrared input port when an LXE Terminal Emulation (TE) program is running and on batch (non-TE) units.

Keyboard Data Entry

Once the terminal emulation program is started, data can be entered with the MX2 keypad. Keyed data can be entered into a data field and transmitted to the host. You might respond to a prompt sent by the host application with a keypad entry, such as a menu listing choices for your next action.

Barcode Data Entry

The MX2 supports data entry using the barcode scanner at the top of the unit. Keyboard data entries can be mixed with barcode data entries.

Infrared Port Data Entry

The MX2 accepts input from the IR port. The MX2 processes data from the IR port the same way it processes keyed data. The data is entered at the cursor position, and the data is subject to all of the barcode/RS-232 input menu parameters, such as truncate.

Terminal Emulation

Note: Narrowband and spread spectrum 900MHz radios are not supported at this time. For details concerning future capabilities, contact the LXE Product Marketing department.

All terminal emulation radio controlled data flows and exchanges are over the radio to the 64XX or 65XX units, then to the computer network and then to a host computer. The LXE Network Management System, as part of the wired network, can remotely configure the MX2's terminal emulation parameters.

Note: MX2's with 64XX series 2.4GHz spread spectrum radios communicate only with 64XX Access Points with installed 64XX 2.4GHz radios.

Note: MX2's with 65XX series 2.4GHz spread spectrum radios communicate only with 65XX Access Points with installed 65XX 2.4GHz radios.

Please refer to the system specific terminal emulation reference guide for instruction when using a MX2 in a specific TE environment. A list of LXE reference guides is located at the end of Chapter 1 "Introduction and Specifications" in the section titled "Manuals."

LXE's terminal emulation programs that are compatible with the MX2 computer are:

ANSI Plus

Running on a MX2 with a 2.4GHz radio. ANSI Plus uses a Telnet connection to communicate with the host computer. A MX2 with a 2.4GHz radio is interfaced to a computer network (Ethernet or Token-Ring) via 2.4GHz radio equipped 64XX or 65XX Access Points. ANSI Plus does not support Narrowband RF.

TN3270 TE and TN5250 TE

Runs on a MX2 with a 64XX or 65XX series 2.4GHz radio. The TE provides IBM host application support over the RF backbone and TCP/IP network. This product does not provide interconnectivity for LXE's narrowband and 900MHz RF backbones.

DOS TE User Defined Stored Forms

DOS terminal emulations have the following space requirements for user defined stored forms:

ANSI Plus	2K required for each form
TN3270	1K required for each form
TN5250	1K required for each form

DOS TE Font Sizes

MX2 screen sizes supported by LXE terminal emulation software are:

- 9 rows by 20 columns
- 16 rows by 20 columns

Table of Contents

CHAPTER 4 THE CONFIGURATION UTILITY 4-1

Introduction 4-1

Installing and Starting the Utility on a PC 4-1

BIOS Upgrade File Location 4-2

RF Files Location 4-2

Proxim 4-2

Lucent 4-4

Quick Start 4-5

The Main Menu 4-7

Default 4-9

The Custom Configuration Menu 4-10

The File Configuration Windows 4-15

First File Configuration Window 4-15

Configuration File 4-15

Save 4-16

Browse 4-16

Main Application 4-16

Application Files 4-16

Add 4-16

Edit 4-18

Delete 4-18

Next 4-18

Done 4-18

Second File Configuration Window 4-19

Configuration File 4-19

ATA Memory Cards 4-19

I/O Cards 4-19

Vendor Specific 4-20

DOS Files 4-20

Save 4-20

Browse 4-20

More 4-21

Prev 4-22

Next 4-22
Done 4-22
Third File Configuration Window 4-23
Configuration File 4-23
Save 4-23
Browse 4-23
autoexec.bat 4-24
config.sys 4-24
Text File 4-24
Prev 4-24
Done 4-24
The Program Settings Windows 4-25
Program Settings File 4-25
Save 4-25
Browse 4-25
Prev 4-26
Next 4-26
Done 4-26
First Program Settings Window (Default.PRS) 4-27
Second Program Settings Window (Default.PRS) 4-28
Third Program Settings Window (Default.PRS) 4-29
Fourth Program Settings Window (Default.PRS) 4-30
Fifth Program Settings Window (Default.PRS) 4-31
Last Program Settings Window (Default.PRS) 4-32
The Comm Settings Dialog Box 4-33
Comm Port 4-33
Baud Rate 4-33
The File Transfer Window 4-34
List File 4-34
Save 4-35
Browse 4-35
Files to Transfer 4-36
Add 4-36
Browse 4-37
Edit 4-37
Delete 4-37
Receive 4-38
Send 4-39
Done 4-39

Illustrations

Figure 4-1 Configuration Utility Main Menu 4-7
Figure 4-2 Example - The Important Dialog Box 4-9
Figure 4-3 Example - The Open Dialog Box for Selecting a Configuration File 4-10
Figure 4-4 Example - The Open Dialog Box for Selecting a Program Settings File 4-11
Figure 4-5 Example - The Custom Configuration Menu 4-12
Figure 4-6 The Prompt for Saving Changes to the Current File Configuration 4-13
Figure 4-7 The Prompt for Saving Changes to the Current Program Settings 4-14
Figure 4-8 Example - The First File Configuration Window 4-15
Figure 4-9 The File Selection Dialog Box for Adding an Application File 4-16
Figure 4-10 The Edit File Properties Dialog Box for an Application File 4-18
Figure 4-11 Example - The Second File Configuration Window 4-19
Figure 4-12 Example - The Select DOS Files Dialog Box 4-21
Figure 4-13 Example - The Third File Configuration Window 4-23
Figure 4-14 Example - The First Program Settings Window 4-27
Figure 4-15 Example - The Second Program Settings Window 4-28
Figure 4-16 Example - The Third Program Settings Window 4-29
Figure 4-17 Example - The Fourth Program Settings Window 4-30
Figure 4-18 Example - The Fifth Program Settings Window 4-31
Figure 4-19 Example - The Last Program Settings Window 4-32
Figure 4-20 The Comm Settings Dialog Box 4-33
Figure 4-21 The File Transfer Window 4-34
Figure 4-22 The Prompt for Saving Changes to the Current File List 4-35
Figure 4-23 The File Selection Dialog Box for Adding a Data File 4-36
Figure 4-24 The Edit File Properties Dialog Box for Editing a Data File 4-37
Figure 4-25 Example - PC Receiving Files from MX2 4-38
Figure 4-26 Example - PC Sending Files to MX2 4-39

Chapter 4
The Configuration Utility

Introduction

The Configuration Utility provides a simple way to change the MX2's settings for barcode symbologies and serial communications. You can also use it to load programs and files into the MX2 or copy files from the MX2 to the PC.

The utility runs on a PC under Windows 3.1x, Windows 95, and Windows NT. This chapter describes how to install the utility and use it to configure the MX2.

Installing and Starting the Utility on a PC

To install the configuration utility, insert the Configuration Utility diskette in the PC's floppy drive (usually Drive A). Then complete the following steps:

1. In Windows, run the SETUP.EXE file from the disk in Drive A.
2. In the "Installation Options" window, select the radio components you'd like to install, if any. Select Next to move on.
3. In the "RF Installation Options" window, uncheck the check boxes for any components you do not want to install. Then select Next to move on.
4. In the "Select a Group Name" window, select a program group in which to place the Configuration Utility icons. Select Next to move on.
5. In the next window, specify the directory in which to place the Configuration Utility files. Select Next to move on.
6. When the installation is completed, select Finish in the final window.

To start the Configuration Utility, double-click on it's icon in the program group.

The first screen that appears is the Main Menu.

BIOS Upgrade File Location

The LXE MX2 Configuration Utility diskettes include a utility to upgrade the system software on the MX2. This software, along with instructions in a README.TXT file, is installed to C:\LXE\MX2\16LINE\COREUPD subdirectory on the user's PC during configuration utility installation.

RF Files Location

The RF software is installed to the \LXE\MX2 subdirectory by default. If your software was installed to a different directory, substitute that directory in the text that follows. If all network options were selected during installation, the following files will be on your PC.

Proxim

\LXE\MX2\RF\PROXIM

RL2PCM.DOS	RangeLAN2 NDIS driver
RL2PCM.COM	RangeLAN2 ODI driver

\LXE\MX2\16LINE\RF\PROXIM

NET.CFG	ODI configuration sample NET.CFG for LXE MX2
PROTOCOL.1	Netbeui configuration sample PROTOCOL.INI for LXE MX2
PROTOCOL.2	NDIS to packet driver sample PROTOCOL.INI for LXE MX2

\LXE\MX2\RF\NETWORK

DIS_PKT.ASM	NDIS packet driver shim source code
DIS_PKT.DOS	NDIS packet driver shim

IPXODI.COM	IPX/SPX protocol driver
LSL.COM	Link Support Layer
ODIPKT.ASM	ODI packet driver shim source code
ODIPKT.COM	ODI packet driver shim
TCPIP.EXE	TCP/IP protocol driver

\LXE\MX2\RF\NETWORK\NWCLIENT

NETSTART.BAT	Batch file to execute VLM
VLM.EXE	Virtual Loadable Module Manager (VLM)
*.VLM	Virtual loadable modules.

\LXE\MX2\PROGRAM\CONFIGS

These are configuration files used by the Configuration Utility to control the downloading of files to the portable.

PX_TCPIP.CFG	RangeLAN2 TCP/IP configuration
PX_VLM.CFG	RangeLAN2 VLM configuration
PX_IPX.CFG	RangeLAN2 IPX/SPX configuration
PX_NBEUI.CFG	RangeLAN2 Netbeui sample configuration
PX_PKDRV.CFG	RangeLAN2 packet driver sample configuration

Note: A Netbeui configuration sample is included in the installation. However, LXE MX2 RF does not include Netbeui drivers. These drivers must be acquired from Microsoft.

Lucent

The RF software is installed to the \LXE\MX2 subdirectory by default. If your software was installed to a different directory, substitute that directory in the text that follows. If all network options were selected during installation, the following files will be on your PC.

\LXE\MX2\RF\LUCENT

WVLANCAD.SYS	WaveLAN card access driver
WVLAN42.COM	WaveLAN packet driver
WVLAN43.COM	WaveLAN ODI driver

\LXE\MX2\16LINE\RF\LUCENT

NET.CFG	ODI configuration sample NET.CFG for LXE MX2

\LXE\MX2\RF\NETWORK

IPXODI.COM	IPX/SPX protocol driver
LSL.COM	Link Support Layer
ODIPKT.ASM	ODI packet driver shim source code
ODIPKT.COM	ODI packet driver shim
TCPIP.EXE	TCP/IP protocol driver

\LXE\MX2\RF\NETWORK\NWCLIENT

NETSTART.BAT	Batch file to execute VLM
VLM.EXE	Virtual Loadable Module Manager (VLM)
*.VLM	Virtual loadable modules.

\LXE\MX2\PROGRAM\CONFIGS

These are configuration files used by the Configuration Utility to control the downloading of files to the portable.

LU_TCPIP.CFG	WaveLan TCP/IP configuration
LU_VLM.CFG	WaveLan VLM configuration
LU_IPX.CFG	WaveLan IPX/SPX configuration

Quick Start

Note: Activity specific Help is available when the Help button is present on the configuration utility screen.

The following instructions are based on the following assumptions:

- The Configuration Utility is installed on a PC,
- the MX2 is in a powered dock,
- the appropriate cable is connecting the dock and the PC, and
- the Comm settings in the PC and the MX2 match.

Transfer file(s) from the PC to the MX2 or from the MX2 to the PC

1. Main Menu | Transfer Files | Add |
2. Enter path and filename on PC or select Browse to browse the files on the PC *only*.
3. Enter path and filename on MX2. Select OK to continue.
4. When file list is complete:
   - To send files to the MX2, click Send. Save file list if needed.
   - To send files to the PC, click Receive. Save file list if needed.
5. Click OK on Important Dialog Box.
6. Click Done to return to Main Menu.

Set up MX2 parameters

1. Main Menu | Custom |
2. Select Configuration File. Select OK to continue.
3. Select Program Settings File. Select OK to continue.
4. Select Program Settings.
5. Make changes in 1st through 5th Program Settings Windows. Select Next to continue from one to the next.
6. Make changes in the last Program Settings Window. Select Done to return to Custom Configuration screen.
7. Select Download. Save Configuration File and Program Settings file with a new name, if needed.
8. Select Send. Save file list if needed.
9. Click OK on Important Dialog Box.
10. Click Done to return to Main Menu.

Create a custom file configuration file

1. Main Menu | Custom |
2. Select Configuration File. Click the "Open as read-only" box – a checkmark should appear. Select OK to continue.
3. Select Program Settings File. Click the "Open as read-only" box – a checkmark should appear. Select OK to continue.
4. Click the "Program Settings Using" box – the checkmark should disappear.
5. Select File Configuration.
6. Change Main Application, if needed.
7. Add, edit or delete Main Application files, if needed.
8. Select Next to continue to 2nd File Configuration Window.
9. Select / deselect types of files.
10. Select More to add or remove DOS files from the filelist. Select Done to return to the 2nd File Configuration Window.
11. Select Next to continue to 3rd File Configuration Window. Make changes to BAT or TXT files if needed.
12. Select Done to return to the File Configuration Screen.
13. Select Done to return to the Custom Configuration Menu.
14. Save changes to current file configuration, changing name of file if needed.

The Main Menu

Note: The figures in this chapter reflect the screen displays for the DEFAULT.CFG and DEFAULT.PRS files. Each configuration file (CFG) requires a companion program settings file (PRS).

Note: Based upon your PC and MX2 directory contents, your screens may not look exactly like the screens displayed in this section, but the functions are the same as described.

This menu gives you access to all the configuration settings for the MX2.



Figure 4-1 Configuration Utility Main Menu

Default

Select this option to load the original factory configuration into your MX2.

Custom

Select this option to choose or modify configuration files or program files to be loaded into your MX2. See the section titled “The Custom Configuration Menu” for information on using the Custom Configuration menu.

Comm Settings

Select this option to modify settings for your computer’s serial port. See the section titled “Comm Settings” for information.

Transfer Files

Select this option to transfer data files between the MX2 and the host computer. See the section titled “Transfer Files” for information.

Default

Select this option to load the original factory configuration into your MX2. The configuration utility prepares files to be transferred to the MX2 and opens a dialog box titled “Important.” Check the file lists in both sections of the dialog box to see if they are correct and complete. If you need to add, delete, or rename files, select from the dialog box. Then use the selection in the main menu to build your own lists.



Figure 4-2 Example - The Important Dialog Box

If the file lists in the dialog box are correct, make sure your MX2 is properly connected to the serial port specified in the Comm Settings dialog box (default is COM 1 at 9600 baud). Then run the **`LD.BAT`** file on the MX2, and select OK in the “Important” dialog box on the computer.

The Custom Configuration Menu

When you select **Custom** from the main menu, an Open dialog box appears. Use this dialog box to select a configuration file from the Configs folder. The configuration file contains the information that will be presented when you select the File Configuration button on the Custom Configuration menu.

Select a configuration file and click Open.



Figure 4-3 Example - The Open Dialog Box for Selecting a Configuration File

*Note: If you select **Open as read-only** and make changes to the configuration settings, you will need to use a new name for the file to save the changes.*

When the configuration file is finished loading, a second Open dialog box appears.



Figure 4-4 Example - The Open Dialog Box for Selecting a Program Settings File

*Note: If you select **Open as read-only** and make changes to the program or parameter settings, you will need to use a new name for the file to save the changes.*

Use this dialog box to select a program-settings file from the Progsets folder. The program-settings file contains the information that will be presented when you select the Program Settings button on the Custom Configuration menu.

Select a program settings file and click Open.

After the program-settings file is loaded, the Custom Configuration menu appears.

If you do **not** want to load any files, click the checked box to remove the checkmark. Upon selecting Download, a message appears stating there were no files selected.



Figure 4-5 Example - The Custom Configuration Menu

File Configuration	Select this option to choose application files to be loaded into the MX2. See section titled “File Configuration Windows” for information.
Configure Files Using	This field shows the configuration file that will be used to specify the files that will be loaded into the MX2. If you do not want to load any files, check the box to remove the checkmark and turn the switch off.
Program Settings	Select this option to view or change settings for barcode symbologies and other programmable MX2 options. See section titled “The Program Settings Windows” for information.

Program Settings Using	This field shows the program-settings file that will be used. If you do not want to load any program settings, turn the switch off.
Comm Settings	Select this option to view or change serial communications settings for the MX2. See section titled “The Comm Settings Dialog Box” for information.
Download	When you finish customizing the MX2 configuration, select this option to load the custom configuration into your MX2. When you select it, the configuration utility prepares files to be transferred to the MX2 and opens the Important dialog box. Make sure your MX2 unit is properly connected to the serial port specified in the Comm Settings dialog box. Then run the **LD.BAT** file on the MX2, and select **OK** in the Important dialog box on the computer.
Done	Select this option to return to the main menu. After selecting Done and if you made any changes to the file configuration or program settings, one or both of the following prompts appear:



Figure 4-6 The Prompt for Saving Changes to the Current File Configuration



Figure 4-7 The Prompt for Saving Changes to the Current Program Settings

Yes	Select this option to save the changes. A Save As dialog box will open. Use the dialog box to specify the location and name of the new configuration or program-settings file.
No	Select this option to discard the changes.
Cancel	Select this option to return to the Custom Configuration menu without saving or discarding the changes.

The File Configuration Windows

When you select **File Configuration** from the Custom Configuration Menu, the first of three File Configuration windows appears. Use these windows to choose application files to be loaded into the MX2.

First File Configuration Window



Figure 4-8 Example - The First File Configuration Window

Configuration File

This field shows the configuration file used to specify the files that will be loaded into the MX2.

Save

After adding, editing, or deleting files in the Application Files list, select Save to save the revised list in the current configuration file or in a new one.

Browse

Select Browse to use a different configuration file. An Open dialog box will appear. Use the dialog box to choose a configuration file from the Configs folder. (If you select Browse after making changes in this or any other File Configuration window without saving the changes, the prompt for saving changes to the current file configuration will appear.)

Main Application

This field identifies the default application that will run on the MX2 after you complete the installation.

Application Files

This field lists the files associated with the main application.

Add

Select this option to include other files to be installed on your MX2. The File Selection dialog box opens.



Figure 4-9 The File Selection Dialog Box for Adding an Application File

Note: The files are added one at a time. Wildcards are not allowed. The path a filename must be entered for each file for both the PC and the portable. All targeted subdirectories must already exist on the PC and the portable.

File Selection

Enter path and filename on host PC

Use this field to specify the file you want to transfer to the MX2.

Enter path and filename on portable

Use this field to specify the location and name you want the transferred file to have on the MX2. The name can be the same as the original file or you can give the file a new name.

Main Application

Turn this switch on if you want the specified file to be the main application on the MX2.

Note: Only one file can be selected as the main application for a MX2. To select another file as the main application, you must first highlight the current one in the Application Files list in the File Configuration window, select Edit, and turn off the Main Application switch for that file.

OK

Select OK to return to the File Configuration window. The specified source file will appear in the Application Files list.

Cancel

Select Cancel to return to the File Configuration window without adding a file to the Application Files list.

Browse

Select Browse to view the files on your computer. An Open dialog box will appear. Use the dialog box to choose a source file to be included in the Custom configuration.

Edit

Select a file in the Application Files list and then select **Edit** to change the source path or destination path for the file. The Edit File Properties dialog box opens.

For information on using this dialog box, see "Add."



Figure 4-10 The Edit File Properties Dialog Box for an Application File

Delete

To delete a file from the Application Files list, select the file in the list and then select **Delete**.

Next

Select **Next** to view or change additional file-configuration options for the custom installation.

The second File Configuration window appears if you select **Next** in the first window.

Done

Select **Done** if you are finished setting file-configuration options for the custom installation at the First File Configuration Window.

Second File Configuration Window

The second File Configuration window appears if you select **Next** in the first window.


File Configuration
Configuration File:
default.CFG
Save
Browse...
Select the types of files that you wish to install from the list below. Multiple selections may be made.
ATA Memory Cards - Include files to operate ATA PC Cards.
I/O Cards - Include files to operate fax/modem PC Cards.
Vendor Specific - Include files for card and socket services only. Choose this for other types of cards.
DOS Files - Include DOS support files such as ATTRIB.COM
More>>
Help
<<Prev
Next>>
Done

Figure 4-11 Example - The Second File Configuration Window

Configuration File

This field shows the configuration file used to specify the files that will be loaded into the MX2.

ATA Memory Cards

Turn this switch on to transfer drivers for ATA memory cards to the MX2.

I/O Cards

Turn this switch on to transfer drivers for fax/modem cards to the MX2.

Vendor Specific

Turn this switch on to transfer drivers for other types of PC cards.

DOS Files

Turn this switch on to transfer files for DOS commands and utilities to the MX2. Select “More” to add or remove DOS files from the custom installation.

Save

After changing selections in this window, select Save to save the revisions in the current configuration file or in a new one.

Browse

Select Browse to use a different configuration file. An Open dialog box will appear. Use the dialog box to choose a configuration file from the Configs folder. (If you select Browse after making changes in this or any other File Configuration window without saving the changes, the prompt for saving changes to the current file configuration will appear.)

More

Select More to add or remove DOS files from the custom installation. The Select DOS Files dialog box appears.



Figure 4-12 Example - The Select DOS Files Dialog Box

More

Highlight DOS files to download to portable

This field lists DOS files that are available. Files that are highlighted are currently selected to be included in the custom installation. Click on a file to select it or deselect it.

Directory on portable to store DOS files

Use this field to specify where the DOS files should be placed in the MX2.

Done

Select Done to return to the File Configuration window.

Prev

Select Prev to return to the previous file-configuration window.

Next

Select Next to move on to the next file-configuration window. The third File Configuration window appears if you select Next in the second window.

Done

Select Done if you are finished setting file-configuration options for the custom installation.

Third File Configuration Window

The third File Configuration window appears if you select **Next** in the Second File Configuration Window.



Figure 4-13 Example - The Third File Configuration Window

Configuration File

This field shows the configuration file used to specify the files that will be loaded into the MX2.

Save

After selecting options in this window, select **Save** to save the revisions in the current configuration file or in a new one.

Browse

Select **Browse** to use a different configuration file. An Open dialog box will appear. Use the dialog box to choose a configuration file from the Configs folder. (If you select Browse after making changes in this or any

other File Configuration window without saving the changes, the prompt for saving changes to the current file configuration will appear.)

autoexec.bat

Select this option to insert new commands into the AUTOEXEC.BAT file that will be transferred to the MX2.

config.sys

Select this option to insert new commands into the CONFIG.SYS file that will be transferred to the MX2.

Text File

Select this option to view or modify any text file that will be transferred to the MX2.

Prev

Select **Prev** to return to the previous file-configuration window.

Done

Select **Done** if you are finished setting file-configuration options for the custom installation.

The Program Settings Windows

When you select **Program Settings** from the Custom Configuration Menu, the first of five Program Settings windows appears. Use these windows to view or change settings for barcode symbologies and other programmable options.

The Program Settings Windows (1 through 5) may or may not have:

On/Off Switches	The smallest white boxes are on/off switches. Click in the box to toggle a switch. When a checkmark appears in the box, the switch is ON.
Input Fields	Input fields do not usually have a drop down arrow to the right. Place the cursor in the input field to enter specific settings for parameters in the larger white boxes. (See appendix B for a table of parameters and settings.)
Drop-Down Lists	Click on the drop down arrow to the right of the list to view the options, and click on the option you want to select. This field cannot be edited.
Radio Buttons	Radio buttons allow you to select one value for a parameters. Select the setting you want by clicking on it. The parameter value is selected when the radio button is filled in.

Program Settings File

This field shows the program-settings file that will be loaded into the MX2.

Save

After selecting options in this window, select Save to save the revisions in the current program-settings file or in a new one.

Browse

Select Browse to use a different program-settings file. An Open dialog box will appear. Use the dialog box to choose a program-settings file from the Progsets folder. (If you select Browse after making changes in this or any other File Configuration window without saving the changes,

the prompt for saving changes to the current program settings will appear.)

Prev

Select Prev to return to the previous program-settings window.

Next

Select Next to move on to the next program-settings window. The last Program Settings window appears if you select Next in the fourth window.

Done

Select Done if you are finished making program settings for the custom installation.

First Program Settings Window (Default.PRS)



Figure 4-14 Example - The First Program Settings Window

Upon clicking Done, you are returned to the Custom Configuration screen. Select Done to return to the Main Menu.

Second Program Settings Window (Default.PRS)



Figure 4-15 Example - The Second Program Settings Window

Select **Prev** to return to the first window, **Next** to continue to the third window and **Done** if you are finished making program settings for the custom installation.

Upon clicking Done, you are returned to the Custom Configuration screen. Select Done to return to the Main Menu.

Third Program Settings Window (Default.PRS)



Figure 4-16 Example - The Third Program Settings Window

Select **Prev** to return to the second window, **Next** to continue to the fourth window and **Done** if you are finished making program settings for the custom installation.

Upon clicking Done, you are returned to the Custom Configuration screen. Select Done to return to the Main Menu.

Fourth Program Settings Window (Default.PRS)



Figure 4-17 Example - The Fourth Program Settings Window

Select **Prev** to return to the third window, **Next** to continue to the fifth and last window and **Done** if you are finished making program settings for the custom installation.

Upon clicking Done, you are returned to the Custom Configuration screen. Select Done to return to the Main Menu.

Fifth Program Settings Window (Default.PRS)



Figure 4-18 Example - The Fifth Program Settings Window

Select **Prev** to return to the fourth window, **Next** to continue to the sixth and last window and **Done** if you are finished making program settings for the custom installation.

Upon clicking Done, you are returned to the Custom Configuration screen. Select Done to return to the Main Menu.

Last Program Settings Window (Default.PRS)



Figure 4-19 Example - The Last Program Settings Window

Select **Prev** to return to the fifth window and **Done** if you are finished making program settings for the custom installation.

Upon clicking Done, you are returned to the Custom Configuration screen. Select Done to return to the Main Menu.

The Comm Settings Dialog Box

When you select **Comm Settings** from the main menu or the Custom Configuration menu, the Comm Settings dialog box appears. Use this dialog box to view or change settings for serial communications from the PC to the MX2.



Figure 4-20 The Comm Settings Dialog Box

Radio Buttons	Radio buttons allow you to select one value for a parameter. Select the setting you want by clicking on it. The parameter value is selected when the radio button is filled in.
Drop-Down Lists	Click on the drop down arrow to the right of the list to view the options, and click on the option you want to select. This field cannot be edited.

Comm Port

Select the serial port that your PC will use to communicate with the MX2. The default port is COM1.

Baud Rate

Select the baud rate for serial communications between your PC and the MX2. The default baud rate is 9600.

The File Transfer Window

When you select **Transfer Files** from the main menu, the File Transfer window appears. Use this window to select data files for transfer between the MX2 and your computer.



Figure 4-21 The File Transfer Window

List File

This field shows the name of the file-list file, if you have one selected.

Note: You can select files to transfer without using or creating a list file.

Save

After making changes in the Files to Transfer list, you can select Save to save the revisions in the current file-list file (if any), in another existing file, or in a new file.

Browse

Select Browse to use a different file-list file. An Open dialog box will appear. Use the dialog box to choose a file-list file from the Filelist folder. If you select Browse after making changes in the File Transfer window without saving the changes, the following prompt will appear:



Figure 4-22 The Prompt for Saving Changes to the Current File List

Browse and Save Changes

Yes
Select this option to save the changes. A Save As dialog box will open. Use the dialog box to specify the location and name of the new file-list file.

No
Select this option to discard the changes.

Cancel
Select this option to return to the File Transfer window without saving or discarding the changes.

Files to Transfer

This field shows the files that will be included in the transfer between the MX2 and the PC.

Add

Select Add to include additional data files in the transfer. The File Selection dialog box opens.



Figure 4-23 The File Selection Dialog Box for Adding a Data File

Enter path and filename on host PC

Use this field to specify the location of the file on the PC.

Enter path and filename on portable

Use this field to specify the location and name you want the transferred file to have on the MX2.

OK

Select OK to return to the File Transfer window. The specified data file will appear in the Files to Transfer list.

Cancel

Select Cancel to return to the File Transfer window without adding a file to the Files to Transfer list.

Browse

Select Browse to view the files on your computer. An Open dialog box will appear. Use the dialog box to choose a data file to be included in the transfer.

Edit

Select a file in the file list and then select Edit to change the source path or destination path for the file. The Edit File Properties dialog box opens. The fields and buttons in this dialog box are the same as in the File Selection dialog box above.



Figure 4-24 The Edit File Properties Dialog Box for Editing a Data File

Delete

To delete a file from the list, select the file and then select Delete.

Receive

Select Receive to begin a file transfer from the MX2 to the PC.



Figure 4-25 Example - PC Receiving Files from MX2

When you select it, the configuration utility prepares files to be transferred to the PC and opens the Important dialog box. Make sure your MX2 unit is properly connected to the serial port specified in the Comm Settings dialog box. Then run the LD.BAT file on the MX2, and select OK in the Important dialog box on the PC.

Send

Select Send to begin a file transfer from the PC to the MX2.



Figure 4-26 Example - PC Sending Files to MX2

The configuration utility prepares files to be transferred to the MX2 and opens the Important dialog box. Make sure your MX2 unit is properly connected to the serial port specified in the Comm Settings dialog box. Then run the LD.BAT file on the MX2, and select OK in the Important dialog box on the PC.

Done

Select Done when you are finished selecting and transferring files.

You are returned to the Main Menu.

Table of Contents

CHAPTER 5 USING XFER 5-1

Introduction 5-1

About XFER 5-1

Syntax and Parameters 5-2

XFER Parameters 5-2

filename(s) 5-6

@file 5-7

..... 5-8

B# 5-9

C# 5-9

D# 5-10

E# 5-10

F# 5-11

H or ? 5-12

Ifile 5-12

Mcommand 5-12

N 5-13

O# 5-13

Q 5-15

R 5-15

S 5-16

T 5-18

W 5-18

X 5-19

Z 5-19

The XFER_ARGS Environment Variable 5-20

Multiple-Option Blocks 5-22

The Modem-Initialization File 5-24

Keywords 5-24

ACCESS_DELAY 5-24

CARRIER_TIMEOUT 5-24

COMPRESSION_STRINGS 5-24

DIAL_METHOD 5-25

ECHO 5-25
FAIL_STRINGS 5-25
HANDSHAKING 5-25
INIT_STRING 5-26
LOCKED_BAUDRATE 5-26
NUMBER# 5-26
PROTOCOL_STRINGS 5-27
Sample Modem- Initialization File 5-28
Performance 5-29
Error Codes 5-30

Chapter 5
Using XFER

Introduction

XFER (XFER.EXE) is a DOS utility that directs the serial transfer of ASCII and binary data between two computers. This chapter provides information for advanced users and system administrators who want to use XFER to transfer files between a MX2 and a PC.

For basic information about XFER and the Xmodem parameter defaults, see Chapter 2 “Using Advanced Features”, section titled “Transferring Files.”

About XFER

XFER supports Xmodem and Zmodem transfers at speeds up to 115200 baud. Modem support is provided via an initialization file that specifies option settings for the modem. Option settings can be specified on the command line or with an environment variable called XFER_ARGS.

XFER supports RTS/CTS handshaking for Xmodem protocol and both XON/ XOFF and RTS/CTS handshaking for Zmodem protocol.

Syntax and Parameters

The command line syntax for XFER is as follows:

```
XFER [/option1 [/option2] . . .] filename(s)
```

You can use a slash (/) or a hyphen (-) to denote options, and you can use uppercase or lowercase letters for them. Options can be placed before or after filenames on the command line.

Basic options and their defaults are listed and described in the following table. The "Default" column indicates whether the option is used (On) or ignored (Off) if you do not include it in the command line. For options that have two or more possible values, the default value is given.

XFER Parameters

Option	Description	Default	
		Xmodem	Zmodem
filename(s)	Identifies the file to be transferred or received.	None	None
@file	(Zmodem only) Specifies a response file consisting of two or more names of files to be transferred. Replace file with the name of the response file to use.	N/A	None
#	Specifies the communications port to use. Replace the # symbol with the desired setting: 1 = COM1 2 = COM2	1	1
B#	Specifies the baud rate. Replace the # symbol with the desired setting: 2400 4800 9600 19200 38400 57600 115200	19200	19200

Option	Description	Default	
		Xmodem	Zmodem
C#	(Zmodem only) Specifies how the retransmission of a file should be handled if a previous transfer was interrupted. Replace the # symbol with the desired setting: 1 = Never recover (start transmission from the beginning of the file) 2 = Follow sender (use the sender's crash-recovery options; ignore the receiver's) 3 = Always recover (send data from the point where transmission was interrupted)	N/A	1
D#	Specifies the number of seconds for XFER to wait for activity before cancelling the transfer. Replace the # symbol with the desired number of seconds for the timeout delay. Acceptable values are 0 (no timeout) through 65,535.	60	60
E#	Specifies the maximum number of times XFER should attempt retransmission of a packet after an error occurs. If the final attempt fails, XFER aborts the transfer. Replace the # symbol with the desired maximum number of attempts. A setting of 0 allows for unlimited attempts.	0	30
F#	Specifies the type of flow control to use for data transfer. Replace the # symbol with the desired setting: 0 = No flow control 1 = XON/ XOFF (Zmodem only) 2 = RTS/ CTS	0	1 = MX2 2 = all others
H or ?	Displays help for the XFER command.	None	None
Ifile	Specifies the modem-initialization file. Replace file with the name of the file to use.	modem.ini	modem.ini

Option	Description	Default	
		Xmodem	Zmodem

Mcommand	Sends a command to the modem before beginning the data transfer. Replace command with one of the following:
	
	A = Auto answer
	ATstr = Send ATstr commands
	D#x = Dial memory #x (0–9)
	Dstr = Dial phone number str
		None	None

N	Forces XFER to ignore all previously specified option settings, including filenames and options specified in the XFER_ARGS environment variable. All XFER options are set to their default state.	Off	Off
O#	Overwrites an existing file with a new file having the same name. Replace the # symbol with the desired setting: 1 = Overwrite if source is longer or newer (Zmodem only) 2 = Overwrite if CRCs don't match (Zmodem only) 3 = Append to existing file (Zmodem only) 4 = Always overwrite 5 = Overwrite if source is newer (Zmodem only) 6 = Overwrite if dates or lengths don't match (Zmodem only) 7 = Never overwrite	7	7
Q	Toggles quiet mode on and off. In quiet mode, only the filename and a "Transmitting..." or "Receiving..." message is displayed. When quiet mode is off, additional information is displayed. Each use of this option reverses the quiet-mode state.	Off	Off

Option	Description	Default	
		Xmodem	Zmodem
R	Receives the specified file or files.	Off	On if no file is specified
S#	(Zmodem only) Specifies how paths and names should be handled when sending files. Replace the # symbol with the desired setting: 0 = Strip paths 1 = Send paths 2 = Send new paths/filenames	N/A	0
T	Transmits the specified file or files.	On	On if file is specified
W#	Window size (Zmodem only): x = Packet size, in bytes 0 = Streaming	N/A	0
X	Uses Xmodem protocol for the transfer.		
Z	Uses Zmodem protocol for the transfer.		

filename(s)

Name(s) of the File(s) to Send or Receive

Xmodem

Only one file can be transferred at a time. You can specify the entire path, including the drive letter. If you do not specify a path, the file is sent from or received into the current directory. If the directory or file doesn't exist on a send, or the directory doesn't exist on a receive, the transfer will fail, with a file-open error.

You must include the filename on the command line when receiving a file. If multiple files are specified for Xmodem, only the first file will be transferred. All other file names will be ignored.

Zmodem

Zmodem allows up to 256 files to be transferred in one session. You can specify the entire path for each file, including the drive letter. If you do not specify a path, the file is sent from or received into the current directory. If the directory or the file doesn't exist on a send, or the directory doesn't exist on a receive, the transfer will fail, with a file-open error. DOS accepts only 128 characters on the command line, but you can use a response file to get around this limitation. (See the @file option.)

When receiving, the filename does not need to be specified for Zmodem. Zmodem transfers the name of the file to be sent before sending the file. (See the S option for information on controlling how Zmodem sends the filename.) Any filename specified on the receiving end will override the default name that is sent by the sender.

When multiple files are sent, a one-to-one correspondence is established. For example, if ten filenames are specified on the sender's side and five filenames are specified on the receiver's side, the first five files transferred will be received with the names specified on the receiver's command line, while the last five files will be received with the names specified on the sender's command line (assuming all the files exist). Each filename on the command line can include its own path.

XFER also recognizes the wildcard characters ? and *. Normal DOS pattern-matching rules for these characters apply.

Be careful about using wildcards when receiving: XFER expands the wildcards of the specified filenames and then searches for any matching patterns in the specified directory. If no matching files are found (in an empty directory, for instance), then no filenames will be sent to the Zmodem receive procedures. This may or may not be what you intend.

Also, DOS does not store files in alphabetical order, and so using *.* to both send and receive files may result in files being renamed because they are loaded in a different order. This can occur even if the file lists on both sides of the transfer are the same.

@file

Response File (Zmodem only)

The @file option allows use of a "response file" for specifying filenames when conducting Zmodem transfers. This option allows you to circumvent the DOS limitation of 128 characters on the command line when you want to send many files in a single transfer session.

When using a response file, simply fill the file with the filenames you wish to send or receive. The filenames may include drives and paths. One filename should appear on each line of the response file. You can specify up to 256 files this way.

The following is a sample response file, named RESPONSE.TXT:

```
autoexec.bat
c:\programs\theprog.exe
c:\data\file1.dat
c:\data\file2.dat
c:\data\file3.dat
```

Not all the filenames need to be specified in the response file. For example, the following command would send seven files, including the five in RESPONSE.TXT above.

```
Xfer /z c:\default\config.sys /@response.txt
c:\data\file4.dat
```

In this case, each filename is read in as it appears on the command line. The file C:\DEFAULT\CONFIG.SYS would be the first one sent, the AUTOEXEC.BAT file specified in the RESPONSE.TXT file would be the second file sent, and the C:\DATA\FILE4.DAT file specified on the command line would be the seventh file sent.

You can specify multiple response files. Regardless of the number of response files you use, the 256-file limitation for a single transfer session is always in effect.

If you include a response file in the XFER_ARGS environment variable, you can use the N option to ignore the response file and start from a default condition.

You can use response files with the S2 option. In this case, the format for the response file would be:

```
autoexec.bat c:\autoexec.bat
c:\programs\theprog.exe c:\prog.exe
c:\data\file1.dat d:\data1
c:\data\file2.dat d:\data2
c:\data\file3.dat d:\data3
```

In this case, the first filename on a line specifies the file on the sender's side. The second filename on the line specifies the filename the sender will pass to the receiver.

Note: The receiver's filename is separated from the sender's filename by a single space. If more than one space is used, the additional spaces will be included as part of the receiver's filename. Because a space character is used as a delimiter, Windows 95 and Windows NT filenames with spaces as part of the filename will not be parsed correctly and should not be used. Placing quotes around the filename will not help in this situation.

The @file option can be used only in Zmodem transfers. You must specify the Z option before the @file option. If you use a response file with the S2 option, you must specify the S2 option before the @file option.

All other rules governing filenames apply to response files.

#

COM Port

This option specifies the communications port to use for the file transfer. Replace the # symbol with the desired setting:

1 = COM1
2 = COM2

B#

Baud Rate

This option specifies the baud rate to be used for the file transfer. Replace the # symbol with the desired setting:

2400
4800
9600
19200
38400
57600
115200

C#

Crash Recovery (Zmodem only)

Crash recovery refers to the ability of Zmodem protocol to detect that a file transfer was not completed and to attempt to recover at the point of failure (instead of recopying the entire file). For instance, if the communications link is severed during the transfer of a 10K file, with only 5K of data successfully transferred, crash recovery can be used to send the remaining 5K without resending the entire 10K file.

Note: This option is supported by Zmodem protocol only. Xmodem will never attempt to recover a file after a crash.

Crash recovery uses the CRC of the sender's and receiver's files to ensure that the portion of the file that was successfully received in the first transfer is identical to that portion of the sender's copy of the file. If this is true, then the receiver instructs the sender to begin sending data beginning at the point in the file that corresponds to the end of the file on the receiver's side.

By default, crash recovery is turned off. To use the C option, replace the # symbol with the desired setting:

1 - No crash recovery
2 - Follow sender
3 - Always use crash recovery

If you use the C option without including a number, then the 1 setting is assumed. An invalid setting will result in an error on the command line.

The C option can be used in conjunction with the O option. If you specify C2 (follow sender) on the command line, the receiver will use the sender's crash and overwrite options. Any overwrite options local to the receiver will be ignored. This is useful if a default crash-recovery command is specified in the XFER_ARGS environment variable and you wish to temporarily disable crash recovery for the current transfer.

D#

Delay Before Terminating Transmission

This option allows you to specify a timeout. If the specified number of seconds elapse with no characters received by either the sender or the receiver, the program aborts the transfer session.

For multiple file transfers in Zmodem, the entire session is aborted, not just the transfer of the current file.

To use the D option, replace the # symbol with the desired number of seconds for the timeout delay.

Acceptable values are 0 (no timeout) through 65,535; the default is 60. A value of 0 disables the timeout feature, meaning that the transfer session will never be aborted because of inactivity. If you use the D option without specifying a number, an error will occur.

E#

Maximum Number of Errors Before Aborting Transfer

The E option allows you to specify the maximum number of times the receiver will request a retransmission of a packet before aborting the transfer session.

Note: For multiple file transfers in Zmodem, the entire session is aborted, not just the transfer of the current file.

For Xmodem, the default is 0, meaning that Xmodem will never be aborted because of errors. For Zmodem, the default is 30. A setting of 0 disables the error-count tracking. If you use the E option without specifying a number, an error will occur.

F#

Flow Control

This option allows you to specify what type of flow control to use for the file transfer.

Flow control is the ability of the receiver to detect that data is coming in faster then it can receive it and to issue a command to the sender instructing it to stop sending data. When the receiver is again able to handle new data, it issues another command instructing the sender to resume the transfer of data.

XFER supports two types of flow control: software (XON/XOFF) and hardware (RTS/CTS). Only one type can be used at a time. The sender and receiver should have this option enabled similarly.

To use the F option, replace the # symbol with the desired setting:

0 - No flow control
1 - XON/ XOFF (Zmodem only)
2 - RTS/ CTS

Note: XON/XOFF cannot be used with Xmodem protocol, because Xmodem protocol sends raw binary data and cannot distinguish between the XON/XOFF characters and file data. Attempting to specify XON/XOFF with Xmodem protocol will result in an error.

If you do not include the F option in the command line, no flow control is used. If you use the F option without specifying a number, it is assumed to mean F0, or no flow control. This is useful in the case where flow control is specified in the XFER_ARGS environment variable but you wish to turn flow control off for the current transfer session. An invalid setting will result in an error on the command line.

On a MX2, XON/XOFF flow control is the default when transferring with Zmodem.

H or ?

Help

This option displays a brief description of the XFER syntax, options, and settings.

Ifile

Modem-Initialization File

This option specifies the file that contains modem setup and control commands. See "The Modem Initialization File" for complete information about the file.

Mcommand

Modem Command

This option allows commands to be sent to the modem before the start of the file transfer. To use the M option, replace command with one of the following commands:

A = Auto answer
ATstr = Send ATstr commands
D#x = Dial memory #x (0–9)
Dstr = Dial phone number str

Specifying XFER /MA instructs the modem to go into auto-answer mode. In this mode the modem will wait for the timeout period specified in the modem-initialization file for another modem to dial into it. On detection of a ring-in signal, XFER will answer the line and attempt to start a file transfer.

Specifying XFER /MATstr allows a string of AT commands to be sent to the modem. These commands will be sent to the modem after the initialization string from the modem-initialization file and can be used to specify a different configuration. Since only one modem command can be specified on the command line, any commands to auto-answer or dial must be included in the AT string.

There are two methods for dialing numbers. The first method uses the format XFER /MD#x, where x is a number from 0 through 9. This number corresponds to a directory number from the modem-initialization file, which identifies a number that should be dialed for this

transfer (see the NUMBER# keyword later in this chapter). If you do not specify a number, directory number 0 is used.

The second dialing method is to use the XFER /MDstr format, where str is a dialing command to be sent directly to the modem. This string can be any recognizable phone number text, such as (555) 444-3333 or 5554443333.

The last M option on the command line or in the environment variable is the one used for controlling the modem. All earlier modem-command settings are ignored.

If you use the M option without specifying a command, the modem will be disabled for that transfer session. This is useful in the case where modem commands are specified in the XFER_ARGS environment variable but you wish to transfer files without a modem for the current transfer session.

N

Ignore Previous Option Settings

This option causes XFER to ignore previously specified options and return to a default state. All options specified in the XFER_ARGS parameter and on the command line preceding the N are ignored. All options that XFER supports are returned to the default state, and all filenames, response files, modem-initialization files, and modem commands that are specified before the N (including the XFER_ ARGS environment variable) are discarded.

The N option is useful when the XFER_ARGS environment variable is used to redefine defaults for XFER. It isn't always obvious that the XFER_ARGS parameter is controlling the behavior of XFER, and it is often the case that several parameters have been redefined. Instead of having to set each option back to its default, you can use the N option to return XFER to a known state.

O#

Overwrite Existing File(s)

The O option specifies what action the receiver should take if the file being transferred already exists on the receiver's side. When using this option, replace the # symbol with the desired setting:

1 - Overwrite if source is longer or newer

2 - Overwrite if CRCs don't match

3 - Append to existing file

4 - Always overwrite
5 - Overwrite if source is newer
6 - Overwrite if dates or lengths don't match
7 - Never overwrite

By default, XFER operates in O7 mode—existing files are never overwritten. For Xmodem, the only valid options are O4 and O7; all other settings resolve to O7 (never overwrite). All settings for the O option are available with Zmodem protocol.

To remain compatible with previous versions of XFER, the O option used without a setting resolves to the O4 setting (always overwrite). This differs from most other XFER options, where specifying the option without a setting usually resolves to the default condition for that option. To use the default condition for the O option, you must specify the O7 setting.

An invalid setting will result in an error on the command line.

Note: XFER does not prompt you to specify whether a file should be overwritten in the default mode. If no overwrite option is specified, the file will never be overwritten. Under Xmodem, the session will abort. Under Zmodem, the file will be skipped and the next file will be transferred.

For the O6 setting under Zmodem, XFER does not set the date or time of a received file to match the original date or time of the sender's version of the file. Instead, the date and time are taken from the receiver's operating system when the file is received and created. Because of this, it is highly unlikely that a file transferred with XFER will have the exact date of the original file. Since the resolution of times for files under DOS is in two-second increments, it is unlikely the timestamps will be the same, even if the times on the receiver and sender are calibrated frequently. Also, DOS doesn't report the seconds field when displaying the modification time of a file during a file listing. So, two files may appear to have the same timestamp when in fact they don't. The tendency with the O6 option is for files to be overwritten, because times usually do not match exactly.

The O3 setting is unique in that it causes the transferred file (binary or ASCII) to be appended to the end of the old file rather than overwriting it.

With Zmodem, the O option can be used with the C option setting for crash recovery. If you specify C2 (follow sender) on the command line, then the receiver will use the sender's crash and overwrite options. Any options local to the receiver will be ignored.

Q

Quiet Mode

This option toggles quiet mode. When quiet mode is enabled, minimal information is displayed about the file transfer in progress. Generally, only the name of the file being transmitted is displayed. When not in quiet mode, XFER will display a copyright message, the filename, and file statistics, including a running count of bytes.

Running XFER in quiet mode on the MX2 can have serious consequences for serial-transfer performance, especially at high speeds. At 115200 baud, transfers are four times faster if quiet mode is enabled on the MX2 than if it is disabled, owing to the delay inherent to writing a running byte count to the screen.

Since the Q option is a toggle switch, each occurrence of it in the command line inverts the quiet-mode state. By default, XFER has quiet mode off. The first occurrence of the Q option turns quiet mode on, the next turns it back off, and so on. This is most useful if the option is specified in the XFER_ARGS environment variable to activate quiet mode by default but you wish to deactivate quiet mode for the current transfer session.

R

Receive File(s)

This option specifies that files are to be received. With Xmodem protocol, the option must be specified whenever you wish to receive a file. The option can be included in the XFER_ARGS environment variable, forcing Xmodem protocol to default to receiving instead of sending files.

With Zmodem, receive is the default if no file is specified on the command line (for example, XFER /z). The name of the file is sent by the transmitting side before the file is transferred, and the file is received with that path and name. If you wish to receive a file under Zmodem with a different name from the sender's original filename, you can use the R option to force Zmodem into receive mode and then specify a filename. (See the "filename(s)" option for information on specifying filenames.) Using the R option without a filename is the same as not using the option at all—the sender's filename (and path) is used.

Note: The last transfer option, R or T, on the command line controls whether to transmit or receive for the session.

S

Specify Sender's Path-and-File Handling (Zmodem only)

The S option controls how the sender handles the paths and filenames of the files that it sends. This option is available only with Zmodem protocol. You must specify the Z option before using the S option. You can use one of the following settings. The settings are described individually below.

0 - Strip paths
1 - Send paths
2 - Send new paths/filenames

If you do not include the S option in the command line, the default setting (0) is used. If you use the S option without specifying a setting (for example, XFER /S), it is assumed to mean S0. This is useful in the case where another option is specified in the XFER_ARGS environment variable but you wish to strip the paths for the current transfer session.

An invalid setting will result in an error on the command line.

0 - Strip Paths

In this mode (the default), the sender will remove any paths that are specified with a filename before sending the filename to the receiver. The new filename will be transmitted to the receiver without any path information. The file will be stored by the receiver in the current directory.

1 - Send Paths

This option performs no processing on the filenames specified on the sender's side. Any drive and path information that is specified is transmitted to the receiver. If a path is specified and it does not exist on the receiver's side, the transfer will abort with a failure.

2 - Send New Paths/Filenames

When the S2 setting is used, all filenames are treated as filename pairs. This gives you the ability to specify dual filenames during a transfer. The first filename (optionally including a drive and path) is the one that the sender uses to open the file. The second filename is used by the sender when it transmits the filename to the receiver. This gives you the ability to transfer a file and have it renamed on the receiver's side. It also lets you transfer a file from one directory on the sender's side to another directory on the receiver's side.

You may specify multiple filename pairs, which may be separated by other XFER options.

You must observe the following conventions when using the S2 option. Failure to conform may result in errors.

- You must specify the S2 command ahead of any filenames.
- When specifying dual filenames, you must separate the filenames by a single space. The first filename in the pair is what the sender uses, and the second filename is what the sender will transmit to the receiver. If you use more than one space, all spaces after the first will be included as part of the receiver's filename.
- You may specify drive and path components for either filename in a pair. However, you cannot specify just a drive and path; that is, the actual name of the file must be included in both filenames.

Correct examples:

```
C:\> xfer /zs2 file1 file2
C:\> xfer /zs2 c:\data\file1 d:\file2
C:\> xfer /zs2 c:\data\file1 d:\file1 c:\yourfile myfile
C:\> xfer /zs2 file1 data1 /b115200 file2 data2
```

Incorrect examples:

```
C:\> xfer /zs2 file1 /b115200 file2
C:\> xfer /zs2 file1        file2
C:\> xfer /zs2 file1[TAB]file2
C:\> xfer /z file1file2 /s2
C:\> xfer /zs2 file1d:\
```

In the second incorrect example, the additional spaces would be included in the receiver's filename. This is generally wrong, but it may be correct if that is the intended result. The third incorrect example is invalid because the filenames must be separated by a single space; no other white-space character can be used. This mistake most often occurs when using response files (see @file).

Note: If a filename is specified on the receiver's side, that filename will override whatever filename the sender transmits to the receiver.

T

Transmit File(s)

This option specifies that files are to be sent. For Xmodem protocol, this is the default; that is, typing XFER MYFILE on the command line would send the file MYFILE.

For Zmodem protocol, transmit is the default if you specify a file on the command line. So, for example, the command XFER /Z MYFILE is equivalent to the command XFER /Z /T MYFILE.

The T option is most useful if the XFER_ARGS environment variable includes the R command but you want to send a file.

Note: The last transfer option, R or T, on the command line controls whether to transmit or receive for the session.

W

Window Size (Zmodem only)

This option controls the use of windowing with Zmodem protocol. By default, Zmodem is a streaming protocol, and windowing is disabled. “Streaming” refers to the method by which Zmodem transfers data. In streaming mode, the sender forms 1K data packets and sends one packet after another in a continuous stream. The sender does not wait, and does not expect, to get acknowledgments from the receiver for any of the packets it sends. Instead, the sender assumes the file transfer is going normally unless it gets an error indication from the receiver.

This works fine in robust, error-free environments. But the receiver can get lost or disconnected without the sender realizing it. Windowing provides a way in noisy environments to give some level of packet acknowledgment to Zmodem protocol. With windowing, the sender will send up to the number of bytes specified by the size of the window and then stop transmitting data until the receiver acknowledges that it has received all of the packets that have been sent. The sender then sends more packets, up to the size of the window, and so on.

Waiting for acknowledgments slows down transfer speeds, but XFER allows a dynamic compromise between speed and robustness. XFER lets you specify the window size with any value from 0 to 65535. Use W0 for streaming mode. For a 1K window, use W1024. Values below 1024 are used exactly as specified and should be the size of the transmitted packets. Values above 1024 should be multiples of 1024 (1024, 2048,

4096, etc.). Values above 1024 that are not multiples of 1024 are rounded up to the nearest multiple of 1024.

If you do not include the W option on the command line, streaming is used. If you use the option without specifying a setting, W0 (streaming) is used by default. This is useful in the case where a window size is specified in the XFER_ARGS environment variable but you wish to use streaming for the current transfer session.

Note: Always place the W option after the Z option, or a parsing error will occur. See the information about the Z option for more details.

X

Xmodem Transfer

The X option instructs XFER to transfer all files in that session using Xmodem protocol. Because this is the default file-transfer protocol, it does not normally need to be specified.

Z

Zmodem Transfer

The Z option instructs XFER to transfer all files in that session using Zmodem protocol. The Z option should come before all other options that are valid for Zmodem only (such as the C option). This is required because Xmodem is the default protocol for XFER, and option parsing will fail if an illegal setting is specified under Xmodem.

In addition, specifying the Z option resets the Zmodem window size for that session, making it necessary for the Z option to come before any use of the W option.

Note: The last protocol option in the command line specifies the protocol that will be used for the file transfer; that is, Xmodem would be used for the transfer ordered by XFER /Z /X myfile, and Zmodem would be used for the transfer ordered by XFER /X /Z myfile.

The XFER_ARGS Environment Variable

XFER recognizes the environment variable XFER_ARGS. This variable can be used to set option settings that you want for most transfer sessions. You can even specify files in the XFER_ARGS environment. Parsing of the XFER command line starts with the XFER_ARGS variable and then continues through any other specified options or filenames.

You can use a single slash or hyphen to merge multiple options in the XFER_ARGS variable, or you can use a slash or hyphen for each option. The following example illustrates both cases:

```
C:\> set XFER_ARGS = /ZROB57600
C:\> set XFER_ARGS = /Z /R /O /B57600
```

For each command line in the example, files will be received (option R) using Zmodem protocol (Z) and a baud rate (B) of 57600 baud, and existing files will always be overwritten (O).

Note: You can use up to ten slashes or hyphens for options in the environment variable. See the following section, "Multiple-Option Blocks" for more details.

Any of the parameters used in the example could be overwritten on the command line. For example, if you issued the following command:

```
C:\> xfer /x myfile
```

XFER would use Xmodem for the file transfer instead of Zmodem, while still using the other option settings specified in the XFER_ ARGS variable.

There are two precautions for mixing options in the environment variable with options on the command line. The first is about options that are supported by Zmodem protocol only. In the following example:

```
C:\> set XFER_ARGS = /z /w4096 /c3
C:\> xfer /x myfile
```

the environment variable is set up to use Zmodem with a 4K window and crash recovery turned on. In the XFER command line, Xmodem protocol is specified. Since Xmodem doesn't support windows or crash recovery, both those options are ignored. Another, more troublesome scenario is the following:

```
C:\> set XFER_ARGS = /z /o5
C:\> xfer /x myfile
```

Here, XFER is set to Zmodem in the environment variable, with an overwrite setting of 5 (overwrite if source is newer). However, in the XFER command line, Xmodem protocol is specified. The only overwrite

settings that Xmodem supports are O4 (always overwrite) and O7 (never overwrite); all other O options resolve to O7 for Xmodem. If the file myfile exists, the transfer will abort. In this case, you should either specify O4 on the command line or not use the X option.

Note: If a filename is included in the XFER_ARGS environment variable, that file will always be the first file sent or received. You can negate it only by specifying the N option on the command line. For this reason, you should generally not include filenames in the environment variable.

Multiple-Option Blocks

XFER supports multiple options after a single slash (/) or hyphen (-) on the command line and in the XFER_ARGS environment variable. Each of the following examples is a valid command line:

```
C:\> xfer /zrob115200 myfile
C:\> xfer /zro /d30 /b115200 myfile
C:\> xfer /zrw2 /o5c3f2 myfile
```

Any option can immediately follow another without a separate delimiter (/ or -) unless the preceding option has a multicharacter setting. The following options have multicharacter settings:

- B (baud rate)
- D (timeout)
- E (error count)
- I (modem-initialization file)
- M (modem command)

The setting for each of these options must be followed by a space. Except for the I and M options, the option is ignored during parsing if there is no space following its setting. For the I option, any extra characters directly following the initialization-file filename will be treated as part of the filename. Any extra characters following the M option will be treated as part of the modem command; this may produce modem-command syntax errors.

Correct examples:

```
C:\> xfer /zrob115200 myfile
C:\> xfer /zo5c3f2b115200 myfile
C:\> xfer /z /mA myfile
```

The first two command lines above are valid because the /b115200 setting is always at the end of the multiple-option block. Also in the second example, the O, C, and F options all have single-digit settings.

Incorrect examples:

```
C:\> xfer /zb115200ro myfile
C:\> xfer /z /mAro6 myfile
```

In the first command line above, XFER would load and run. However, the R and O options would not be detected, because the b115200 setting is not followed by a space. Therefore, XFER would try to send the file

myfile, not receive it. The second example is wrong because the R and O6 parameters would be included as part of the modem command A.

Be careful when specifying the COM port in a multiple-option block. For example, the following command:

```
C:\> xfer /zo2 myfile
```

sets the overwrite option to 2 (overwrite if CRCs don't match) but doesn't cause XFER to use COM port 2. The following commands could be used to do this:

```
C:\> xfer /z2o myfile
C:\> xfer /z2o2 myfile
C:\> xfer /zo22 myfile
```

In the last example, the first 2 is treated as the setting for the O, and the second 2 is parsed as the COM port to use for the transfer.

The Modem-Initialization File

The modem-initialization file (MODEM.INI) contains keyword-and-value pairs, with each pair on a separate line. Each keyword is separated from its value by one or more spaces; tabs and other white-space characters are not valid. Keywords can be in any order within the file.

Lines beginning with a # character or with a space character are treated as comment lines and are ignored. The # character can also be used to embed comments within a line. Any characters after a # character in a line are ignored for that line.

Note: Individual lines cannot exceed 128 characters in length, including comments, or errors in parsing may occur.

Keywords

ACCESS_DELAY

This keyword specifies the number of milliseconds for XFER to wait for a response from the local modem when sending a command to the local modem. The default is 2000 ms (2 seconds).

CARRIER_TIMEOUT

This keyword specifies the number of seconds for XFER to wait for a carrier signal from the remote end before timing out. The default is 60 seconds.

COMPRESSION_STRINGS

This keyword specifies a list of response strings (expected responses from the modem) that indicate that a connection was made using data compression. Because modems often support various types of data compression, they may have more than one string indicating that compression is taking place. You can use the COMPRESSION_STRING keyword as many times as necessary to create the desired list. However, the combined length of all the values assigned to COMPRESSION_STRING cannot exceed 115 characters.

DIAL_METHOD

This keyword specifies how the modem attempts to dial phone numbers. This can be T for tone dial or P for pulse dial.

ECHO

This keyword indicates whether responses received from the modem should be displayed to the screen. Enable the keyword by setting the value string to T (for true); clear it by setting the value string to F (for false).

FAIL_STRINGS

This keyword is a list of response strings (expected responses from the modem) that indicate that the connection to the remote end failed. These strings contain text (such as NO CARRIER and BUSY) that the modem might return on an error. Using a configurable list of errors allows the serial-in/out modem run-time library to compensate for differences in messages between individual modems. You can use the FAIL_STRING keyword as many times as necessary to create the desired list. However, the combined length of all the values assigned to FAIL_STRING cannot exceed 115 characters.

HANDSHAKING

This keyword controls the type of handshaking the MX2 will perform with the modem. Generally, RTS/CTS handshaking is necessary to support the advanced functions of modems, such as compression and error-correcting protocols.

You can set this keyword to N for no handshaking, X for Xon/Xoff software flow control, or R for RTS/CTS hardware handshaking.

Note: The HANDSHAKING keyword in the modem-initialization file takes precedence over any flow-control options selected on the command line in XFER.

INIT_STRING

This keyword specifies the string to use to initialize the modem. The initialization-string value should begin with the AT sequence for Hayes-compatible modems, as the serial in/out modem routines do not attach these characters to the beginning of the initialization string before sending it to the modem.

LOCKED_BAUDRATE

When enabled, this keyword indicates that the local modem is configured to communicate with the PC at a fixed baud rate, regardless of the speed of the connection between the modem and the remote end. This is the normal state of affairs for any modem that supports either data compression or error-correcting protocols. Having this keyword enabled implies that the modem is using hardware handshaking.

The baud rate used for a file transfer will be the baud rate set for XFER by the B option (the default is 19200 baud). If the B option is not set, the baud rate used is whatever the modem indicates it is using in the CONNECT message after connecting to the remote end.

Enable this keyword by setting the value string to T (for true). Clear it by setting the value string to F (for false).

NUMBER#

The NUMBER# keyword specifies a user-defined phone number. The value string can be any sequence of characters that defines a valid number for the modem to dial. Up to ten phone numbers may be specified, with each one assigned a keyword NUMBER0 through NUMBER9. Any number may be assigned to a keyword (unless the number has already been assigned). You do not need to define all ten NUMBER# keywords, and they do not need to be defined in numerical order.

See the Mcommand section for information on how to access the NUMBER# strings to dial when using XFER.

PROTOCOL_STRINGS

This keyword is a list of response strings (expected responses from the modem) that indicate that a connection was made using an error-correcting protocol. Since modems often support various error-correcting protocols, they may have more than one string indicating that such a protocol is being used. You can use the PROTOCOL_STRING keyword as many times as necessary to create the desired list. However, the combined length of all the values assigned to PROTOCOL_STRING cannot exceed 115 characters.

Sample Modem- Initialization File

```
INIT_STRING     ATE1Q0V1X4&C1&D2S7=10s9=6s10=20S1
                1=55S0=2
FAIL_STRING     NO CARRIER
FAIL_STRING     ERROR
FAIL_STRING     NO DIALTONE
FAIL_STRING     BUSY
FAIL_STRING     NO ANSWER
# This is a comment.
  So is this.
COMPRESSION_STRING      CLASS 5
COMPRESSION_STRING      V.42BIS
PROTOCOL_STRIN          LAPM
PROTOCOL_STRIN          ALT
DIAL_METHOD             T     # (T)ONE or
                              (P)ULSE dialing
CARRIER_TIMEOUT         60
ACCESS_DELAY            2000
LOCKED_BAUDRATE         T     # (T)RUE or
                              (F)ALSE
ECHO                    T     # (T)RUE or
                              (F)ALSE
HANDSHAKING             R     # (R)TSCTS,
                              (X)ONXOFF, or
                              (N)ONE
NUMBER0                 9 555-1234
NUMBER9                 (111) 555-9999
NUMBER5                 (111) 555-7777
NUMBER1                 9 555-4321
```

Note: The keywords are all case-sensitive and must be capitalized. For the FAIL_STRINGS, COMPRESSION_STRINGS, and PROTOCOL_ STRINGS settings, the value string should also be capitalized. Any responses from the modem are converted to capital letters before being compared with the various substrings.

Performance

This section describes issues relating to serial performance on the MX2. Although these issues are described in the context of XFER, they apply to serial transfers in general.

File-transfer speed is severely reduced when byte counts are displayed on the MX2 screen. Use the Q option in XFER to enable quiet mode and speed up transfers.

Performance also is diminished when data is transferred to the C drive or to a PCMCIA ATA card. Both of these devices write data to the disk very slowly. Problems may arise as the disks become full and loading algorithms are executed to clean up space for new data. This can become particularly severe with Zmodem in streaming protocol, because the sender never waits for the receiver to write data to the disk. To avoid this problem, use Zmodem with either windowing or flow control enabled. Flow control is generally faster and permits the receiver to operate at its peak capacity.

Another factor in performance is the presence of other software running in the background. Card and socket services, for instance, use the timer interrupt for certain functions. Because card and socket services chain into this interrupt and execute some code with interrupts disabled, the system may become overburdened when running serial interrupts at high speed (greater than 19200 baud). In this case, overrun, parity, and framing errors become more common, sometimes resulting in an inability to send a file efficiently. If this occurs, select a lower baud rate and enable flow control.

Error Codes

The following table lists error codes returned by XFER.

Value	Mnemonic	Description
0	OK	All files transferred OK.
1	ABORT_FILESSKIPPED	One or more files were skipped during a multiple file download.
2	ABORT_TIMEOUT	The transfer was aborted because of a timeout.
3	ABORT_KEYPRESS	The abort key (ESC) was pressed.
4	ABORT_LINEERROR	A communications line error (e.g., OVERRUN) occurred.
5	ABORT_FILEERROR	A read, write, open, close, or access error occurred on a file.
6	ABORT_FTPERROR	An invalid file-transfer protocol option was selected.
7	ABORT_CHECKERROR	A checksum or CRC error occurred.
8	ABORT_MEMORYERROR	An error occurred while trying to allocate memory from the heap.
9	ABORT_RECEIVERERROR	The receiver encountered a problem and requested to skip the file.
10	ABORT_COMERROR	An error occurred while opening the COM port.
11	ABORT_ARGERROR	An error in an argument (option setting) occurred on the command line.
20	ABORT_UNKNOWN	An unknown error occurred.
31	MODEM_ABORT_CONNECTION	XFER could not establish a connection with the remote end.
32	MODEM_ABORT_NORESPONSE	The modem did not respond.
33	MODEM_ABORT_INIFILE	The specified modem-initialization file could not be found.

Table of Contents

CHAPTER 6 COMMANDS 6-1

Introduction 6-1

System Utilities 6-1

CFGDEV.SYS 6-2
CFGIO.EXE 6-3
COMIO.COM 6-4
DECODE.SYS 6-4
FLASHDSK.SYS 6-5
FORMAT.COM 6-5
LOCK.COM 6-6
ORGANIZE.COM 6-7
PM.COM 6-8
VDISK.SYS 6-9
XFER.EXE 6-9

ROM-DOS Commands 6-10

ROM-DOS vs MS-DOS 6-10

ATTRIB.EXE 6-12
BUFFERS 6-13
CHKDSK.EXE 6-14
COMMAND.COM 6-16
DIR 6-18
FCBS 6-21
FIND.EXE 6-22
HELP.COM 6-23
NEWFILE 6-24
PRINT.EXE 6-25
SHARE.EXE 6-27
SWITCHES 6-28
TREE.COM 6-29
VER 6-30
XCOPY.EXE 6-31
XDEL 6-33

Chapter 6
Commands

Introduction

This chapter describes some of the device drivers and utilities that are designed to be run on a MX2 in section titled “System Utilities.” It also includes Datalight ROM-DOS commands that are available in the MX2. ROM-DOS commands that differ from their MS-DOS equivalents are identified and described.

The information in this chapter is taken from Datalight’s “ROM-DOS 6.22 User’s Guide” and is used by permission.

System Utilities

Where applicable, command syntax and parameters are given. Parameters may be supplied using either uppercase or lowercase letters, and the hyphen (-) may be substituted for the forward slash (/).

CFGDEV.SYS

The CFGDEV.SYS file is located on drive **B** of the MX2. When CFGDEV.SYS is loaded by the CONFIG.SYS file on that drive, a logical character-based device called PARAMS is created. This device receives programming strings that modify the configuration parameters that control the behavior of several system components. There are three ways you can send programming strings to the PARAMS device:

Barcode

Special barcode labels beginning with **$+$-** and ending with **EE** can be scanned using any barcode scanning device. Appendix C contains many useful labels.

File Copy

Files containing the barcode programming strings can be created and copied to the PARAMS device. The Configuration Utility creates a file called BPARAMS.INI that contains all of the configuration settings. The autoexec.bat file on the MX2's drive **C** contains the following command:

```
EXIST c:\bparams.ini copy c:\bparams.ini PARAMS
```

which copies the BPARAMS.INI file to PARAMS. You may also create your own file containing configuration settings.

Example: To use the D2 defaults with the **CTL-ALT-DEL** key sequence disabled, complete the following steps:

1. Create a MYPARAMS.INI file with the following text:

   ```
   $+$-D2E00EE
   ```

   D2 sets the D2 defaults, and **E00** disables the **CTL-ALT-DEL** key combination.

2. Copy MYPARAMS.INI to the PARAMS device using the following DOS command:

   ```
   COPY MYPARAMS.INI PARAMS
   ```

Run-Time Library API

The API in the MX2 run-time library contains two function calls that allow you to send configuration strings to the PARAMS driver from within a C application. See **CFG_Write()** and **CFG_Read()** in the "MX2 Programmer's Reference."

Note: Attempts to create, delete, or modify a file called params will conflict with the PARAMS device. You cannot eliminate the loading of cfgdev.sys except through the safe-boot process.

CFGIO.EXE

The CFGIO.EXE utility changes the current font set or the current keypad mapping to be used by the system (or both). This is primarily to be used for loading support of alternate keypad overlays and fonts for international use. The new settings will take place only if the font set and keypad mapping are compatible.

Syntax

```
CFGIO [fontfile] [keymap]
```

Options

fontfile

Specifies the name of the file containing the new font set to be loaded into the system. Font files have the extension fnt.

keymap

Specifies the name of the file containing the new keypad map to be loaded into the system. Keypad map files have the extension kbd.

COMIO.COM

This utility provides an easy means for developers to interact with the MX2 by allowing video and keyboard interaction to be done at a host PC. It does this by controlling redirection of video and keyboard I/O through the portable's serial port COM1. When keyboard redirection is disabled, input is received from the MX2's keypad; when it is enabled, input is taken from the serial port. The same mode of operation applies to video output, which is sent to either the display or out the serial port.

When redirecting video output, keypad input, or both, you must connect the MX2's serial port to a host computer. The host computer should be running a basic terminal emulator that provides a direct connection to the host communications port. The host communications port settings should be: no parity, 8 data bits, 1 stop bit, and the baud rate specified in the comio.com command line. By default, both video and keyboard I/O are redirected, but either one may be changed independently.

Syntax

```
COMIO [/b#] [/h] [/k] [/v]
```

/b#

Specifies the baud rate to use. If you do not specify this setting, the current baud rate is used.

/h

Displays a help file for the utility.

/k

Changes keyboard redirection only.

/v

Changes video redirection only.

DECODE.SYS

This driver controls barcode scanning devices and decodes barcode labels into text. If special programming barcodes are read, the decoded information will be sent to the PARAMS device. Otherwise, the resulting text is placed in the keyboard buffer for reading by the application. DECODE.SYS is located on drive B of the MX2 and is loaded by the CONFIG.SYS file located on that drive. You cannot eliminate the loading of DECODE.SYS except through the safe-boot process.

FLASHDSK.SYS

This driver configures all of the unit's available flash memory as a read-write disk, called a flash disk. Reading from a flash disk is fast, but writing can be somewhat slower. This driver is located on the B drive and is loaded by the CONFIG.SYS file located on that drive. You cannot eliminate the loading of FLASHDSK.SYS.

FORMAT.COM

This utility formats a read-write disk drive. Only the flash and RAM drives may be formatted using this command. FORMAT.COM uses the existing drive parameters to recreate the drive, but without any files stored on it. This provides a quick method for cleaning out an existing drive.

Syntax

```
FORMAT [drive:] [/y]
```

Options

drive

Specifies the letter of the drive to be formatted. If you do not specify a drive letter, the current drive is used.

/y

Suppresses output from being sent to the display, and bypasses the usual prompt to proceed with formatting.

LOCK.COM

Use this utility to enable or disable write protection on flash or RAM drives. (This is the software equivalent of the write-protect tab on a floppy disk.) You can use LOCK.COM to protect against accidental erasure of all files stored on the flash disk.

Whenever the MX2 is rebooted, write protection on a drive will be disabled, by default. To lock the drive upon bootup, include a lock command in the AUTOEXEC.BAT file on drive C.

Syntax

```
LOCK [drive:] [/l] [/u] [/y]
```

Options

drive

Specifies the drive letter of the drive which is to be locked or unlocked. If you do not specify a drive letter, the current drive is used.

/l (the letter L)

Lock the flash drive to prevent further disk writes.

/u

Unlocks the flash drive, allowing further disk writes.

/y

Suppresses output from being sent to the display.

Note: If both the /l and /u options are given, the last option specified will take effect.

ORGANIZE.COM

This utility reorganizes sectors on a flash drive to improve flash disk access. Data is relocated so that all free sectors are grouped together, reducing the overhead of freeing space for new data. ORGANIZE.COM has a greater effect on a flash disk as the disk gets closer to being full.

Note: The only MX2 drive you can organize with this utility is the flash disk created with the FLASHDSK.SYS driver. ATA flash drives will not respond properly to this utility.

Syntax

```
ORGANIZE [drive:] [/y]
```

Options

drive

Specifies the drive letter of the flash drive that is to be reorganized. If a drive letter is not given, the current drive will be used.

/y

Suppresses output from being sent to the display.

PM.COM

Use this utility to control various power-management features of the MX2. You can use it at the command line or in a batch file (including AUTOEXEC.BAT) to set or read power-management settings.

Syntax

```
PM [/b#] [/f#] [/h] [/i] [/r] [/t#]
```

Options

/b#

Sets the automatic timeout for the backlight. Replace the # symbol with the number of seconds to wait after a keypress before automatically turning off the backlight. Each keypress restarts the timeout countdown. The range of acceptable values for # is 0 (off) to 255; the default is 15 seconds.

/f#

Sets the time interval for audio indication when the batteries are low. Replace the # symbol with the number of minutes between soundings of the tone. The tone will not sound until the battery has been in the low state for the same number of minutes. The range of acceptable values for # is 0 (off) to 255; this option is off by default.

Note: The audio warning uses extra current, causing the batteries to drain faster. Therefore, you might want to set the interval for as long as possible or not use it at all.

/h

Displays a help file for the utility.

/i

Displays timer settings for auto-off, backlight timeout, and low-battery audio indication.

/r

Resets power management to the cold-boot defaults.

/t#

Sets the auto-off timeout. Replace the # with the number of seconds of nonuse before the unit should move to its lowest power state. The range of acceptable values for # is 16 to 1032, or 0 for off; the default is 300 seconds (5 minutes).

VDISK.SYS

This driver configures all of the unit's available extended memory as a read/write disk, called a RAM disk. This driver is located on drive B of the MX2 and is loaded by the CONFIG.SYS file located on that drive. You cannot configure the parameters for this driver.

XFER.EXE

The XFER utility gives you the ability to transfer files to and from a PC through the MX2's serial port. For complete information about XFER, see Chapter 5 "Using XFER."

ROM-DOS Commands

This section provides descriptions of the ROM-DOS commands listed in the following “ROM-DOS vs MS-DOS” table. Each entry includes an explanation of the command's purpose, the command entry syntax, remarks, and examples.

Each command also has a label to designate whether it is an internal or external command. Internal commands are part of the command processor program, COMMAND.COM. These functions are available only while COMMAND.COM is running. External commands are actually stand-alone utility programs. They are independent from COMMAND.COM. Internal commands that are unique to CONFIG.SYS processing are also identified. These commands can be used only in a CONFIG.SYS file.

ROM-DOS vs MS-DOS

The following table identifies differences between ROM-DOS commands and their MS-DOS equivalents. For more information, see the individual command descriptions in the next section.

Command	Features Exclusive to ROM-DOS	Features Exclusive to MS-DOS
ATTRIB	-C: Clears all file attributes	/S: Processes files in all subdirectories
BUFFERS		Allows designation of secondary buffer cache
CHKDSK	/C: Corrects errors without user confirmation	
COMMAND	Internal command help only	/Y: Steps through batch file specified by /C or /K switch help.hlp in MS-DOS includes all commands (external and internal), installable drivers, etc.

Command	Features Exclusive to ROM-DOS	Features Exclusive to MS-DOS
DIR	/A X: Shows attributes	/O:C and /O:-C: Sorts by compression ratio /C[H]: Displays compression ratio of files compressed using Drivespace or Doublespace
FCBS	, [minimum number]	
FIND		/I: Not case-sensitive
HELP	Requires command.hlp	MS-DOS requires external file, help.com, but provides more help text
NEWFILE	ALL	Not available with MS-DOS
PRINT	/F: Sets maximum number of files	/D:LPTx (MX2 has no parallel port.) /U /M /S /Q
SHARE	/U: Unloads share.exe	/F:space: Allocates space to record
SWITCHES		/W
TREE		/A: Indicates no graphics characters for tree symbols
VER	/R: Shows full version and release number Allows revision of the version number	
XCOPY		/Y /-Y: Turns confirmation prompts on or off
XDEL	All	Not available with MS-DOS Similar to DELTREE

ATTRIB.EXE

Type

External

Purpose

The ATTRIB command either displays or modifies the attribute of a file.

Syntax

```
ATTRIB [+ | -][option][filespec]
```

Remarks

The file attributes define the characteristics of a file. They determine if a file may be deleted or modified, or if it is archived. The ATTRIB command is used to manage these file attributes.

Wildcard characters may be used in the ATTRIB **filespec**.

The ATTRIB command will modify file attributes if modify commands are given to ATTRIB. The modify commands are:

Command	Description
+/-	Add(+) or remove(-) attribute
A	Archive attribute
C	Clear all attributes
H	Hidden file attribute
R	Read only attribute
S	System file attribute

If no modify commands are found by ATTRIB, then the files are displayed along with the file names and their current attributes.

Examples

ATTRIB will add the read-only attribute to the file myfile.dat.

```
ATTRIB +r myfile.dat
```

ATTRIB will remove the read-only attribute and the archive attribute for all files with the DAT extension.

```
ATTRIB -a -r *.dat
```

ATTRIB will display the attributes of all files with the DAT extension.

```
ATTRIB *.dat
```

BUFFERS

Type

config.sys

Purpose

ROM-DOS has internal buffers to temporarily hold data read from the disk. Increasing the number of internal buffers will speed system performance.

Syntax

```
BUFFERS = number
```

Remarks

Each buffer used by ROM-DOS requires 512 bytes of RAM. The BUFFERS command will increase or decrease the amount of RAM used by the operating system.

The minimum number of buffers is 2 and the maximum number is 40. If a number less than 2 is given then the number of BUFFERS is set to 2. If a number larger than 40 is given then BUFFERS is set to 40.

Example

The following example causes ROM-DOS to have 10 buffers. These 10 buffers will use 5120 bytes of RAM.

```
BUFFERS = 10
```

CHKDSK.EXE

Type

External

Purpose

The CHKDSK command checks the disk directories and File Allocation Table (FAT) and displays a disk and memory report.

Syntax

```
CHKDSK [d:][path][filespec][/C] [/F] [/V]
```

Remarks

CHKDSK examines a disk and determines if the disk has any errors in the File Allocation Table (FAT) and will optionally fix errors.

Options

The /F option causes CHKDSK to fix errors on the disk if any were found. The errors that can be found are directory or FAT errors. If the /F is not specified then CHKDSK acts as if it will fix the disk, but the corrections will not be written out to the disk.

If errors are detected, you will be prompted with a message similar to the following:

```
15 lost allocation units found in 5 chains.
Convert lost chains to files?
```

If you answer Y for Yes, each lost chain will be written to a file in the root directory of the current default drive. Each file will have the name file*nnnn*.chk. *nnnn* will be a sequential number. The first chain will be in FILE000.CHK. These files can be verified to see if they contain valuable information, and then deleted if desired. Answering N for No to the above prompt, CHKDSK will still make the corrections however the lost chains will not be saved to the disk.

The /C option allows CHKDSK to correct errors without user confirmation. This option must be used along with the /F option for corrections to be made.

The /V option causes CHKDSK to display each path and file as it is processed.

If a file specification is specified, then CHKDSK displays all files matching the specification that have noncontiguous data areas on the disk. Files that are stored in noncontiguous areas, especially .exe files,

have slower disk access times. If CHKDSK reports a large number of files with this problem, a utility program that optimizes the files and free space on your disk should be used.

After checking the disk, CHKDSK displays any error messages followed by a report on the state of the disk that was checked. An example of the report is shown below.

```
Volume ROM-DOS created June 1,1990 1:00a
Volume Serial Number is 190E-4AA2
      362496 bytes total disk space
      0 bytes in 1 hidden files
      6144 bytes in 2 user files
      356352 bytes available on disk
      655360 bytes total memory
      595360 bytes free
```

CHKDSK does not wait for a disk to be inserted before the checking is initiated nor does it repair any errors.

Examples

CHKDSK will check the integrity of drive A. The report will be printed to the console.

```
CHKDSK a:
```

CHKDSK will check the integrity of RAM disk D. The report will be saved in a file called DRIVE_D.RPT.

```
CHKDSK d: >drive_d.rpt
```

COMMAND.COM

Type

External

Purpose

Start a new command processor.

Syntax

```
COMMAND [device] [/E:number] [/K:filename]
        [/P] [/C string] [/MSG]
```

Remarks

This command starts a new copy of the ROM-DOS command processor. The command processor is the program that has all the internal DOS commands in it.

Starting a new command processor will also produce a new environment. The size of the environment is 128 bytes by default, but it can be changed using the /E switch.

Command and its arguments can also be used in a SHELL= statement in your config.sys file. See the full description of SHELL for more details.

Options

The *device* option specifies that COMMAND.COM should use a different device, such as AUX, for input and output.

The /E:number switch sets the environment size. Number represents the size of the environment in bytes. Number must be in the range from 160 to 32768. All other values will be ignored and the default value of 256 will be used. ROM-DOS will round the value entered up to the nearest multiple of 16.

The /K:filename option tells the command processor to run the specified filename and then display the ROM-DOS command prompt. It is not recommended that this option be used in a CONFIG.SYS SHELL= statement.

The /P switch causes COMMAND not to exit, or in other words, to remain permanent. The /P switch should be used only when command is used in a CONFIG.SYS SHELL statement.

The /c string switch causes COMMAND to execute the command in string and then terminate. The string command can be any internal or external command.

The /MSG option indicates that all error messages should be stored in memory. This option is recommended only for diskette based systems. ROM-DOS keeps many of its error messages in the resident part of COMMAND.COM rather than using valuable memory to store them. If an error message is needed and you have loaded ROM-DOS from a diskette, the message will only be available if the boot disk is still in the drive. By using the /MSG option, the messages will be available in memory at all times. The /P option must be used along with the /MSG option.

Examples

The following command will cause a new copy of COMMAND to be executed. It will perform a DIR command on the C drive and then exit back to the previous Command Processor.

```
COMMAND /C DIR C:
```

The following example shows loading of a permanent copy of command with an environment size of 256 bytes.

```
SHELL=C:\COMMAND.COM /P /E:256
```

DIR

Type

Internal

Purpose

Displays a list of the files that are in a directory.

Syntax

```
DIR [d:][path][filename][/option]
```

Remarks

The DIR command can be used to list all the files in a directory, or to show the directory entries of specific files. The standard directory display format includes columns for filenames, filename extensions, file sizes, and the dates and times the files were created.

Options

/A *attributes*

The /A option causes the DIR command to display only the files that match the specified filespec and have the given attribute. The table below shows the legal attribute descriptions.

Letter	Description
A	Archive
D	Directories
H	Hidden files
R	Read-only files
S	System files
X	Show attributes

-

The dash (-) symbol can be used to negate listed attributes. For example, to select all files that do not have the archive bit set, use the /A -A option.

/B

The /B, or bare, option causes the display to be displayed without volume label, date, time, or size information.

/L

The /L option causes the filenames to be displayed in lowercase.

/P

The /P option selects page mode, which makes ROM-DOS pause the display each time the screen is full. Press any key to go on to the next page of entries.

/O *attributes*

The /O option causes the filenames to be displayed in sorted order. The sort order can contain one or more of the following letters:

Letter	Description
D	By date and time, newest first
E	Alphabetic order by extension
G	Directories grouped before files
N	Alphabetic order by name
S	Size, smallest first

-

The dash (-) symbol can precede the sort option to reverse the sort order. For example, to sort all files in the directory in reverse alphabetic order, use the /O-N option.

/S

The /S option causes the display to include files in subdirectories also.

/W

Display list in a wide format without date, time, or size.

The DIRCMD environment variable can be used to set the default preferences for the DIR command. The SET command will assign the values to an environment variable. Refer to the SET command section for proper usage. For example, if you wanted to always have the /P option set for DIR, the statement SET DIRCMD=/P could be used. The default settings in DIRCMD can be overridden by using the minus sign (-) preceding the option. If you wanted to cancel the paging for a single use of the DIR command, you would enter DIR /-P.

Examples

To see the directory entries of all files in the current drive and directory, type:

```
DIR
```

To see all files in the subdirectory MEMOS on drive **B**, type:

```
DIR B:\MEMOS
```

Display all files sorted by file name order.

```
DIR /ON
```

Display all hidden files.

```
DIR /AH
```

Display all files with a .doc extension, without file sizes, or volume labels.

```
DIR *.DOC /B
```

FCBS

Type

CONFIG.SYS

Purpose

The FCBS command allows you to specify the number of file control blocks (FCBs) open at one time.

Syntax

```
FCBS = number[,minimum number]
```

Remarks

Number specifies the maximum number of FCBs open at any given time. The default for this value is 4. The value for *number* must be in the range from 1 to 255. The minimum number specifies the minimum number of FCBs to be open at all times. The *minimum number* argument has the same default and range value as the number argument.

Example

Set the maximum number of FCBs to 8 and leave at least 4 open at all times.

```
FCBS = 8,4
```

FIND.EXE

Type
External

Purpose
FIND is a filter to display only lines that contain a specified string.

The input to FIND may come from a file, or it may be piped in from another filter or a DOS command.

Syntax
```
FIND [/option] match-string [filename]
```

Options
The /C option causes FIND to only display the count of lines found with the specified string.

The /N option causes FIND to display the line number of the line found containing the string.

The /V option causes FIND to display the lines that do not contain the string.

The match-string argument specifies the word or group of characters to search for.

The filename argument specifies the file or group of files to search in. The complete drive and path can be specified. Wildcard characters can be used in the filename.

Examples
The following example shows each line in the file JUNK.C that contains the string “printf”.

```
FIND printf junk.c
```

The following example shows each line in a directory listing that contains a DIR. The command first executes a DOS DIR command with the output piped into the FIND command. The FIND command then displays each line that contains the string “DIR”.

```
dir ¦ FIND DIR
```

The following example give a count of the lines in the file MANUAL.TXT that contain the string “ROM-DOS”.

```
FIND /C ROM-DOS MANUAL.TXT

.....MANUAL.TXT: 105
```

HELP.COM

Type

Internal

Purpose

Provides on-line help of each ROM-DOS command.

Syntax

```
HELP <command>
```

Remarks

HELP serves as a memory aid. HELP for each command can also be displayed by entering /? following the command name.

The file COMMAND.HLP must be available to use this command.

Examples

To list the help of the DIR command you can type:

```
HELP DIR
```

or

```
DIR /?
```

All available batch file commands are also listed by HELP.

NEWFILE

Type
CONFIG.SYS

Purpose
The NEWFILE command allows you to continue CONFIG.SYS file processing from a new file. The file can be located in another directory or even on a different drive.

Syntax
```
NEWFILE=filename
```

Remarks
The NEWFILE command is especially useful when the CONFIG.SYS file is located on an inaccessible drive or in ROM. Additional device drivers or instructions can be added easily to the new file and will be processed along with the main CONFIG.SYS file upon starting the system.

When the NEWFILE= instruction is processed, control will be passed from the present file (the one containing the NEWFILE instruction) to the file specified in the command. Any commands placed after the NEWFILE instruction in the original file will not be processed. If for some reason the specified file name cannot be located, CONFIG.SYS processing will be terminated (even if instructions were to be placed after the NEWFILE command) and the remainder of the startup process will be completed.

NEWFILE commands can be nested. That is, your original CONFIG.SYS can call a second set of instructions via the NEWFILE command. The second file can in turn call a third file by using the NEWFILE command, and so on. Be sure that each filename in the successive steps has a unique name, otherwise, an infinite loop will be created as control is passed back to the same file repeatedly.

Each filename given in a NEWFILE command line will have an environment variable of the same name.

Example
The following example will cause instructions in the file NEWCFG.SYS, located in the C:\BIN directory, to be executed as part of the CONFIG.SYS file. The contents of NEWCFG.SYS may include any of the commands listed in this section.

```
NEWFILE=C:\BIN\NEWCFG.SYS
```

PRINT.EXE

Type

External

Purpose

The PRINT utility prints a single file or a list of files.

Syntax

```
PRINT [/d:] [filename] [/options]
```

Remarks

PRINT allows you to enter between 1 and 32 files for spooling to the printer. The files are output to the device in a spooled manner (while the user performs other operations).

If PRINT is entered without any parameters, then it displays all the files that are in the queue.

The first time PRINT is used the operator is prompted for the device to perform the operation. The following message is used to prompt the operator for the device.

```
Name of list device [PRN]:
```

The legal devices for printing are LPT1, LPT2, LPT3, LPT4, COM1, COM2, COM3, COM4, AUX, or PRN.

Options

The /B option allows the user to set the buffer size. The default buffer size is 512 bytes. A larger buffer size causes print to operate faster. The maximum buffer size is 32k bytes and the minimum size 256 bytes. This option is only allowed the first time PRINT is run.

The /C option cancels only the file names listed after the /C command.

The /F option allows the user to set the maximum number of files to be queued up at one time. The default number of files is 10. The minimum is 2 and the maximum is 32. Support for more files is often useful when using wild cards in file names. This option is only allowed the first time PRINT is run (or until the next system reboot).

The /P option causes all files listed after this option to be submitted for printing. This is the default for filenames encountered on the PRINT command line.

The /T option cancels all the files from the print queue (list). Think of this as a terminator.

The /H option will display the help screen.

Examples

PRINT puts three files into the print queue. The first file will start being printed after the command ends.

```
PRINT FILE1.TXT FILE2.TXT FILE3.TXT
```

The file FILE2.TXT will be removed from the print queue. All other files in the queue will print normally.

```
PRINT /C FILE2.TXT
```

All files in the print queue are canceled. Printing may continue for a short time because of the buffer in your printer.

```
PRINT /T
```

SHARE.EXE

Type

External

Purpose

SHARE installs the capabilities for file-sharing and file-locking on your hard disk.

Syntax

```
SHARE [/options]
```

Or from CONFIG.SYS:

```
INSTALL=[d:][path]SHARE.EXE [/options]
```

Remarks

The SHARE utility is most commonly used in a network or multitasking environment where file sharing is necessary. When SHARE is loaded, DOS will utilize the SHARE utility to validate read and write requests from application programs and users.

The /L:# option specifies the maximum number of files that can be locked at one time. The default number of files is 20.

The /U option unloads the share utility and frees the memory. SHARE will not unload if other TSRs have been loaded on top of it. The other TSRs must be unloaded first before trying to unload SHARE.

Examples

The following example loads the SHARE program from the command line:

```
SHARE
```

The next example installs SHARE from the CONFIG.SYS file and changes the maximum number of locked files to 30:

```
INSTALL=C:\UTILS\SHARE.EXE /l:30
```

The final example unloads SHARE and frees the used memory.

```
SHARE /U
```

SWITCHES

Type

CONFIG.SYS

Purpose

The SWITCHES command allows special CONFIG.SYS file options.

Syntax

```
SWITCHES=[/k] [/n] [/f]
```

Remarks

The /k argument makes an enhanced keyboard behave like a conventional-style keyboard.

The /n argument prevents the use of the `F5` and `F8` function keys to bypass the startup commands.

The /f argument instructs ROM-DOS to skip the delay after displaying the `Starting ROM-DOS...` message at boot time. The delay allows the user time to use the F5 and F8 options to alter the processing of the startup files.

Examples

The following example prevents the user from using the `F5` and `F8` keys at boot time.

```
switches = /n
```

TREE.COM

Type

External

Purpose

The TREE command displays each subdirectory and optionally the files within them for a specified drive.

Syntax

```
TREE [d:] [/F]
```

Remarks

The TREE command displays the full path of each subdirectory on a specified disk.

The *d:* specifies the drive that TREE will display the subdirectories from. This argument must be specified.

Options

The /F switch causes TREE to display the files in each subdirectory.

Examples

This command will display all subdirectories on drive **C**.

```
C:\DATA> TREE C:
```

This command will display all subdirectories on drive **A** along with the files within each subdirectory.

```
C:\DATA> TREE A: /F
```

VER

Type

Internal

Purpose

Displays the version number of ROM-DOS in use. Allows revision of this version number.

Syntax

```
VER [n.nn] [/R]
```

Remarks

If a new version number is specified, two digits after the decimal are required. Note that this command revises only the record of the DOS version number; it does not change the actual operating system loaded in the computer.

The version command shows both the version of the VER command itself and the version of DOS in operation.

Options

The /R option shows the full version and release number of ROM-DOS.

Example

The following example changes the record of current DOS version in use to DOS 5.0. Any programs that are executed, following this command, will recognize that DOS 5.0 is running.

```
VER 5.0
```

XCOPY.EXE

Type

External

Purpose

The XCOPY command copies multiple files and, optionally, subdirectories from one disk to another.

Syntax

```
XCOPY [source] [target] [/options]
```

Remarks

The XCOPY command is used for copying multiple files and subdirectories, if they exist.

The *source* and the *target* parameter are complete drive path and file specification descriptions. If you do not specify a path, XCOPY assumes the default path. If a file name is not specified then *.* is assumed.

The ATTRIB command may be used to modify the archive bit for the various XCOPY options that check the archive status of files. Refer to the ATTRIB command description for instructions.

Options

The /A copies only source files that have the archive bit set in them. The archive is not reset.

The /D<*mm-dd-yy*> option causes XCOPY to copy only those files with a date later than the date specified in the /D option.

The /E option causes XCOPY to create subdirectories on the target even if they are empty.

The /M option causes XCOPY to copy only those source files that have the archive bit set. Once the source file is copied the archive bit is reset.

The /P option causes XCOPY to prompt before each file is copied. The prompt appears as follows:

```
C:\COMMAND.COM (Y/N)?
```

If a Y is entered then the file is copied, otherwise, the file is not copied.

The /S option causes XCOPY to copy files in subdirectories of the source directory.

The /V option causes XCOPY to verify each write to the disk.

The /W option causes XCOPY to wait before starting to copy files. The following prompt is displayed.

```
Press any key to begin copying file(s)
```

Example

XCOPY to the A drive all files in the BIN subdirectory that have an EXE extension and that have the archive bit set.

```
XCOPY \bin\*.exe a: /a
```

XDEL

Type

External

Purpose

The XDEL command deletes files and subdirectories including empty subdirectories.

Syntax

```
XDEL filespec [/options]
```

Remarks

The XDEL command allows the deletion of files and subdirectories in the same step.

The filespec argument is the starting point for the deletion. The filespec argument can contain the drive and path for reaching the starting point and can also contain wild card characters to designate a group of file or directory names.

Options

The /D option deletes empty subdirectories. Deletion will not occur if there are any files in the subdirectory, unless the /S option is specified along with the /D option.

The /P option gives you a confirmation prompt before deleting each file.

The /R option allows deletion of read-only files without having to change the file attributes prior to the delete.

The /S option deletes files in subdirectories located below the specified starting directory. When used along with the /D option, it will delete the files within a subdirectory along with the subdirectory entry itself.

Examples

The following examples will all use the diagram below as a reference:

```
DIR1
    SUB1
        sub1file.txt
    SUB2
        sub2file.txt
    SUB3
dir1file1.txt
dir1file2.txt
```

The following XDEL command would delete all of the files in the directories DIR1, SUB1, and SUB2 but not the directory headings themselves.

```
XDEL DIR1 /s
```

To delete the empty subdirectory heading for SUB3, use XDEL as follows:

```
XDEL DIR1 /d
```

To delete all of the files in the three directories and the directory headings at the same time, use the following command:

```
XDEL DIR1 /s /d
```

Table of Contents

CHAPTER 7 THE DOCKING STATION 7-1

Introduction **7-1**

The Single Dock **7-2**

- **Attaching the Single Dock to a Computer** **7-3**
- **The Power Adapter** **7-4**
- **Using a Single Dock** **7-5**
  - Charging Batteries 7-5
  - Transferring Files with XFER 7-5
- **Technical Specifications** **7-7**
  - Single Dock 7-7
  - Power Supply 7-7

Illustrations

Figure 7-1 Charging/Communication Dock for One MX2 7-2
Figure 7-2 Back Panel of the Single Dock 7-3
Figure 7-3 US Dock Power Adapter 7-4

Chapter 7
The Docking Station

Introduction

LXE offers one docking station for the MX2 – a stationary single dock that holds one MX2. The stationary single dock powered docking station has two primary uses:

- Recharge the MX2 NiMH battery pack and lithium backup batteries.
- Provide a connection for serial communications between the MX2 and the host computer or another serial device, such as a printer or modem.

The powered docking station requires an AC/DC power source.

Note: Do not use the MX2 docking station with any other unit.

Note: The MX2 is not designed to use alkaline batteries.

Please refer to the "MX2 Installation and Operator's Guide" (LXE DocID MX2A136OPGDWW) when using the MX2 with a Docking Station.

Please refer to the "MX2 Docking Station Operator's Guide" (LXE DocID MX2A137OPGDWW) when using a Docking Station.

The Single Dock

A cable and power adapter for the Single Dock are available separately. To make your own cables, see Appendix A for pin assignments.



Figure 7-1 Charging/Communication Dock for One MX2

1	Serial 25-pin Connector
2	Power Input Jack
3	MX2 Receptacle
4	Battery Charging / Communication Pads
5	Infrared Window
6	Power Indicator
7	Ready Indicator

Attaching the Single Dock to a Computer

Complete the following steps:

1. Attach the 25-pin end of the cable to the cable connector on the back of the Single Dock.
2. Attach the other end of the cable to a serial port on your computer.
3. If you ordered the optional power adapter, attach it to Power Input Jack on the Single Dock .



Figure 7-2 Back Panel of the Single Dock

1 Power input jack

2 Cable connector

See Appendix A "Connector Configurations" for pin assignments.

The Power Adapter

Important: ***The MX2 is not designed to use alkaline or non-rechargeable batteries.***



Figure 7-3 US Dock Power Adapter

You can use a 9-volt power adapter with the Single Dock to recharge the batteries in the MX2. Power adapters are available from LXE.

Attach the small, round plug of the power adapter to the power input jack on the back of the Single Dock. Plug the other end into an AC outlet or power strip. The red light-emitting diode (LED) labeled POWER on the front panel of the Single Dock should light up.

The power adapter is used only to recharge the batteries in the MX2. However, if you do not use it, the LED indicators on the Single Dock will not light up. (The READY light indicates that the MX2 is properly inserted in the dock. The READY light will appear red when charging MX2 batteries and green when batteries are fully charged.)

Note: *Use only a 9-volt power adapter supplied by LXE. Using another adapter can damage the dock.*

Using a Single Dock

Set up the Single Dock as described in the preceding sections. Place the MX2 into the dock, with the keypad facing the front. If you are using a power adapter, the green LED labeled READY on the front panel of the Single Dock should light up.

Note: If the READY light does not come on, make sure the POWER light is on and the MX2 is fully inserted into the dock, with the keypad facing out. If it still doesn't work, make sure the power adapter is securely attached to the MX2 and that the contacts in the dock are clean. (If you are not using a power adapter, the light will not come on.)

While the MX2 is in the Single Dock, you can download programs to it or upload data from it just as if it were connected directly to your computer.

If you are using a nickel metal hydride (NiMH) battery pack in the MX2, you can use the Single Dock to recharge the batteries. Simply leave the battery pack in the MX2 when you place it in the dock. The battery pack and the lithium backup battery will be recharged while the READY light is on. The charging time is 3 to 8 hours, depending on the type of battery pack and the current charging level.

Charging Batteries

To charge the rechargeable batteries in a MX2, place the MX2 into a dock that is connected to a power supply. The dock does not need to be connected to a computer.

Transferring Files with XFER

You can transfer files with the XFER utility on the MX2. XFER has the ability to automatically request access to the communications line from the Single Dock.

To use XFER to transfer a file to the MX2, place the MX2 in the Dock. On the MX2, type in the command to receive a file, which is typically the following:

```
C:\> xfer /r filename.txt
```

On the host, type the following at a DOS prompt:

```
C:\> xfer filename.txt
```

When you execute the XFER command on the host, XFER will transfer the file from the host to the MX2.

Note: Xmodem uses no flow control, by default. For Zmodem, the default flow control is RTS/CTS. To use XFER with Zmodem with the Dock, hardware flow control must be turned off using the appropriate XFER command line switch, and XON/XOFF flow control should be used instead. This holds true for any communications software on a MX2 using the Dock.

See Chapter 4 “Configuration Utility” or Chapter 5 “Using XFER.”

Technical Specifications

Single Dock

Parameter	Specification
Height	2.75” (6.9 cm)
Depth	6” (15 cm)
Width	5.25” (13.33 cm)
Weight	1.15 lbs (.52 kilograms)
Usage	Indoors

Power Supply

Parameter	Specification
Transformer	Class 2
Input	120V 60Hz 12W
Output	9VDC 500mA
Usage	Indoors

Table of Contents

APPENDIX A CONNECTOR CONFIGURATIONS A-1

Introduction A-1

The MX2 Computer A-1

Serial IR Port A-1

Single Dock A-2

25-Pin Connector A-2

Illustrations

Figure A-1 Serial IR Port A-1
Figure A-2 Docking Pads – Right, Center, Left A-1
Figure A-3 The Cable Connector for the Single Dock A-2

Appendix A
Connector
Configurations

Appendix A
Connector Configurations

Introduction

Cables for all MX2 products are available from LXE. However, you may want to make your own cables for custom uses. This appendix provides information about MX2 cables, including diagrams and tables describing the connector configurations for the MX2 and the Single Dock.

The MX2 Computer

Serial IR Port

The IR port provides an IR transceiver for sending and receiving half-duplex IR data that meets the IrDA physical layer specifications.

In addition, thee are three pads along the bottom of the unit. The pads are used when the MX2 is in the dock. With the MX2 oriented with it's keypad facing toward the user:

The right-most pad is the positive lead and is used for recharging the MX2 batteries.

The center pad is the negative lead and is used for recharging the MX2 batteries.

The left-most pad is used for modified RS-232 input into the MX2. This pin serves as RXD while the MX2 is in the dock.



Figure A-1 Serial IR Port



Figure A-2 Docking Pads – Right, Center, Left

Single Dock

The back panel of the Single Dock has a 25-pin dock-to-host cable connector.



Figure A-3 The Cable Connector for the Single Dock

25-Pin Connector

Pin #	Signal	Connected To Pin
1	Frame GND	
2	Portable TXD	
3	Portable RXD	
4	RTS	8
5	CTS	8
6	DSR	22
7	GND	
8	DCD	4, 5
9–19	Unconnected	
20	DTR	6
21	Unconnected	
22	Ring in	20, 6
23–25	Unconnected	

Table of Contents

APPENDIX B PROGRAMMING PARAMETERS B-1

Introduction B-1

Parameters, Settings, and Defaults B-2

Code 39 ..... B-2
Interleaved 2 of 5 ..... B-3
Matrix 2 of 5 ..... B-3
Standard 2 of 5 ..... B-4
Code 11 ..... B-4
Codabar/Ames B-5
MSI B-5
Code 93 ..... B-6
Universal Product Code-A (UPC-A) B-6
Universal Product Code-E (UPC-E) B-7
European Article Numbering (EAN) Japan Article Numbering (JAN) B-7
UPC, EAN, JAN Extensions B-8
Code 128 ..... B-8
Labelcode 4/5 ..... B-8
Other Controls B-9

Appendix B
Programming Parameters

Introduction

This appendix contains information about programmable settings for the MX2. You can use the Configuration Utility or the barcodes provided in appendix C to program your MX2. Also included in this chapter are listings of files installed on the unit when using LXE's terminal emulation programs.

The "Parameters, Settings, and Defaults" table (see next page) provides the following information:

- **Code Parameter** is the "human" name for the programming option.
- **I.D. #** is the "decoder" name for the programming option. For example, if you wanted to set a Code 39 minimum label length, you would use I.D. #**01**. Programming I.D. numbers given in this appendix can be used with all programming methods.
- **Type** tells what kind of setting to use for each code parameter.

  On/Off is a toggle. **1** turns the parameter on, and **0** turns it off.

  Value requires a two-character entry (e.g., **02** for two beeps after each good read).
- **Acceptable Input** gives the settings or range of settings that you can use for each code parameter.
- **Defaults** tells how the parameter is set when you select predefined default **D0**, **D1**, or **D2**.

  Predefined Default 0 (D0) turns every on/off parameter off and sets all minimum and maximum lengths to the lowest values.

  Predefined Default 1 (D1) turns every on/off parameter on, sets all minimum lengths to the lowest values, and sets all maximum lengths to the highest values. This default set is normally used only for troubleshooting. It gives you the best chance of reading an unknown barcode symbology

and also identifies the symbology of each barcode you scan.

Predefined Default 2 (D2) is the default set that was installed in the MX2 at the factory. This default set will work for most applications. If you have changed any settings and want to reset the MX2 to the original defaults, scan the **D2** barcode in Appendix C.

Parameters, Settings, and Defaults

Enter 1 for On and 0 for Off.

Code 39

Code Parameters	I.D. #	Type	Acceptable Input	Defaults		
				D0	D1	D2
Enable	00	On/Off	On *or* Off	Off	On	On
Minimum length	01	Value	00–50	00	00	00
Maximum length	02	Value	01–50	01	50	20
Enable checksum	03	On/Off	On *or* Off	Off	Off	Off
Send checksum	04	On/Off	On *or* Off	Off	Off	Off
Full ASCII mode	05	On/Off	On *or* Off	Off	On	On

Interleaved 2 of 5

Enter 1 for On and 0 for Off.

Code Parameters	I.D. #	Type	Acceptable Input	Defaults		
				D0	D1	D2
Enable	08	On/Off	On *or* Off	Off	On	On
Minimum length	09	Value	02 - 50	02	02	06
Maximum length	0A	Value	02 - 50	02	50	10
Enable checksum	0B	On/Off	On *or* Off	Off	Off	Off
Send checksum	0C	On/Off	On *or* Off	Off	Off	Off
Use lengths 6 and 14 only *(case code)*	0D	On/Off	On *or* Off	Off	Off	Off

Matrix 2 of 5

Enter 1 for On and 0 for Off.

Code Parameters	I.D. #	Type	Acceptable Input	Defaults		
				D0	D1	D2
Enable	10	On/Off	On *or* Off	Off	On	Off
Minimum length	11	Value	01 - 50	01	01	06
Maximum length	12	Value	01 - 50	1	50	10
Enable checksum	13	On/Off	On *or* Off	Off	Off	Off
Send checksum	14	On/Off	On *or* Off	Off	Off	Off

Standard 2 of 5

Enter 1 for On and 0 for Off.

Code Parameters	I.D. #	Type	Acceptable Input	Defaults		
				D0	D1	D2
Enable	15	On/Off	On *or* Off	Off	On	Off
Minimum length	16	Value	01 - 50	01	01	06
Maximum length	17	Value	01 - 50	01	50	10
Enable checksum	18	On/Off	On *or* Off	Off	Off	Off
Send checksum	19	On/Off	On *or* Off	Off	Off	Off
Use 2-bar start/stop	1A	On/Off	On *or* Off	Off	Off	Off

Code 11

Enter 1 for On and 0 for Off.

Code Parameters	I.D. #	Type	Acceptable Input	Defaults		
				D0	D1	D2
Enable	1B	On/Off	On *or* Off	Off	On	Off
Minimum length	1C	Value	01 - 50	01	01	04
Maximum length	1D	Value	01 - 50	01	50	10
Require 2 check digits	1E	On/Off	On *or* Off	Off	Off	Off
Send check digit(s)	1F	On/Off	On *or* Off	Off	On	Off

Codabar/Ames

Enter 1 for On and 0 for Off.

Code Parameters	I.D. #	Type	Acceptable Input	Defaults		
				D0	D1	D2
Ames Enable	51	On/Off	On *or* Off	Off	On	Off
Codabar Enable	20	On/Off	On *or* Off	Off	On	On
Minimum length	21	Value	01 - 50	01	01	04
Maximum length	22	Value	01 - 50	01	50	20
Send start/stop	23	On/Off	On *or* Off	Off	On	Off
Codabar-to-CLSI conversion	24	On/Off	On *or* Off	Off	Off	Off
Wide intercharacter gaps allowed	25	On/Off	On *or* Off	Off	Off	On

MSI

Enter 1 for On and 0 for Off.

Code Parameters	I.D. #	Type	Acceptable Input	Defaults		
				D0	D1	D2
Enable	26	On/Off	On *or* Off	Off	On	Off
Minimum length	27	Value	01 - 14	01	01	04
Maximum length	28	Value	01 - 14	01	14	10
Require 2 check digits	29	On/Off	On *or* Off	Off	Off	Off
2nd check digit Mod 11	2A	On/Off	On *or* Off	Off	Off	Off

Code Parameters	I.D. #	Type	Acceptable Input	Defaults		
				D0	D1	D2
Send check digit(s)	2B	On/Off	On *or* Off	Off	On	Off

Code 93

Enter 1 for On and 0 for Off.

Code Parameters	I.D. #	Type	Acceptable Input	Defaults		
				D0	D1	D2
Enable	2C	On/Off	On *or* Off	Off	On	Off
Minimum length	2D	Value	00 - 50	00	01	02
Maximum length	2E	Value	01 - 50	00	50	20

Universal Product Code-A (UPC-A)

Enter 1 for On and 0 for Off.

Code Parameters	I.D. #	Type	Acceptable Input	Defaults		
				D0	D1	D2
Enable	30	On/Off	On *or* Off	Off	On	On
Send system digit	31	On/Off	On *or* Off	Off	On	On
Send check digit	32	On/Off	On *or* Off	Off	On	Off
Convert UPC-A to EAN13	33	On/Off	On *or* Off	Off	On	Off

Universal Product Code-E (UPC-E)

Enter 1 for On and 0 for Off.

Code Parameters	I.D. #	Type	Acceptable Input	Defaults		
				D0	D1	D2
Use system digit 0	34	On/Off	On *or* Off	Off	On	On
Use system digit 1	35	On/Off	On *or* Off	Off	On	On
Convert UPCE to UPCA	36	On/Off	On *or* Off	Off	On	Off
Send system digit	37	On/Off	On *or* Off	Off	On	Off
Send check digit	38	On/Off	On *or* Off	Off	On	Off

European Article Numbering (EAN) Japan Article Numbering (JAN)

Enter 1 for On and 0 for Off.

Code Parameters	I.D. #	Type	Acceptable Input	Defaults		
				D0	D1	D2
Enable EAN-8/JAN-8	39	On/Off	On *or* Off	Off	On	On
Enable EAN-13/JAN-13	3A	On/Off	On *or* Off	Off	On	On
Convert EAN-13 to ISBN	3B	On/Off	On *or* Off	Off	Off	Off
Send EAN/JAN checksum	3F	On/Off	On *or* Off	Off	Off	Off

UPC, EAN, JAN Extensions

Enter 1 for On and 0 for Off.

Code Parameters	I.D. #	Type	Acceptable Input	Defaults		
				D0	D1	D2
Allow 2-digit extensions	3C	On/Off	On *or* Off	Off	On	On
Allow 5-digit extensions	3D	On/Off	On *or* Off	Off	On	On
Require extensions	3E	On/Off	On *or* Off	Off	Off	Off

Code 128

Enter 1 for On and 0 for Off.

Code Parameters	I.D. #	Type	Acceptable Input	Defaults		
				D0	D1	D2
Enable	40	On/Off	On *or* Off	Off	On	On
Minimum length	41	Value	01 - 50	01	01	02
Maximum length	42	Value	01 - 50	01	50	20
Enable UCC/EAN 128	43	On/Off	On *or* Off	Off	Off	Off

Labelcode 4/5

Enter 1 for On and 0 for Off.

Code Parameters	I.D. #	Type	Acceptable Input	Defaults		
				D0	D1	D2
Enable	52	On/Off	On *or* Off	Off	On	Off
Convert	53	On/Off	On *or* Off	Off	Off	Off

Other Controls

Enter 1 for On and 0 for Off.

Code Parameters	I.D. #	Type	Acceptable Input	Defaults		
				D0	D1	D2
Laser programming enable	B0	On/Off	On *or* Off	On	On	On
Autoterminator	B1	Value	*Any single ASCII character (00=Off)*	(CR)	(CR)	(CR)
Auto-off timer	B2	Value	01 - 99 *(in 4-sec. increments) (00 = Off)*	75	75	75
Send assigned symbology identifiers*	B5	On/Off	On *or* Off	Off	On	Off
* *A = UPC-A* *B = I 2 of 5* *C = Code 39* *D = M 2 of 5* *E = UPCE* *F = S 2 of 5* *G = EAN-8* *H = MSI* *I = Codabar* *J = Code 11* *K = Code 128* *L = Code 93* *M = EAN-13* *N = Labelcode 4/5* *O = Ames*						
Good-read beep tone	B8	Value	00 = 2400 Hz 01 = 2600 Hz 02 = 2800 Hz 03 = 3000 Hz 04 = 3200 Hz 05 = 3400 Hz 06 = 3600 Hz 07 = 3800 Hz	00	00	00
Number of good-read beeps	B9	Value	01 - 04	01	01	01
Good-read beep duration	BA	Value	00 = 0.07 sec. 01 = 0.13 sec. 02 = 0.18 sec. 03 = 0.36 sec.	00	00	00

Code Parameters	I.D. #	Type	Acceptable Input	Defaults		
				D0	D1	D2
Beeper volume	BC	Value	00 = Off 01 - 09 *(01 = Lowest;* *07 = Highest;* *08 = Higher;* *09 = Lower)*	07	07	07
Error beep tone	BD	Value	00 = 2400 Hz 01 = 2580 Hz 02 = 2770 Hz 03 = 3000 Hz 04 = 3270 Hz 05 = 3600 Hz 06 = 4000 Hz 07 = 4520 Hz	01	01	01
Long-range trigger mode	D4[1]	On/Off	On = Release Scan Off = Spot Timeout	Off	Off	Off
Spot beam timeout	D5[1]	Value	00 = 0.25 sec. 01 = 0.50 sec. 02 = 1.00 sec. 03 = 1.50 sec. 04 = 2.00 sec.	01	01	01
Release scan timeout	D6[1]	Value	01 - 30 *(seconds)*	02	02	02
Spotting Beam Enable	D7	On/Off	On *or* Off	On	On	On
Keypress sound	DD	Value	00 = Off 01 = Click 02 = Beep	01	01	01
Enable CTL-ALT-DEL reboot	E0	On/Off	On *or* Off	Off	Off	On
Enable trigger programmability	E1[2]	On/Off	On *or* Off	On	On	On
Backlight auto-off timeout	E2	Value	01 - 99 *(seconds)* *(00 = Off)*	15	15	15

[1] Long Range Scanner models only.
[2] This parameter affects MX2 Enter key programmability.

Code Parameters	I.D. #	Type	Acceptable Input	Defaults		
				D0	D1	D2
Double Action Key Mode	E3	Value	01 = Double Strike 02 = Press and Wait	01	01	01
Double Action Key Timeout	E4	Value	00 = 165 01 = 220 02 = 275 03 = 330 04 = 385 05 = 440 06 = 495 07 = 550 08 = 605 09 = 660	03	03	03

Table of Contents

APPENDIX C BARCODES FOR CONFIGURING MX2 C-1

Introduction C-1

Default Settings C-2

Barcodes C-5

Predefined Defaults C-5

D2 ..... C-5

Code 39 ..... C-5

Enable - On C-5
Minimum Length - 0 ..... C-5
Maximum Length - 20 ..... C-6
Enable Checksum - Off C-7
Send Checksum - Off C-7
Full ASCII Mode - On C-7

Interleaved 2 of 5 ..... C-8

Enable - On C-8
Minimum Length - 6 ..... C-8
Maximum Length - 10 ..... C-9
Enable Checksum - Off C-10
Send Checksum - Off C-10
Use Lengths 6 and 14 Only (Case Code) - Off C-10

Matrix 2 of 5 ..... C-11

Enable - Off C-11
Minimum Length - 6 ..... C-11
Maximum Length - 10 ..... C-12
Enable Checksum - Off C-13
Send Checksum - Off C-13

Standard 2 of 5 ..... C-14

Enable - Off C-14
Minimum Length - 6 ..... C-14
Maximum Length - 10 ..... C-15
Enable Checksum - Off C-16
Send Checksum - Off C-16
Use 2-Bar Start/Stop - Off C-16

Code 11 ..... C-17
Enable - Off C-17
Minimum Length - 4 ..... C-17
Maximum Length - 10 ..... C-18
Require 2 Check Digits - Off C-18
Send Check Digit(s) - Off C-19
Codabar/Ames C-20
Codabar Enable - On C-20
Ames Enable - Off C-20
Minimum Length - 4 ..... C-21
Maximum Length - 20 ..... C-21
Send Stop/Start - Off C-22
Codabar-to-CLSI Conversion - Off C-23
Wide Intercharacter Gaps Allowed - On C-23
MSI C-24
Enable - Off C-24
Minimum Length - 4 ..... C-24
Maximum Length - 10 ..... C-25
Require 2 Check Digits - Off C-25
2nd Check Digit Mod 11 - Off C-26
Send Check Digit(s) - Off C-26
Code 93 ..... C-27
Enable - Off C-27
Minimum Length - 2 ..... C-27
Maximum Length - 20 ..... C-28
Code 128 ..... C-29
Enable - On C-29
Minimum Length - 2 ..... C-29
Maximum Length - 20 ..... C-30
Enable UCC/EAN 128 - Off C-31
Labelcode 4/5 ..... C-32
Enable - Off C-32
Convert - Off C-32
UPC-A C-33
Enable UPC-A - On C-33
Send System Digit - On C-33
Send Check Digit - Off C-33
Convert UPC-A to EAN-13 - Off C-34

UPC-E C-35
Use System Digit 0 - On C-35
Use System Digit 1 - On C-35
Convert UPC-E to UPC-A - Off C-35
Send System Digit - Off C-36
Send Check Digit - Off C-36
EAN/JAN C-37
Enable EAN-8/JAN-8 - On C-37
Enable EAN-13/JAN-13 - On C-37
Convert EAN-13 to ISBN - Off C-37
Send EAN/JAN Checksum - Off C-38
UPC/EAN/JAN Extensions C-39
Allow 2-Digit Extensions - On C-39
Allow 5-Digit Extensions - On C-39
Require Extensions - Off C-39
Other Controls C-40
Autoterminator - CR C-40
Auto-Off Timer - 5 min. C-41
Send Symbology Identifier - Off C-42
Good-Read Beep Tone (in Hertz) - 2400 ..... C-42
Number of Good-Read Beeps - 1 ..... C-43
Good-Read Beep Duration (in seconds) - 0.07 ..... C-43
Beeper Volume - Highest C-44
Error Beep Tone (in Hertz) - 2580 ..... C-45
Long-Range Trigger Mode – Off C-46
Spotting Beam Enable – On C-46
Spot Beam Timeout (in seconds) 0.5 ..... C-47
Release Scan Timeout (in seconds) - 2 ..... C-48
Keypress Sound - Click C-49
Enable Ctl-Alt-Del Reboot - On C-49
Enable Trigger Programmability - On C-49
Backlight Auto-Off Timeout (in seconds) - 15 ..... C-50
Double Key Action Mode – Double Press C-51
Double Key Action Timeout – 330 ms C-51

Appendix C
Barcodes for Configuring MX2

Introduction

This appendix provides barcodes for common setup parameters for programming the MX2. Factory default settings are listed in the section titled "Default Settings" and are included *as part of the parameter heading.*

To make settings that aren't provided here, you can use your own barcodes. Using the barcodes contained in this section, you can change any scanning system parameter or reset all parameters to their default values. This chapter contains Code 39 barcode symbols for system setup parameters.

Refer to the MX2 Installation and Operator's Guide (LXE DocID MX2A136OPGDWW) for the section titled "Scanner Warnings and Labels" for important laser safety information **before** using the scanner.

When scanning the barcodes in this section, *remember*:

- Do not look into the laser's lens.
- Do not stare directly into the laser beam.
- Do not remove the laser caution labels from the MX2.

How To

Select the symbol parameter you want to scan. Lay this reference guide flat on a table or propped up.

Holding the scanner approximately 6 - 12 inches away from the symbol, scan the selected symbol.

When the Scan LED illuminates, the parameter has been decoded.

Note: Whether there are beeps in conjunction with scan and decode functions is dependent on the application currently running in the MX2. For example, the ANSI Plus terminal emulator program emits one beep when a barcode is scanned and decoded successfully.

Default Settings

Code 39	
Enable	On
Minimum Length	0
Maximum Length	20
Enable Checksum	Off
Send Checksum	Off
Full ASCII Mode	On

Interleaved 2 of 5	
Enable	On
Minimum Length	6
Maximum Length	10
Enable Checksum	Off
Send Checksum	Off
Use Lengths 6 and 14 Only (Case Code)	Off

Matrix 2 of 5	
Enable	Off
Minimum Length	6
Maximum Length	10
Enable Checksum	Off
Send Checksum	Off

Standard 2 of 5	
Enable	Off
Minimum Length	6
Maximum Length	10
Enable Checksum	Off
Send Checksum	Off
Use 2-Bar Start/Stop	Off

Code 11	
Enable	Off
Minimum Length	4
Maximum Length	10
Require 2 Check Digits	Off
Send Check Digit(s)	Off

Codabar/Ames	
Ames Enable	Off

Enable	On
Minimum Length	4
Maximum Length	20
Send Stop/Start	Off
Codabar-to-CLSI Conversion	Off
Wide Intercharacter Gaps Allowed	On

MSI	
Enable	Off
Minimum Length	4
Maximum Length	10
Require 2 Check Digits	Off
2nd Check Digit Mod 11	Off
Send Check Digit(s)	Off

Code 93	
Enable	Off
Minimum Length	2
Maximum Length	20

Code 128	
Enable	On
Minimum Length	2
Maximum Length	20
Enable UCC/EAN 128	Off

Labelcode 4/5	
Enable	Off
Convert	Off

UPC-A	
Enable UPC-A	On
Send System Digit	On
Send Check Digit	Off
Convert UPC-A to EAN-13	Off

UPC-E	
Use System Digit 0	On
Use System Digit 1	On
Convert UPC-E to UPC-A	Off
Send System Digit	Off
Send Check Digit	Off

EAN/JAN	
Enable EAN-8/JAN-8	On
Enable EAN-13/JAN-13	On
Convert EAN-13 to ISBN	Off
Send EAN/JAN Checksum	Off

UPC/EAN/JAN Extensions	
Allow 2-Digit Extensions	On
Allow 5-Digit Extensions	On
Require Extensions	Off

Other Controls	
Autoterminator	CR
Auto-Off Timer	5 min.
Send Symbology Identifier	Off
Good-Read Beep Tone (in Hertz)	2400
Number of Good-Read Beeps	1
Good-Read Beep Duration (in seconds)	0.07
Beeper Volume	Highest
Error Beep Tone (in Hertz)	2580
*Long-Range Trigger Mode	Off (Spot Timeout)
*Spot Beam Timeout (in seconds)	0.5
*Release Scan Timeout (in seconds)	2
Spotting Beam Enable	On
Keypress Sound	Click
Enable Ctl-Alt-Del Reboot	On
Enable Trigger Programmability[1]	On
Backlight Auto-Off Timeout (in seconds)	15
Double Key Action Mode	Double Strike
Double Key Action Timeout	330

* *(long-range scanner models only)*

[1] This parameter affects MX2 Enter key programmability.

Barcodes

Predefined Defaults

D2

Code 39

Enable - On

On

Off

Minimum Length - 0

0

10

20

30

40

50

Maximum Length - 20

1

10

20

30

40

50

Enable Checksum - Off

On



Off

Send Checksum - Off

On

Off

Full ASCII Mode - On

On

Off

Interleaved 2 of 5

Enable - On

On



Off



Minimum Length - 6

2

6

10

20



30



40

50



Maximum Length - 10

2

10

20

30

40

50

Enable Checksum - Off

On



Off

Send Checksum - Off

On

Off



Use Lengths 6 and 14 Only (Case Code) - Off

On

Off



Matrix 2 of 5

Enable - Off

On



Off



Minimum Length - 6

1

6

10

20

30

40

50



Maximum Length - 10

1

10

20

30

40

50

Enable Checksum - Off

On



Off

Send Checksum - Off

On

Off

Standard 2 of 5

Enable - Off

On



Off



Minimum Length - 6

1

6



10

20



30



40

50



Maximum Length - 10

1

10



20

30

40

50

Enable Checksum - Off

On

Off

Send Checksum - Off

On

Off

Use 2-Bar Start/Stop - Off

On

Off

Code 11

Enable - Off

On

Off

Minimum Length - 4

4

10

20

30

40

50

Maximum Length - 10

1

10

20

30

40

50

Require 2 Check Digits - Off

On

Off

Appendix C Barcodes for Configuring MX2

Send Check Digit(s) - Off

On

Off

Codabar/Ames

Codabar Enable - On

On

Off

Ames Enable - Off

On

Off

Appendix C
Barcodes for
Configuring MX2

Minimum Length - 4

1

4

10

20

30

40

50

Maximum Length - 20

1

10

20

30

40

50

Send Stop/Start - Off

On

Off

Appendix C
Barcodes for
Configuring MX2

Codabar-to-CLSI Conversion - Off

On



Off



Wide Intercharacter Gaps Allowed - On

On

Off

MSI

Enable - Off

On



Off



Minimum Length - 4

1

4

7

10



12

14

Maximum Length - 10

1



4



7



10

12

14



Require 2 Check Digits - Off

On



Off



2nd Check Digit Mod 11 - Off

On

Off

Send Check Digit(s) - Off

On

Off

Code 93

Enable - Off

On



Off



Minimum Length - 2

2

10



20

30



40



50

Maximum Length - 20

2

10

20

30

40

50

Code 128

Enable - On

On



Off



Minimum Length - 2

1

2

10

20



30



40

50



Maximum Length - 20

1

10

20

30

40

50

Enable UCC/EAN 128 - Off

On



Off

Labelcode 4/5

Enable - Off

On

Off

Convert - Off

On

Off

UPC-A

Enable UPC-A - On

On

Off



Send System Digit - On

On

Off



Send Check Digit - Off

On

Off

Convert UPC-A to EAN-13 - Off

On

Off

UPC-E

Use System Digit 0 - On

On



Off

Use System Digit 1 - On

On

Off

Convert UPC-E to UPC-A - Off

On

Off

Send System Digit - Off

On

Off

Send Check Digit - Off

On

Off

EAN/JAN

Enable EAN-8/JAN-8 - On

On



Off

Enable EAN-13/JAN-13 - On

On

Off

Convert EAN-13 to ISBN - Off

On

Off

Send EAN/JAN Checksum - Off

On

Off

UPC/EAN/JAN Extensions

Allow 2-Digit Extensions - On

On



Off

Allow 5-Digit Extensions - On

On

Off

Require Extensions - Off

On

Off

Other Controls

Autoterminator - CR

(C R)

(TAB)

None

Auto-Off Timer - 5 min.

Off



20 sec.

40 sec.

1 min.



2 min.

3 min.

4 min.



5 min.

6 min.

Send Symbology Identifier - Off

On

Off



Good-Read Beep Tone (in Hertz) - 2400

2400

2800

3200

3600

Number of Good-Read Beeps - 1

1



2

3

4

Good-Read Beep Duration (in seconds) - 0.07

0.07

0.13

0.18

0.36

Beeper Volume - Highest

Off

Lowest

Medium

Highest

Higher

Lower

Error Beep Tone (in Hertz) - 2580

2580

3000

3600

4520

Long-Range Trigger Mode – Off

Long range scanner parameter only.

On = Release Scan;
Off = Spot Timeout

On



Off



Spotting Beam Enable – On

Long range scanner parameter only.

On



Off



Spot Beam Timeout (in seconds) 0.5

Long range scanner parameter only.

0.25

0.5

1

1.5

2

Release Scan Timeout (in seconds) - 2

1

2

3

5

10

30

Keypress Sound - Click

Off



Click

Beep



Enable Ctl-Alt-Del Reboot - On

On

Off



Enable Trigger Programmability - On

On



Off



Backlight Auto-Off Timeout (in seconds) - 15

Off

2

5

7

9

15

20

30

Appendix C
Barcodes for
Configuring MX2

Double Key Action Mode – Double Press

Double Press



Press and Wait

Double Key Action Timeout – 330 ms

165



220

275

330

385

440

495

550

605

660

Table of Contents

APPENDIX D KEY MAPS **D-1**

Keypad D-1

Key Map 101-Key Equivalencies for Batch Units..... D-2

Illustrations

Figure D-1 MX2 Keypad D-1

Appendix D
Key Maps

Keypad



Figure D-1 MX2 Keypad

Note: The batch unit key mapping is used on hand held computers that are NOT running an LXE Terminal Emulator.

When running LXE's ANSI Plus and TN3270 or TN5250 Terminal Emulation (TE) programs on the MX2, please refer to the following terminal emulation reference guides for equivalent keys and keypress sequences:

ANSI Plus Reference Guide	ANSIPA136PROGREF
TN3270 Terminal Reference Guide	TN3270A136RFGD
TN5250 Terminal Reference Guide	TN5250A136RFGD

The MX2 does not use the following keys normally found on a desktop computer keyboard:

F11	F12	Open/Closed Parentheses
Scroll Lock	Pause/Break	Print Screen/SysReq
Insert	Num Lock	Numeric keypad number keys
Right Alt		Open/Closed Square Brackets
Right Ctrl		Open/Closed Curly Braces

Key Map 101-Key Equivalencies for Batch Units

When using a sequence of keys that includes the Fn key, press the Fn key first then the rest of the key sequence.

Note: When the computer boots, the default condition of Caps (or CapsLock) is Off. The Caps (or CapsLock) condition can be set using BIOS Setup or toggled with a Fn-CTL key sequence. The CAPS icon is on the screen when CapsLock is On.

To get this	First press this key				Then press
key	Fn	DblStk	Ctrl	Alt	this key
Contrast	✔				Lamp Key then up/down arrow keys
Volume					MX2 Config Program
Fn					Fn
Shift	✔				Ctrl
Alt					Alt
Ctrl					Ctrl
Scan					Scan
Enter					Enter
Escape					Esc
International	✔			✔	Desired Keys[1]
Back Space	✔				Space
Tab	✔				0

[1] See Chapter 2 "Using Advanced Features" Section titled "Key Combinations for International Characters" for keypresses and instruction. This keyed function is a DOS function and does not affect LXE terminal emulation-assigned international characters.

To get this	First press this key				Then press
key	Fn	DblStk	Ctrl	Alt	this key
BackTab					N/A
Space					Space
Break					N/A
Pause					N/A
Up Arrow	✔				8
Down Arrow	✔				2
Right Arrow	✔				6
Left Arrow	✔				4
Pan Up	✔				5 then Up Arrow
Pan Down	✔				5 then Down Arrow
Pan Right	✔				5 then Right Arrow
Pan Left	✔				5 then Left Arrow
Pan Home	✔				7
Insert					N/A
Delete	✔				Esc
Home	✔				7
End	✔				1
Page Up	✔				9
Page Down	✔				3
NumLock (Toggle)					N/A
CapsLock (Toggle)	✔				Ctl
Right Shift	✔		✔		6
Left Shift	✔		✔		4
Right Alt					N/A
Left Alt					Alt
Right Ctrl					N/A
Left Ctrl					Ctrl
ScrollLock					N/A
PrintScrn					N/A
SysReq					N/A
F1					F1
F2					F2

To get this	First press this key				Then press
key	Fn	DblStk	Ctrl	Alt	this key
F3					F3
F4					F4
F5					F5
F6	✔				F1
F7	✔				F2
F8	✔				F3
F9	✔				F4
F10	✔				F5
F11					N/A
F12					N/A
a					**A**B
b		✔			A**B**
c					**C**D
d		✔			C**D**
e					**E**F
f		✔			E**F**
g					**G**H
h		✔			G**H**
i					**I**J
j		✔			I**J**
k					**K**L
l		✔			K**L**
m					**M**N
n		✔			M**N**
o					**O**P
p		✔			O**P**
q					**Q**R
r		✔			Q**R**
s					**S**T
t		✔			S**T**
u					**U**V
v		✔			U**V**

To get this	First press this key				Then press
key	Fn	DblStk	Ctrl	Alt	this key
w					**W**X
x		✔			W**X**
y					**Y**Z
z		✔			Y**Z**
A	✔		✔		**A**B
B	✔	✔	✔		A**B**
C	✔		✔		**C**D
D	✔	✔	✔		C**D**
E	✔		✔		**E**F
F	✔	✔	✔		E**F**
G	✔		✔		**G**H
H	✔	✔	✔		G**H**
I	✔		✔		**I**J
J	✔	✔	✔		I**J**
K	✔		✔		**K**L
L	✔	✔	✔		K**L**
M	✔		✔		**M**N
N	✔	✔	✔		M**N**
O	✔		✔		**O**P
P	✔	✔	✔		O**P**
Q	✔		✔		**Q**R
R	✔	✔	✔		Q**R**
S	✔		✔		**S**T
T	✔	✔	✔		S**T**
U	✔		✔		**U**V
V	✔	✔	✔		U**V**
W	✔		✔		**W**X
X	✔	✔	✔		W**X**
Y	✔		✔		**Y**Z
Z	✔	✔	✔		Y**Z**
1 (alpha)					N/A
2 (alpha)					N/A

To get this	First press this key				Then press
key	Fn	DblStk	Ctrl	Alt	this key
3 (alpha)					N/A
4 (alpha)					N/A
5 (alpha)					N/A
6 (alpha)					N/A
7 (alpha)					N/A
8 (alpha)					N/A
9 (alpha)					N/A
0 (alpha)					N/A
DOT (alpha)	✔				YZ
1 (numeric)					1
2 (numeric)					2
3 (numeric)					3
4 (numeric)					4
5 (numeric)					5
6 (numeric)					6
7 (numeric)					7
8 (numeric)					8
9 (numeric)					9
0 (numeric)					0
DOT (numeric)					N/A
- (numeric)					N/A
+ (numeric)					N/A
/ (numeric)					N/A
* (numeric)					N/A
Home (numeric)	✔				7
End (numeric)	✔				1
PgDn (numeric)	✔				3
PgUp (numeric)	✔				9
Lt Arrow (numeric)	✔				4
Rt Arrow (numeric)	✔				6
Up Arrow (numeric)	✔				8
Dn Arrow (numeric)	✔				2

To get this	First press this key				Then press
key	Fn	DblStk	Ctrl	Alt	this key
Insert (numeric)					N/A
Del (numeric)	✔				Esc
<	✔	✔			M**N**
>	✔	✔			C**D**
=	✔	✔			E**F**
: (colon)	✔				**S**T
; (semicolon)	✔	✔			S**T**
?	✔				**Q**R
`	✔				**O**P
{					N/A
}					N/A
- (minus sign)	✔	✔			G**H**
_ (underscore)	✔	✔			Q**R**
, (comma)	✔	✔			Y**Z**
+	✔	✔			I**J**
[					N/A
]					N/A
‘(apostrophe)	✔				**C**D
~ (tilde)	✔				**M**N
/	✔				**E**F
\	✔				**G**H
|	✔	✔			O**P**
“	✔	✔			W**X**
!	✔				**I**J
@	✔				**A**B
#	✔	✔			A**B**
$	✔				**K**L
%	✔	✔			K**L**
^	✔				**U**V
&	✔	✔			U**V**
* (asterisk)	✔				**W**X
(					N/A

To get this	First press this key				Then press
key	Fn	DblStk	Ctrl	Alt	this key
)					N/A